

[Manuals.plus](#) /

> [Panasonic](#) /

> Panasonic LAMDASH Shaver Cleaning Agent ES-4L06A Instruction Manual

Panasonic ES-4L06A

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

[Submit question](#)

Panasonic LAMDASH Shaver Cleaning Agent ES-4L06A Instruction Manual

This manual provides instructions for the proper use and maintenance of Panasonic LAMDASH Shaver Cleaning Agents, model ES-4L06A.

PRODUCT OVERVIEW

The Panasonic LAMDASH Shaver Cleaning Agent (Model ES-4L06A) is designed for use with Panasonic LAMDASH shaver cleaning and charging stations. This product ensures effective cleaning and maintenance of your electric shaver, contributing to its longevity and performance. Each package contains six individual cleaning agent packets.



Image 1: Six individual packets of Panasonic LAMDASH Shaver Cleaning Agent. Each packet is blue with white text and a scissor icon indicating where to open.

SAFETY INFORMATION

- Keep out of reach of children.
- Do not ingest. If swallowed, seek immediate medical attention.
- Avoid contact with eyes. In case of contact, rinse thoroughly with water and consult a doctor if irritation persists.
- Use only as directed with compatible Panasonic LAMDASH shaver cleaning and charging stations.
- Store in a cool, dry place away from direct sunlight.

SETUP AND PREPARATION

1. **Unpack the Cleaning Agent:** Carefully remove one cleaning agent packet from its packaging.



Image 2: A close-up view of six Panasonic LAMDASH Shaver Cleaning Agent packets, showing the branding and instructions in Japanese.

2. **Locate the Cleaning Station Reservoir:** Refer to your shaver cleaning station's manual to identify the cleaning solution reservoir.
3. **Open the Packet:** Tear or cut the cleaning agent packet along the indicated line (usually marked with scissors).
4. **Pour the Agent:** Carefully pour the entire contents of one cleaning agent packet into the designated reservoir of your Panasonic LAMDASH shaver cleaning station.
5. **Close the Reservoir:** Securely close the reservoir lid after pouring.

OPERATING INSTRUCTIONS

Once the cleaning agent is loaded into the reservoir, follow the operating instructions for your specific Panasonic LAMDASH shaver cleaning and charging station.

1. **Place Shaver in Station:** Ensure your shaver is clean of large debris and correctly placed in the cleaning station.
2. **Initiate Cleaning Cycle:** Press the start button or follow the prompts on your cleaning station to begin the cleaning cycle.

3. **Drying and Charging:** After the cleaning cycle, the station will typically dry and charge the shaver. Allow the process to complete fully.

Note: The frequency of cleaning agent replacement depends on usage. Replace the cleaning agent when the cleaning solution level is low or when the cleaning indicator on your station suggests it.

MAINTENANCE AND STORAGE

- **Cleaning Agent Replacement:** Replace the cleaning agent approximately every 1 to 1.5 months with daily use, or as indicated by your cleaning station.
- **Disposal:** Dispose of used cleaning solution and empty packets according to local regulations.
- **Storage of Unused Packets:** Store unused cleaning agent packets in their original packaging in a cool, dry place.



Image 3: An open cardboard box showing three cleaning agent packets inside, illustrating how the product is packaged.



Image 4: The exterior of the cardboard packaging for the Panasonic LAMDASH Shaver Cleaning Agent, indicating the model number ES-4L06A and quantity.

TROUBLESHOOTING

If you encounter issues with the cleaning process, consider the following:

- **Shaver Not Cleaning Properly:**
 - Ensure the cleaning agent reservoir has sufficient solution.
 - Verify the shaver is correctly seated in the cleaning station.
 - Check if the cleaning agent needs replacement.
- **Cleaning Station Indicator Lights:** Refer to your shaver cleaning station's specific manual for interpretation of indicator lights and error codes.
- **Unusual Odor:** If an unusual odor is detected, replace the cleaning solution. Ensure the cleaning station is clean and free of debris.

SPECIFICATIONS

Feature	Detail
Brand	Panasonic

Model Number	ES-4L06A
Product Type	Shaver Cleaning Agent
Quantity	6 pieces per pack
Material Feature	Biodegradable Warning
Package Dimensions	7.99 x 5.24 x 0.67 inches
Item Weight	5.29 ounces

WARRANTY AND SUPPORT

For warranty information and customer support regarding your Panasonic LAMDASH shaver cleaning station or the cleaning agents, please refer to the documentation provided with your shaver or visit the official Panasonic website.

Panasonic Official Website: www.panasonic.com