Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Colibri CU300T1

Colibri Premium V-Cut Cigar Cutter Instruction Manual

Model: CU300T1

1. Introduction

Thank you for choosing the Colibri Premium V-Cut Cigar Cutter. This precision-engineered tool is designed to provide a clean and deep V-cut for your cigars, enhancing your smoking experience. Please read this manual carefully to ensure proper use and maintenance of your cutter.

2. Product Overview

The Colibri V-Cut Cigar Cutter features a robust construction with a zinc body and sharp stainless steel blades. Its ergonomic design ensures a comfortable and secure grip, while the advanced spring-loaded mechanism allows for effortless operation.





Figure 2.1: The Colibri V-Cut Cigar Cutter in its closed, compact state.





Figure 2.2: The cutter in its open position, revealing the V-shaped blade for cutting.



Figure 2.3: Dimensions of the Colibri V-Cut Cigar Cutter.

Key Features:

- **Precision Cutting Technology:** Sharp, stainless steel blade for a clean V-cut.
- **Advanced Spring-Loaded Mechanism:** Smooth, effortless operation.
- **Ergonomic Design:** Comfortable and secure grip.
- **Versatile Capacity:** Accommodates cigars up to a 60+ ring gauge.
- **Optimal Penetration:** Designed to penetrate up to 7mm into the cigar cap for a classic V-shape.

3. Setup

Your Colibri V-Cut Cigar Cutter comes ready for immediate use. No assembly is required. Simply remove it from its packaging.

4. Operating Instructions

Follow these steps to achieve a perfect V-cut on your cigar:

1. **Open the Cutter:** Locate the small button on the front of the cutter, below the V-cut opening. Press this button to release the spring-loaded mechanism, causing the top section of the cutter to extend upwards.
2. **Insert the Cigar:** Gently insert the head (cap) of your cigar into the V-shaped opening. Ensure the cigar is centered and

positioned to achieve your desired depth of cut, typically up to 7mm for a deep V-cut.

3. **Make the Cut:** With a firm and steady motion, push the top section of the cutter downwards. The sharp stainless steel blade will smoothly slice into the cigar cap, creating a precise V-shape.
4. **Retrieve the Cigar:** Once the cut is complete, release the pressure. The cutter will return to its open position, allowing you to remove your perfectly cut cigar.



Figure 4.1: Positioning a cigar for a V-cut.

Benefits of a V-Cut:

- Creates a larger surface area for drawing, resulting in a richer and fuller flavor.
- Minimizes the risk of the cigar cap unraveling, providing a cleaner smoking experience.
- Ideal for cigars with a larger ring gauge, offering a consistent and deep cut.

5. Maintenance

Proper care will ensure the longevity and performance of your Colibri V-Cut Cigar Cutter:

- **Cleaning:** After each use, gently tap out any loose tobacco remnants from the cutting chamber. For a more thorough cleaning, use a soft, dry cloth to wipe down the exterior and the blades. Avoid using water or harsh chemicals, as this can damage the finish or corrode the metal.
- **Blade Care:** The stainless steel blades are designed to stay sharp. Avoid cutting anything other than cigars to prevent dulling or damage.
- **Storage:** Store your cutter in a dry place, away from extreme temperatures and humidity. The included gift box provides

excellent protection when not in use.



Figure 5.1: Store your cutter in its original packaging for protection.

6. Troubleshooting

If you encounter any issues with your Colibri V-Cut Cigar Cutter, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Unclean or ragged cut	Improper cigar placement; dull blades (unlikely for new cutter); tobacco residue.	Ensure cigar is centered and fully inserted. Clean blades as per maintenance instructions.
Cutter mechanism feels stiff or sticky	Accumulation of tobacco oils or debris; lack of lubrication.	Clean the cutter thoroughly. If issue persists, contact customer support. Do not attempt to lubricate with non-food-grade oils.

Problem	Possible Cause	Solution
Cutter does not open/close smoothly	Obstruction in the mechanism; spring issue.	Check for any visible obstructions. If the spring mechanism is faulty, refer to the warranty section for repair or replacement.

7. Specifications

Attribute	Detail
Brand	Colibri
Model Number	CU300T1
Material	Zinc (Body), Stainless Steel (Blade)
Color	Black
Dimensions (L x W x H)	2.8 x 1.6 x 0.5 inches
Item Weight	4 ounces (114 Grams)
Max Ring Gauge	60+
Blade Penetration	Up to 7 Millimeters

8. Warranty and Support

Your Colibri Premium V-Cut Cigar Cutter is backed by a 2-year limited warranty, ensuring quality and durability. For warranty claims, technical support, or any inquiries, please refer to the contact information provided on your product packaging or visit the official Colibri website. Please retain your proof of purchase for warranty validation.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00H85QXPG

More documents and user manuals: **https://manuals.plus/**