

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Surebonder](#) /

› [Surebonder H-270F High Temperature Full Size Glue Gun Instruction Manual](#)

## Surebonder FPRH270F

# Surebonder H-270F High Temperature Full Size Glue Gun

Model: FPRH270F

## INTRODUCTION

---

The Surebonder H-270F is a high-temperature, full-size glue gun designed for optimal bonding with a variety of materials including metal, wood, ceramics, and other porous and non-porous surfaces. This manual provides essential information for the safe and effective use of your glue gun.

## SAFETY INFORMATION

---

**WARNING: This product contains chemicals known to the State of California to cause cancer, birth defects, or other reproductive harm. For more information, visit [www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov).**

Always exercise caution when operating the glue gun as the nozzle and melted glue can reach high temperatures. Keep out of reach of children.

Key safety features include:

- **Safety Fuse:** Designed to shut off the gun in the event of an electrical issue.
- **Insulated Nozzle:** Provides protection against burns.
- **Side Fins:** Prevent glue from flowing backward when the gun is laid down, ensuring stability and preventing accidental contact with hot surfaces.

## PRODUCT OVERVIEW

---



Front view of the Surebonder H-270F High Temperature Full Size Glue Gun, showcasing its green and black design with the Surebonder logo.



Side view of the Surebonder H-270F Glue Gun, highlighting the trigger mechanism and the integrated stand.



The Surebonder H-270F Glue Gun shown in its retail packaging, indicating it is a 'Full Size' and 'High Temp' model.

The Surebonder H-270F glue gun features a comfortable grip, a sturdy stand for stability during use, and a high-temperature heating element for strong bonds. It is designed to use full-size glue sticks.

## SETUP GUIDE

1. **Insert Glue Stick:** Insert a full-size (0.43 inch / 11mm diameter) glue stick into the opening at the back of the glue gun. Push it firmly until it stops.
2. **Position the Stand:** Ensure the integrated stand is flipped down to support the glue gun when not in use, preventing the hot nozzle from touching surfaces.
3. **Connect to Power:** Plug the power cord into a standard electrical outlet (120V AC).
4. **Preheat:** Allow the glue gun to preheat for approximately 3-5 minutes. The gun is ready when a slight pressure on the trigger dispenses melted glue.

## OPERATING INSTRUCTIONS

1. **Apply Glue:** Gently squeeze the trigger to dispense melted glue. Apply the glue to one of the surfaces you wish to bond.
2. **Join Surfaces:** Immediately press the two surfaces together firmly. Hot melt glue sets quickly, typically within 30-60 seconds.
3. **Refill Glue Stick:** As the glue stick shortens, insert a new one into the back of the gun. The new stick will push the old one through. Do not pull out partially used glue sticks from the back.
4. **After Use:** When finished, unplug the glue gun from the electrical outlet. Allow it to cool completely on its stand before storing.



Collage showing various crafting applications of the Surebonder H-270F glue gun, including attaching embellishments to fabric and wood.

## CARE AND MAINTENANCE

- **Cleaning:** Ensure the glue gun is unplugged and completely cool before cleaning. Wipe the exterior with a damp

cloth. Do not use abrasive cleaners or immerse the gun in water.

- **Nozzle Care:** Do not attempt to clean the nozzle while the gun is hot. Any hardened glue on the nozzle can be carefully removed once the gun is cool.
- **Storage:** Store the glue gun in a dry, safe place, away from extreme temperatures and out of reach of children.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Glue gun does not heat up.	Not plugged in; power outlet issue; internal fuse tripped.	Check power connection and outlet. If still not heating, the internal safety fuse may have tripped. The unit may need replacement.
Glue does not dispense.	Not preheated long enough; glue stick not fully inserted; wrong size glue stick.	Allow adequate preheating time (3-5 minutes). Ensure glue stick is pushed in completely. Use only full-size (0.43 inch / 11mm) glue sticks.
Glue drips from nozzle.	Normal for high-temperature glue guns; gun is too hot.	A small amount of dripping is normal. Ensure the gun is on its stand when not in use. Unplug if not using for extended periods.

## SPECIFICATIONS

Feature	Detail
Model Number	FPRH270F
Color	Green/Black
Power Source	Corded Electric
Compatible Material	Ceramic, Glass, Metal, Wood
Material	Metal, Plastic
Item Weight	9.2 ounces
Product Dimensions	9.38 x 7.25 x 2.25 inches
UPC	018239354290

## WARRANTY INFORMATION

This Surebonder H-270F High Temperature Full Size Glue Gun comes with a **90-day warranty** from the date of purchase. This warranty covers manufacturing defects under normal use. Please retain your proof of purchase for warranty claims. For warranty service or support, please contact Surebonder customer service.

## IMPORTANT NOTE ON VIDEOS

No official product videos could be embedded in this manual as no video source URLs were provided in the product data. Only image assets were available.

© 2024 Surebonder. All rights reserved.

For further assistance, visit the [Surebonder Store on Amazon](#).