

[Manuals.plus](#) /

› [parts-quick](#) /

› PARTS-QUICK 4GB DDR3 PC3-10600 1333MHz DIMM Memory Module for HP Pavilion Elite e9180f Instruction Manual

## parts-quick 4GB DDR3 PC3-10600 1333MHz DIMM

# PARTS-QUICK 4GB DDR3 PC3-10600 1333MHz DIMM Memory Module

## INSTRUCTION MANUAL FOR HP PAVILION ELITE e9180F

### 1. Introduction

This manual provides detailed instructions for the installation, operation, maintenance, and troubleshooting of your new PARTS-QUICK 4GB DDR3 PC3-10600 1333MHz DIMM memory module. This module is specifically designed for compatibility with the HP Pavilion Elite e9180f desktop computer, enhancing its performance by increasing available system memory. Please read this manual thoroughly before proceeding with installation.

### 2. Safety Precautions

Before handling any internal computer components, observe the following safety guidelines to prevent damage to yourself or your equipment:

- **Power Off:** Always ensure your computer is completely powered off and unplugged from the wall outlet before opening the case.
- **Static Electricity:** Static electricity can damage sensitive electronic components. Discharge static electricity by touching a grounded metal object (e.g., the unpainted metal chassis of your computer) before handling the memory module. Consider using an anti-static wrist strap.
- **Handle with Care:** Hold the memory module by its edges, avoiding contact with the gold connector pins or the chips on the module.
- **Work Area:** Ensure your work area is clean, well-lit, and free of obstructions.

### 3. Installation Guide

Follow these steps carefully to install the memory module into your HP Pavilion Elite e9180f desktop computer.

#### 3.1. Preparation

1. Shut down your computer completely.
2. Unplug the power cord and all other cables (monitor, keyboard, mouse, USB devices, etc.) from the back of the computer.
3. Move the computer to a clean, flat, and stable work surface.

### 3.2. Accessing Memory Slots

1. Locate and remove the screws securing the side panel of your computer case. Typically, these are on the rear of the case.
2. Carefully slide off the side panel to expose the internal components.
3. Identify the motherboard and the existing RAM slots. These are usually long, narrow slots with clips on either end, often located near the CPU.

### 3.3. Installing the Memory Module

1. If you are replacing an existing module, gently push down the clips on both ends of the slot to release the old module. Remove it carefully.
2. Unpack the new PARTS-QUICK memory module. Hold it by the edges.
3. Align the notch on the memory module with the key in the RAM slot. This ensures correct orientation.
4. Place the module into the slot and apply firm, even pressure to both ends simultaneously until the clips on the sides snap into place, securing the module. You should hear a click.
5. Visually inspect the module to ensure it is seated correctly and evenly in the slot, with the clips fully engaged.



*Figure 1: PARTS-QUICK 4GB DDR3 PC3-10600 1333MHz DIMM Memory Module. This image shows the general appearance of the memory module, highlighting its form factor and connector pins.*

### 3.4. Reassembly

1. Slide the computer's side panel back into place and secure it with the screws you removed earlier.
2. Reconnect all cables (power, monitor, keyboard, mouse, etc.) to the back of your computer.

3. Plug the power cord back into the wall outlet.

## 4. Verifying Installation

After installation, power on your computer and verify that the new memory is recognized:

- **BIOS/UEFI Check:** During startup, press the designated key (often Del, F2, F10, or Esc) to enter the BIOS/UEFI setup. Navigate to the system information or memory section to confirm the total installed RAM.
- **Operating System Check (Windows):** Once Windows loads, right-click on 'This PC' or 'My Computer', select 'Properties'. The 'Installed RAM' or 'Memory' section should display the updated total memory.
- **Operating System Check (Linux):** Open a terminal and type `free -h` or `sudo lshw -short -C memory` to view memory details.

If the memory is not recognized, refer to the Troubleshooting section.

## 5. Maintenance

Memory modules generally require minimal maintenance. To ensure optimal performance and longevity:

- **Dust Removal:** Periodically open your computer case (following safety precautions) and use compressed air to gently remove dust buildup from around the memory modules and other components. Dust can impede airflow and lead to overheating.
- **Environmental Control:** Operate your computer in a clean, dry environment with adequate ventilation to prevent excessive heat and humidity, which can negatively impact electronic components.

## 6. Troubleshooting

If you encounter issues after installing the memory module, consult the following table:

| Problem                                                      | Possible Cause                           | Solution                                                                                                                                                      |
|--------------------------------------------------------------|------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Computer does not boot or displays a blank screen.           | Memory module not seated correctly.      | Power off and unplug the computer. Re-seat the memory module firmly in its slot, ensuring the clips snap into place.                                          |
| Operating system reports incorrect amount of RAM.            | Module not fully recognized or faulty.   | Verify seating. If issue persists, try the module in a different slot (if available) or test with another known-good module if possible. Check BIOS settings. |
| System instability, crashes, or Blue Screen of Death (BSOD). | Faulty module or incompatibility.        | Run a memory diagnostic tool (e.g., Windows Memory Diagnostic). If errors are found, the module may be faulty. Ensure your system's BIOS is up to date.       |
| Computer emits a series of beeps on startup.                 | BIOS POST error indicating memory issue. | Consult your HP Pavilion Elite e9180f motherboard manual for beep codes to diagnose the specific memory error. Re-seat the module.                            |

## 7. Specifications

Detailed specifications for the PARTS-QUICK 4GB DDR3 PC3-10600 1333MHz DIMM memory module:

| Feature  | Detail |
|----------|--------|
| Capacity | 4 GB   |

| Feature                  | Detail                           |
|--------------------------|----------------------------------|
| Form Factor              | 240-pin DIMM                     |
| Memory Type              | DDR3 SDRAM                       |
| Speed                    | PC3-10600 (1333 MHz)             |
| Voltage                  | 1.5V                             |
| Error Correction         | Non-ECC                          |
| Buffering                | Unbuffered                       |
| Compatibility            | HP Pavilion Elite e9180f Desktop |
| Environmental Compliance | Halogen Free; ROHS               |
| Item Weight              | 8 ounces                         |

### 8. Warranty and Support

---

This PARTS-QUICK memory module is backed by a **Lifetime Warranty**, ensuring peace of mind regarding its quality and durability. For technical assistance, troubleshooting, or warranty claims, please contact PARTS-QUICK Toll Free Technical Support. Refer to the product packaging or the PARTS-QUICK official website for current contact information.