

Manuals.plus /

> [Geberit](#) /

> Geberit AP130 Toilet Cistern Lid with Flush Button (Model 240099111) - User Manual

Geberit 240099111

Geberit AP130 Toilet Cistern Lid with Flush Button (Model 240099111) - User Manual

Brand: Geberit | Model: 240099111

1. INTRODUCTION

This manual provides essential information for the proper installation, operation, and maintenance of your Geberit AP130 toilet cistern lid, model 240099111. Please read these instructions carefully before proceeding with installation or use to ensure correct function and longevity of the product. Retain this manual for future reference.

2. PRODUCT OVERVIEW

The Geberit AP130 toilet cistern lid is a replacement component designed for specific Geberit cisterns. It includes an integrated flush button mechanism for efficient water discharge. This lid is manufactured to Geberit's quality standards, ensuring compatibility and reliable performance.

2.1 Components

- Cistern Lid (White)
- Integrated Flush Button Mechanism



Figure 1: Top view of the Geberit AP130 toilet cistern lid, showing the main body and the flush button on the right side.



Figure 2: Angled perspective of the cistern lid, providing a clearer view of the flush button's textured surface and its integration into the lid.

3. SETUP AND INSTALLATION

Installation of the Geberit AP130 cistern lid is generally straightforward, assuming the existing cistern is compatible. If you are unsure about compatibility or the installation process, it is recommended to consult a qualified plumber.

1. **Preparation:** Ensure the toilet cistern is clean and free from debris. If replacing an old lid, carefully remove it.
2. **Positioning:** Align the new Geberit AP130 lid over the top of the cistern. Ensure it sits flush and evenly on all sides.
3. **Flush Button Alignment:** Gently press down on the lid. The integrated flush button mechanism should align with the internal flushing components of your Geberit cistern. Verify that the button can be pressed smoothly

and returns to its original position without obstruction.

4. **Testing:** Perform a test flush to confirm that the button activates the flushing mechanism correctly and that the lid remains stable during operation.



Figure 3: Underside view of the cistern lid, illustrating the internal structure and potential mounting or alignment points for the flush mechanism.

4. OPERATION

The Geberit AP130 cistern lid operates by pressing the integrated flush button. This button activates the flushing mechanism within the cistern, releasing water into the toilet bowl. Ensure the button is pressed firmly and released completely for optimal flushing performance.

5. MAINTENANCE

Regular cleaning and inspection will help maintain the appearance and functionality of your Geberit AP130 cistern lid.

- **Cleaning:** Clean the lid surface with a soft cloth and mild, non-abrasive cleaning agents. Avoid harsh chemicals or abrasive scrubbers, as these can damage the finish.
- **Inspection:** Periodically check the flush button for smooth operation. Ensure there is no sticking or excessive resistance.
- **Damage:** If the lid or flush button becomes damaged, consider replacing the unit to ensure proper hygiene and function.

6. TROUBLESHOOTING

This section addresses common issues you might encounter with the Geberit AP130 cistern lid.

Problem	Possible Cause	Solution
Flush button sticks or is hard to press.	Misalignment with internal mechanism, debris, or internal component wear.	◦ Re-seat the lid to ensure proper alignment. ◦ Clean around the button to remove any debris. ◦ If the issue persists, the internal flush mechanism (not part of the lid) may require inspection or replacement by a professional.
Lid does not sit flush on the cistern.	Incorrect lid model for cistern, obstruction, or damage to the cistern rim.	◦ Verify the lid model (240099111) is compatible with your Geberit cistern. ◦ Check for any foreign objects or damage on the cistern rim that might prevent the lid from seating properly.

7. SPECIFICATIONS

Attribute	Detail
Brand	Geberit
Model Number	240099111
Part Number	240099111
Color	White
Item Weight	1.34 pounds (approx. 0.61 kg)
Product Dimensions	16.06 x 6.38 x 5.59 inches (approx. 40.8 x 16.2 x 14.2 cm)
Manufacturer	Geberit
Batteries Required	No

8. WARRANTY AND SUPPORT

Specific warranty information for the Geberit AP130 cistern lid (Model 240099111) is typically provided at the point of purchase or can be found on the official Geberit website. For technical support, replacement parts, or warranty claims, please contact Geberit customer service or your authorized Geberit dealer. Always refer to your purchase documentation for details regarding your product's warranty period and terms. For further assistance, visit the official Geberit website:www.geberit.com

© 2023 Geberit. All rights reserved. Information in this manual is subject to change without notice.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B00HNTA510>

More documents and user manuals: <https://manuals.plus/>