

Sony BDPS1200

Sony BDPS1200 Wired Blu-Ray Disc Player User Manual

1. INTRODUCTION

This manual provides essential information for setting up, operating, and maintaining your Sony BDPS1200 Blu-Ray Disc Player. The BDPS1200 is designed to deliver high-quality video and audio playback from Blu-ray discs and DVDs, along with access to various streaming services via a wired Ethernet connection.



Figure 1: Front view of the Sony BDPS1200 Blu-Ray Disc Player, showcasing its sleek, compact design with the disc tray and power button visible.

2. SETUP GUIDE

Follow these steps to connect your Sony BDPS1200 Blu-Ray Disc Player to your television and network.

2.1 Connecting to a Television

1. **Power Off:** Ensure your television and the Blu-ray player are both powered off before making any connections.
2. **HDMI Connection:** Connect one end of an HDMI cable (sold separately) to the HDMI OUT port on the

rear of the Blu-ray player. Connect the other end to an available HDMI IN port on your television. Note the HDMI input number on your TV for later selection.

3. **Power Connection:** Connect the AC power cord to the Blu-ray player and then plug it into a wall outlet.

2.2 Network Connection (Wired)

The BDPS1200 uses a wired Ethernet connection for internet access.

1. **Ethernet Cable:** Connect an Ethernet cable from your router or modem to the LAN (Ethernet) port on the rear of the Blu-ray player.
2. **Network Settings:** After powering on, navigate to the player's network settings menu to configure the wired connection if necessary. Most wired connections are automatically detected.



Figure 2: Angled view of the Sony BDPS1200 Blu-Ray Disc Player, highlighting its compact form factor and the Blu-ray disc logo on the disc tray.

3. OPERATING INSTRUCTIONS

This section covers the basic operation of your Blu-ray Disc Player.

3.1 Disc Playback

1. **Power On:** Turn on your television and select the correct HDMI input. Power on the Blu-ray player.
2. **Insert Disc:** Press the **OPEN/CLOSE** button to open the disc tray. Place a Blu-ray disc or DVD onto the tray with the label side facing up. Press **OPEN/CLOSE** again to close the tray.
3. **Start Playback:** The player will typically begin playback automatically. If not, select the disc icon from the home menu and press **PLAY**.

3.2 Streaming Services

Access a wide range of online content through the player's streaming capabilities.

1. **Access Home Menu:** From the player's home screen, navigate to the 'Video' or 'Network' section.

2. **Select Service:** Choose from available streaming applications such as Netflix, Pandora, YouTube, Hulu Plus, and more. A subscription may be required for some services.
3. **Quick Start/Load:** The player features Quick Start/Load technology, allowing for faster startup times and quicker access to disc playback and streaming content.

3.3 USB Media Playback

The player supports playback of media files from a USB flash drive.

1. **Insert USB Drive:** Insert your USB flash drive into the USB port on the front of the player.
2. **Select Media:** Navigate to the 'Photo', 'Music', or 'Video' section on the player's home menu and select the USB device. Browse and select your desired files for playback.

4. KEY FEATURES

The Sony BDPS1200 Blu-Ray Disc Player offers the following key features:

- **Full HD 1080p Blu-ray Disc Playback:** Experience movies in stunning high definition.
- **DVD Playback:** Enjoy your existing DVD collection with upscaling to near HD quality.
- **Access to Streaming Services:** Stream content from over 200 streaming services, including popular apps like Netflix, Pandora, YouTube, and Hulu Plus (requires wired Ethernet connection and subscriptions for some services).
- **Quick Start/Load:** Reduces startup time and speeds up disc loading for quicker entertainment access.
- **USB Playback:** Play videos, music, and view photos from a connected USB storage device.

Note: Features such as Dual Core processing, 4K Upscaling, 3D playback, Screen Mirroring, and Super Wi-Fi are not available on the BDPS1200 model.

Your browser does not support the video tag.

Video 1: An overview of Sony Blu-ray Player features, including streaming capabilities and quick start functions. This video highlights features across several models (BDPS1200, BDPS3200, BDPS5200, BDPS6200), with specific feature availability for the BDPS1200 noted in the manual's 'Key Features' section.

5. SPECIFICATIONS

Detailed technical specifications for the Sony BDPS1200 Blu-Ray Disc Player.

Feature	Specification
Brand	Sony
Model Name	BDPS1200
Media Type	Blu-Ray Disc, DVD
Special Feature	Blu-ray support
Resolution	1920x1080 (1080p)
Connector Type	HDMI

Feature	Specification
Connectivity Technology	HDMI, Ethernet
Color	Black
Item Weight	2 Pounds
Audio Output Mode	Surround
File Format Support	MP4, MP3, JPEG
Surround Sound Channel Configuration	7.1
Video Encoding	H.264/AVC
Compatible Devices	Television
Analog Video Format	NTSC
Number of Channels	7
Item Dimensions (L x W x H)	10.44"L x 7.84"W x 1.7"H
UPC	027242872769

6. TROUBLESHOOTING

If you encounter issues with your Blu-ray Disc Player, refer to the following common solutions.

6.1 No Power

- Ensure the power cord is securely connected to both the player and a working wall outlet.
- Check if the power outlet is functional by plugging in another device.

6.2 No Picture or Distorted Picture

- Verify the HDMI cable is securely connected to both the player and the TV.
- Ensure your TV is set to the correct HDMI input source.
- Try a different HDMI cable or TV input port.

6.3 No Sound or Distorted Sound

- Check the audio settings on both the player and your TV/audio receiver.
- Ensure volume is not muted or set too low.
- Verify all audio cables (if used) are properly connected.

6.4 Streaming Services Not Working

- Confirm the Ethernet cable is properly connected to the player and your router/modem.
- Check your internet connection by testing other devices on the same network.
- Restart your router/modem and the Blu-ray player.

- Ensure the player's firmware is up to date. Access the 'Settings' menu to check for and install updates.

6.5 Disc Playback Issues

- Clean the disc with a soft, lint-free cloth, wiping from the center outwards.
- Ensure the disc is inserted correctly with the label side facing up.
- Try playing a different disc to determine if the issue is with the player or the specific disc.

7. MAINTENANCE

Proper care and maintenance will help ensure the longevity and optimal performance of your Blu-ray Disc Player.

- **Cleaning the Unit:** Use a soft, dry cloth to wipe the exterior of the player. Avoid using abrasive cleaners, waxes, or solvents.
- **Disc Care:** Handle discs by their edges to avoid fingerprints and scratches. Store discs in their cases when not in use.
- **Ventilation:** Ensure adequate ventilation around the player to prevent overheating. Do not block ventilation openings.
- **Firmware Updates:** Periodically check for and install firmware updates through the player's settings menu to ensure optimal performance and access to the latest features and security enhancements.

8. WARRANTY AND SUPPORT

Your Sony BDPS1200 Blu-Ray Disc Player comes with a **90-day Limited Hardware Warranty**. For detailed warranty information and terms, please refer to the documentation included with your product or visit the official Sony support website.

For further assistance, technical support, or to view additional product resources, please visit the [Sony Store on Amazon](#) or the official Sony support website.