

[Manuals.plus](#) /

› [Energizer](#) /

› Energizer AC1UEUHIP5 iPhone 5 2100mA Travel Charger User Manual

Energizer AC1UEUHIP5

Energizer AC1UEUHIP5 Travel Charger User Manual

Model: AC1UEUHIP5

1. INTRODUCTION

This user manual provides essential information for the safe and efficient operation of your Energizer AC1UEUHIP5 Travel Charger. Please read this manual thoroughly before using the product and retain it for future reference.

The Energizer AC1UEUHIP5 charging kit is designed to provide a reliable power solution for your compatible smart devices. It serves as an ideal primary or backup charger, ensuring your devices remain powered throughout the day. The included connection cable facilitates both charging and data transfer capabilities for a wide range of compatible devices.





Figure 1: Energizer AC1UEUHIP5 Travel Charger and its retail packaging.

2. PACKAGE CONTENTS

Please verify that all items are present and in good condition upon opening the package. If any items are missing or damaged, contact customer support.

- 1 x Energizer AC1UEUHIP5 Wall Charger Adapter
- 1 x Compatible Charging/Data Cable (Lightning connector)
- 1 x User Manual (this document)
- 1 x Warranty Certificate

3. SETUP

Follow these steps to set up your Energizer AC1UEUHIP5 Travel Charger:

1. Unpack the wall charger adapter and the charging cable from their packaging.
2. Insert the USB-A end of the charging cable into the USB port on the Energizer wall charger adapter. Ensure it is fully inserted.

3. Plug the wall charger adapter into a standard electrical wall outlet.
4. Connect the Lightning connector end of the cable to your compatible device (e.g., iPhone 5, iPhone 5s, iPhone 5 SE).

The device should indicate that it is charging. For optimal performance, use a wall outlet that is easily accessible.

4. OPERATING INSTRUCTIONS

4.1 Charging Your Device

Once the charger is set up as described in Section 3, your device will begin charging automatically upon connection. The charger provides 2.1 Amps of power, suitable for rapid charging of compatible smartphones and tablets.

- Ensure your device is securely connected to the Lightning cable.
- Monitor your device's screen for the charging indicator.
- Disconnect your device once it is fully charged to conserve energy.

4.2 Data Transfer

The included cable also supports data transfer between your compatible device and a computer. To transfer data:

1. Disconnect the USB-A end of the cable from the wall charger adapter.
2. Connect the USB-A end of the cable to an available USB port on your computer.
3. Your device should be recognized by the computer, allowing for data synchronization or file transfer.

5. CARE AND MAINTENANCE

Proper care and maintenance will extend the lifespan of your Energizer charger:

- **Cleaning:** Disconnect the charger from the power outlet before cleaning. Use a soft, dry cloth to wipe the surface. Do not use liquid cleaners or aerosols.
- **Storage:** Store the charger and cable in a cool, dry place away from direct sunlight and extreme temperatures.
- **Handling:** Avoid dropping the charger or subjecting it to strong impacts. Do not bend or crimp the cable excessively.
- **Environment:** Do not expose the charger to water, moisture, or high humidity.

6. TROUBLESHOOTING

If you encounter issues with your Energizer AC1UEUHIP5 Travel Charger, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Device not charging.	• Charger not properly plugged in. • Cable not securely connected. • Faulty wall outlet. • Damaged cable or charger.	• Ensure charger is fully inserted into the wall outlet. • Check connections at both ends of the cable. • Try a different wall outlet. • Inspect cable and charger for visible damage. Replace if necessary.

Problem	Possible Cause	Solution
Slow charging.	• Device running power-intensive apps. • Cable degradation.	• Close unnecessary applications on your device. • Ensure the cable is the original or a certified replacement.
Device not recognized for data transfer.	• Cable not connected to computer. • Driver issues on computer.	• Ensure the cable's USB-A end is connected to a computer, not the wall adapter. • Restart your computer and device. Check computer's device manager for driver issues.

If the problem persists after attempting these solutions, please refer to the [Warranty and Support](#) section for further assistance.

7. SPECIFICATIONS

Brand	Energizer
Model	AC1UEUHIP5
Manufacturer	Energizer Batteries
Part Number	3492548144402
Compatible Devices	Mobile Phones (specifically iPhone 5, iPhone 5s, iPhone 5 SE)
Power Source	Wired Electric
Number of USB Ports	1
Connection Type	USB (Input), Lightning (Output)
Product Dimensions	1 x 1 x 1 cm
Product Weight	80 grams (0.08 Kilogram)
Color	White
First Available Date	March 24, 2014

8. WARRANTY AND SUPPORT

Your Energizer AC1UEUHIP5 Travel Charger comes with a warranty certificate. Please refer to the warranty certificate included in your package for detailed terms and conditions regarding coverage and duration.

For technical support, troubleshooting assistance beyond what is covered in this manual, or warranty claims, please contact Energizer customer service. Contact information can typically be found on the product packaging or the official Energizer website.

Please retain your proof of purchase for warranty purposes.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B00HU5DC1W>

More documents and user manuals: <https://manuals.plus/>