#### Manuals+

Q & A | Deep Search | Upload

#### manuals.plus /

- v4ink /
- > v4ink C7115X Toner Cartridge Instruction Manual for HP LaserJet Printers

#### v4ink C7115X-2PK

# v4ink C7115X Toner Cartridge Instruction Manual

Compatible with HP LaserJet 1000, 1150, 1200, 1220, 1300, 3300, 3310, 3320, 3330, 3380 Series

Printers

## 1. Introduction

This manual provides essential instructions for the installation, operation, and maintenance of your v4ink C7115X compatible toner cartridges. Please read this guide thoroughly to ensure optimal performance and longevity of your product.

The v4ink C7115X toner cartridges are designed to be compatible replacements for HP 13X, 15X, C7115X, Q2613X, and C7115A toner cartridges, offering high yield black ink for a range of HP LaserJet printers.



Image 1.1: v4ink C7115X Toner Cartridges and Packaging

# 2. COMPATIBLE PRINTER MODELS

The v4ink C7115X toner cartridges are compatible with the following HP LaserJet printer models:

- HP LaserJet 1000, 1000W, 1005
- HP LaserJet 1150, 1150n
- HP LaserJet 1200, 1200n, 1220
- HP LaserJet 1300, 1300n, 1300xi
- HP LaserJet 3300, 3310, 3320, 3320n, 3330, 3380, 3385, 3390

# **Compatible Printer List**



1000 1000W 1005 1150 1150n 1200 1220 1300 1300n 1300xi 3300 3310 3320 3330 3380 3385



Image 2.1: Compatible Printer List

#### 3. SETUP AND INSTALLATION

Follow these steps to install your new v4ink C7115X toner cartridge:

- 1. **Unpack the Cartridge:** Carefully remove the new toner cartridge from its packaging.
- 2. **Remove Sealing Tape:** Locate and firmly pull the sealing tape entirely from the cartridge. This tape protects the toner during shipping and must be removed for proper function.
- 3. Shake Gently: Gently rock the cartridge from side to side a few times to distribute the toner evenly inside.
- 4. **Open Printer Access:** Open the toner cartridge access door on your HP LaserJet printer. Refer to your printer's specific manual for exact location if unsure.
- 5. Remove Old Cartridge: Carefully remove the old toner cartridge from the printer.
- 6. **Insert New Cartridge:** Align the new v4ink cartridge with the guides inside the printer and push it firmly until it clicks into place.
- 7. Close Printer Access: Close the toner cartridge access door.

8. **Printer Recognition:** If your printer displays a message regarding a non-HP or compatible cartridge, press "OK" or confirm to bypass the message and continue printing. This is a standard notification for compatible cartridges and does not indicate a fault.

#### 4. OPERATING INSTRUCTIONS

Once installed, your v4ink C7115X toner cartridge is ready for use. These cartridges are designed to deliver reliable printing results with sharp text, bold blacks, and crisp graphics.

# **Page Yield**

Each v4ink C7115X toner cartridge is rated for approximately**4,000 pages** based on 5% coverage on letter/A4 sized paper. Actual page yield may vary significantly depending on content printed, print settings, and other factors.



Image 4.1: Estimated Page Yield

# **Standout Quality for Everyday Prints** OEMv4ink -

Image 4.2: Print Quality Example

#### 5. MAINTENANCE

To ensure consistent performance and extend the life of your toner cartridge and printer:

- **Storage:** Store unused toner cartridges in their original, sealed packaging in a cool, dry place away from direct sunlight and extreme temperatures.
- **Handling:** Avoid touching the drum or electrical contacts on the cartridge, as oils from your skin can affect print quality.
- **Printer Cleaning:** Periodically clean the inside of your printer according to the manufacturer's instructions to remove any toner dust buildup.

#### 6. TROUBLESHOOTING

If you encounter issues with your v4ink C7115X toner cartridge, consider the following:

• "Non-HP Cartridge" Message: As mentioned in the setup section, this is normal for compatible cartridges.

Simply press "OK" or confirm on your printer's display to proceed.

#### • Poor Print Quality (Streaks, Fading):

- Gently remove the cartridge and rock it side to side to redistribute toner. Reinstall and test.
- Ensure the sealing tape was completely removed during installation.
- Check printer settings for print quality and toner density.
- If the cartridge is nearing its estimated page yield, it may be running low on toner.

#### • Cartridge Not Recognized:

- Remove the cartridge and inspect the electrical contacts on both the cartridge and inside the printer for any debris or damage. Gently wipe contacts with a lint-free cloth.
- Ensure the cartridge is seated firmly and correctly in its slot.
- · Restart your printer and computer.

If problems persist, please refer to the Warranty and Support section for contact information.

## 7. SPECIFICATIONS

Feature	Detail
Product Name	v4ink C7115X Compatible Toner Cartridge
Compatibility Options	C7115X, 13X, 15X, Q2613X, C7115A
Color	Black
Page Yield	Up to 4,000 pages (at 5% coverage, Letter/A4)
Special Feature	High Yield
Product Dimensions	12.5 x 6.5 x 6.5 inches
Item Weight	0.01 ounces (per cartridge)
Included Components	Toner Cartridge

## 8. WARRANTY AND SUPPORT

v4ink is committed to providing high-quality compatible printer consumables. Our products undergo careful manufacturing, testing, and inspection to ensure a top-notch print experience.

We offer a professional guarantee for our products. For any questions, technical support, or warranty claims, please contact v4ink customer service through the retailer where you purchased the product or visit the official v4ink website for support options.

v4ink has been trusted by over one million printer users for the past 10 years, reflecting our dedication to customer satisfaction and product reliability.



#### Related Documents - C7115X-2PK



#### v4ink Product Safety Warning and Contact Information

Important safety warnings for v4ink products, including contact details for manufacturers and representatives in the UK and EU. Information on product handling and disposal.



# Brother HL-L8430CDW Business Color Laser Printer: Specifications and Features

Detailed information on the Brother HL-L8430CDW business color laser printer, including its low-cost printing, high-quality output, advanced security features, expandable paper capacity, specifications, and optional accessories.



#### Honeywell Home X8S Smart Thermostat Getting Started Guide

This guide provides instructions for installing and setting up the Honeywell Home X8S Smart Thermostat, including wiring, app connection, and basic troubleshooting.



#### Brookstone WiFi Camera User Manual

Comprehensive user manual for the Brookstone WiFi Camera (Model BKWIFICAM4-2PK-WM), covering setup, features, app functions, and troubleshooting for optimal home security and monitoring.



#### LEDEEZ Multicolor Smart LED Bulbs User Manual

User manual for LEDEEZ Multicolor Smart LED Bulbs (2-Pack) with Bluetooth connectivity. Includes instructions on setup, app control, group creation, safety precautions, and FCC compliance.



#### Müller Graveyard Candles Safety Data Sheet

Safety Data Sheet for Müller Graveyard Candles, providing detailed information on product identification, hazards, composition, first aid, firefighting, accidental release measures, handling and storage, exposure controls, physical and chemical properties, stability and reactivity, toxicological information, ecological information, disposal considerations, transport information, and regulatory information.