

[Manuals.plus](#) /

› [hansgrohe](#) /

› Hansgrohe Focus 04505800 Stainless Steel High Arc Kitchen Faucet User Manual

hansgrohe 04505800

Hansgrohe Focus 04505800 Stainless Steel High Arc Kitchen Faucet User Manual

INTRODUCTION

The Hansgrohe Focus range of kitchen faucets combines modern aesthetics with practical functionality. Designed to integrate seamlessly into contemporary kitchens with clean lines, this faucet offers a high-quality, scratch-resistant stainless-steel optic finish. Its high arc spout provides ample space for various kitchen tasks, and the pull-down spray head enhances versatility with two distinct spray modes. This manual provides essential information for the installation, operation, and maintenance of your Hansgrohe Focus kitchen faucet.



Figure 1: Hansgrohe Focus Stainless Steel High Arc Kitchen Faucet

PRODUCT FEATURES

- **Modern Functionality:** Flexible design suitable for various kitchen ambiances.
- **Stainless Steel Optic Finish:** High-quality, scratch-resistant surface achieved through PVD technology.
- **Enhanced Movement:** 150° swivel spout for increased access to the kitchen sink.
- **Pull-Down Spray:** Extends reach for targeted rinsing of fruits, vegetables, and general cleaning.
- **Dual Spray Modes:** Easily switch between crystal clear laminar spray for filling pots and a gentle shower spray for delicate items.
- **Magnetic Docking:** Hansgrohe MagFit ensures the pull-out spray head is securely and centrally held in the spout.
- **Flexible Hoses:** 3/8-inch hoses for quick connection to standard angle valves.



Figure 2: Key Features of the Hansgrohe Focus Faucet

SETUP AND INSTALLATION

Hansgrohe recommends that a licensed plumber install this product to ensure proper function and adherence to local plumbing codes. The faucet is designed for deck mount installation with a single hole. The mounting hole diameter should be 1 inch. The faucet includes flexible 3/8-inch hoses for connection to standard hot and cold angle valves.

Installation Steps (General Overview):

1. Ensure water supply is turned off at the main shut-off valve.
2. Prepare the mounting hole on the sink or countertop.
3. Insert the faucet into the mounting hole.
4. Secure the faucet from underneath the sink using the provided mounting hardware.
5. Connect the flexible supply hoses to the hot and cold water lines.
6. Attach the pull-down spray hose and counterweight (if applicable) to ensure smooth retraction.

7. Turn on the water supply and check for leaks.



Figure 3: Faucet Dimensions and Installation Overview

OPERATING INSTRUCTIONS

Your Hansgrohe Focus kitchen faucet is designed for ease of use and versatility.

- **Water Flow Activation:** Lift the lever handle to turn on the water flow. Push down to turn off.
- **Temperature Control:** Move the lever handle left for hot water and right for cold water.
- **Swivel Spout:** The high arc spout can swivel 150°, allowing you to direct water flow across your sink area.
- **Pull-Down Spray Head:** Gently pull the spray head down from the spout to extend it. The magnetic docking system (MagFit) will securely return it to its position when released.
- **Changing Spray Modes:** A button on the spray head allows you to switch between two spray types: a crystal clear laminar spray for powerful filling and a gentle shower spray for rinsing delicate items like fruits and vegetables.

Your browser does not support the video tag.

Video: Hansgrohe Focus Kitchen Faucet Overview (Duration: 0:57)

This video demonstrates the operation and features of the Hansgrohe Focus Kitchen Faucet, including the pull-down spray and dual spray modes.

MAINTENANCE

To maintain the appearance and functionality of your Hansgrohe Focus faucet, follow these guidelines:

- **Regular Cleaning:** Clean the faucet regularly with a soft cloth and a mild, non-abrasive cleaner. Avoid using harsh chemicals, abrasive sponges, or cleaners containing alcohol, ammonia, or bleach, as these can damage the finish.
- **Spray Head Nozzles:** The spray head features QuickClean technology for easy limescale removal. Simply rub the silicone nozzles to dislodge mineral buildup.
- **Hose Maintenance:** Ensure the pull-down hose moves freely under the sink and is not obstructed by items in the cabinet.

TROUBLESHOOTING

If you encounter issues with your Hansgrohe Focus faucet, consider the following common solutions:

- **Low Water Flow:** Check if the aerator or spray head nozzles are clogged with mineral deposits. Clean them as described in the Maintenance section. Ensure the shut-off valves under the sink are fully open.
- **Leaking:** If water is leaking from the handle or base, the internal cartridge may need adjustment or replacement. Contact a licensed plumber or Hansgrohe customer support.
- **Spray Head Not Retracting:** Check if the counterweight on the pull-down hose under the sink is properly positioned and not obstructed. Ensure the hose is not kinked or tangled.
- **Temperature Issues:** If you are not getting the desired hot or cold water, verify that the hot and cold water supply lines are correctly connected and that the water heater is functioning properly.

For persistent problems, refer to the Warranty and Support section for assistance.

SPECIFICATIONS

Feature	Detail
Brand	hansgrohe
Model Name	Focus High Arc
Model Number	04505800
Color	Stainless Steel Optic
Finish Type	Steel Optik
Material	Brass
Mounting Type	Deck Mount
Number of Handles	1
Handle Type	Lever

Hole Count	1
Spout Design	High Arc, Pull Down
Spout Height	9 Inches
Spout Reach	8.63 Inches
Flow Rate	1.75 Gallons Per Minute
Item Weight	6.5 Pounds
Included Components	Connection Hoses, Kitchen Faucet

WARRANTY INFORMATION

Hansgrohe, Inc. warrants to the original consumer purchaser that Hansgrohe products will be free from defects in material and workmanship for as long as the original consumer purchaser owns both the product and the home in which the product was originally installed. This warranty is non-transferable.

For commercial purchasers, the warranty period is one (1) year from the date of purchase. The warranty period for products in Rubbed Bronze, Matte Black, and Matte White finishes is three (3) years from the date of purchase.

This warranty does not cover Hansgrohe products purchased from unauthorized sellers. Authorized sellers can be found on Hansgrohe branded websites. Additional warranty restrictions apply. Please refer to the manufacturer's website for full warranty details.

SUPPORT

For technical assistance, replacement parts, or warranty claims, please contact Hansgrohe customer support through their official website or the contact information provided with your product packaging. When contacting support, please have your model number (04505800) and proof of purchase readily available.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question