Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

SoBuy FKW11-N

SoBuy FKW11-N Bamboo Rolling Cart

Instruction Manual

Model: FKW11-N | Brand: SoBuy

1. Introduction

Thank you for choosing the SoBuy FKW11-N Bamboo Rolling Cart. This versatile cart is designed to provide convenient storage and serving solutions for various spaces in your home, such as the kitchen, bathroom, or utility room. Constructed from natural bamboo, it offers durability and a modern aesthetic.

This manual provides essential information for the safe assembly, operation, and maintenance of your new rolling cart. Please read it thoroughly before assembly and retain it for future reference.



Image 1.1: The SoBuy FKW11-N Bamboo Rolling Cart in a kitchen, showcasing its storage capabilities.

2. Safety Information

Please observe the following safety precautions to prevent injury or damage to the product:

- Always assemble the cart on a soft, clean surface to prevent scratches.
- Ensure all screws and fasteners are securely tightened before use. Do not overtighten screws, as this may cause cracking in the bamboo.
- Do not exceed the maximum weight capacity of 5 kg per shelf or 15 kg total for the entire cart.
- Keep small parts and packaging materials away from children to avoid choking hazards.
- Do not stand or climb on the cart.
- Use the cart on a level surface to prevent tipping.
- Regularly check for loose parts and tighten as necessary.

3. Package Contents

Before assembly, verify that all components are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Bamboo frame components (legs, crossbars)
- 3 x Bamboo shelves
- 6 x Metal stopper bars
- 4 x Casters (wheels)
- Assembly hardware (screws, Allen wrench)
- Instruction manual



Image 3.1: Detail of a caster wheel, essential for the cart's mobility.



Image 3.2: Detail of a metal stopper bar, designed to secure items on the shelf.

4. Setup (Assembly Instructions)

Assembly is quick and straightforward. An illustrated manual is included in the package for detailed steps. Follow these general guidelines:

1. **Prepare the Workspace:** Lay out all components on a clean, soft surface to prevent damage.
2. **Attach Casters:** Securely attach the four casters to the bottom of the cart's leg frames using the provided screws and Allen wrench. Ensure they are firmly attached but do not overtighten.
3. **Assemble Frame:** Connect the bamboo leg frames using the crossbars. Pay attention to the orientation of the parts as indicated in the illustrated manual.
4. **Install Shelves:** Slide each bamboo shelf into the designated slots on the frame. Ensure they are level and fully seated.
5. **Secure Stopper Bars:** Attach the metal stopper bars to the front and back of each shelf level. These bars prevent

items from sliding off.

6. **Final Check:** Once assembled, gently shake the cart to ensure stability. Tighten any loose screws if necessary, being careful not to overtighten.

5. Operating Instructions

The SoBuy FKW11-N Rolling Cart is designed for easy use and versatility.

- **Mobility:** Utilize the four robust casters to easily move the cart between rooms or to different areas within a space.
- **Storage:** Place items such as dishes, kitchen utensils, pantry staples, bathroom toiletries, or linens on the three sturdy shelves. The metal stopper bars help keep items secure.
- **Weight Distribution:** Distribute weight evenly across the shelves. Avoid placing heavy items solely on one side or corner.
- **Capacity:** Do not exceed the maximum weight capacity of 5 kg per shelf or 15 kg for the entire cart. Overloading can compromise stability and damage the cart.



Image 5.1: The rolling cart providing convenient storage for towels and toiletries in a bathroom.

6. Maintenance

To ensure the longevity and appearance of your bamboo rolling cart, follow these maintenance guidelines:

- **Cleaning:** Wipe the bamboo surfaces with a soft, damp cloth. For stubborn dirt, use a mild soap solution and then wipe dry immediately. Avoid abrasive cleaners or harsh chemicals.
- **Drying:** Bamboo is naturally resistant to humidity, but prolonged exposure to moisture should be avoided. Always dry the cart thoroughly after cleaning.
- **Inspection:** Periodically check all screws and connections for tightness. Retighten if necessary to maintain stability.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause the bamboo to fade or dry out.

7. Troubleshooting

If you encounter any issues with your SoBuy FKW11-N Rolling Cart, refer to the following common problems and solutions:

- **Cart is Wobbly:**
  - Ensure all assembly screws are securely tightened.
  - Verify that the cart is on a flat, level surface.
  - Check if any components are incorrectly assembled.
- **Wheels Not Rolling Smoothly:**
  - Check for any debris (hair, lint) caught in the caster wheels. Clean as necessary.
  - Ensure the caster attachment screws are not overtightened, which can restrict movement.
- **Bamboo Cracking During Assembly:**
  - This can occur if screws are overtightened. Always tighten screws until snug, but avoid excessive force.
  - If significant cracking occurs, contact customer support for replacement parts.

8. Specifications

Model Number:	FKW11-N (Manufacturer Reference: 32054)
Material:	100% Natural Varnished Bamboo
Color:	Natural Bamboo
Dimensions (L x W x H):	46 x 38 x 76 cm (18.1 x 15 x 29.9 inches)
Item Weight:	5.2 kg (11.46 lbs)
Maximum Load per Shelf:	5 kg (11 lbs)
Maximum Total Load:	15 kg (33 lbs)
Assembly Required:	Yes



Image 8.1: Detailed dimensions of the SoBuy FKW11-N Rolling Cart.

9. Warranty and Support

SoBuy products are manufactured with quality and customer satisfaction in mind. While specific warranty details may vary by region and retailer, we are committed to providing support for our products.

If you have any questions, require assistance with assembly, or need to report a missing or damaged part, please contact SoBuy customer service through your retailer or the official SoBuy website. Please have your model number (FKW11-N) and purchase information ready when contacting support.

© 2024 SoBuy. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00HWPXT5E

More documents and user manuals: **https://manuals.plus/**