

[Manuals.plus](#) /

> [Newco](#) /

> Newco GXF-P Automatic Airpot Coffee Brewer Instruction Manual

Newco GXF-P

Newco GXF-P Automatic Airpot Coffee Brewer Instruction Manual

Model: GXF-P

INTRODUCTION

This manual provides comprehensive instructions for the safe and efficient operation, installation, and maintenance of your Newco GXF-P Automatic Airpot Coffee Brewer. Please read this manual thoroughly before operating the appliance and retain it for future reference. The Newco GXF-P is designed to brew coffee directly into 1.9L or 2.2L airpots, featuring advanced functions like Visa-Brew and a Gravity Hot Water Faucet System.

IMPORTANT SAFETY INSTRUCTIONS

To reduce the risk of fire, electric shock, and injury, always observe basic safety precautions when using electrical appliances.

- Read all instructions before operating the brewer.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against fire, electric shock, and injury to persons, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner. Contact Newco for examination, repair, or adjustment.
- The use of accessory attachments not recommended by the appliance manufacturer may result in fire, electric shock, or injury to persons.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.

- Ensure the brewer is connected to a properly grounded electrical outlet.
- Exercise extreme caution when dispensing hot liquids.

PRODUCT OVERVIEW AND COMPONENTS

The Newco GXF-P Automatic Airpot Coffee Brewer is a robust machine designed for efficient coffee preparation. Below is an image illustrating the main components of the brewer.





Image Description: A front view of the Newco GXF-P Automatic Airpot Coffee Brewer. The brewer features a stainless steel exterior. At the top, the "NEWCO" logo is visible. Below the logo, there are control switches for "POWER" and "START/BREW", along with an indicator light. On the left side, a red lever for the hot water faucet is present. The brew basket is positioned above a stainless steel airpot, which sits on the drip tray. The overall design is functional and industrial.

Key Features:

- **Airpot Compatibility:** Brews directly into 1.9L or 2.2L airpots.
- **Visa-Brew Function:** An indicator lamp flashes during a brew cycle for an adjustable period, preventing premature removal of the brew basket or serving vessel.
- **PDS Valve:** Newco's exclusive porcelain flow control valve ensures accurate pot levels with each brew.
- **Patented Modular Design:** The GX brewer's cabinet design allows for easy modification to brew into various vessel types by simply changing the base.
- **Gravity Hot Water Faucet System:** Dispenses hot water without affecting the brew volume during a brewing cycle.

SETUP AND INSTALLATION

Proper installation is crucial for optimal performance and safety.

1. **Unpacking:** Carefully remove the brewer from its packaging. Inspect for any shipping damage.
2. **Placement:** Place the brewer on a stable, level surface. Ensure adequate clearance around the unit for ventilation and access.
3. **Water Connection:** Connect the brewer to a potable cold water supply using a dedicated water line and shut-off valve. Ensure all connections are secure and leak-free. It is recommended to use a water filter.
4. **Electrical Connection:** Plug the brewer into a grounded electrical outlet. Verify that the voltage matches the brewer's requirements (120 Volts or 240 Volts, as applicable).
5. **Initial Rinse:** Before first use, run several cycles of plain water through the brewer to flush out any manufacturing residues. Do not add coffee during this process.

OPERATING INSTRUCTIONS

Brewing Coffee

1. **Power On:** Ensure the brewer is plugged in and the power switch is in the "ON" position. Allow the water to heat to the optimal brewing temperature.
2. **Prepare Airpot:** Place an empty 1.9L or 2.2L airpot securely on the drip tray beneath the brew basket.
3. **Add Filter and Coffee:** Insert a paper filter into the brew basket. Add the desired amount of ground coffee into the

filter.

4. **Initiate Brew Cycle:** Press the "START" or "BREW" button. The Visa-Brew indicator lamp will flash, signaling that a brew cycle is in progress.
5. **Wait for Completion:** Allow the brewing cycle to complete. The Visa-Brew lamp will stop flashing after its adjustable period, indicating it is safer to remove the airpot.
6. **Serve:** Once brewing is complete, carefully remove the airpot and serve.

Using the Hot Water Faucet

The Newco GXF-P features a Gravity Hot Water Faucet System, allowing you to dispense hot water without interrupting the brewing process or altering the brew volume.

1. **Place Container:** Position a heat-safe cup or container under the hot water faucet.
2. **Dispense Water:** Pull the red lever on the hot water faucet to dispense hot water.
3. **Close Faucet:** Release the lever to stop the flow of hot water. Exercise caution as the water is hot.

MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your Newco GXF-P brewer. Always unplug the brewer and allow it to cool before cleaning.

Daily Cleaning

- **Brew Basket:** Remove and wash the brew basket with mild detergent and warm water. Rinse thoroughly.
- **Drip Tray:** Empty and clean the drip tray.
- **Exterior:** Wipe down the exterior surfaces of the brewer with a damp cloth. Do not use abrasive cleaners or immerse the unit in water.
- **Airpots:** Clean airpots according to their manufacturer's instructions.

Descaling

Mineral deposits (scale) can build up in the brewer over time, affecting performance. Descale your brewer regularly, depending on water hardness and usage.

- Use a commercial descaling solution designed for coffee brewers, following the product's instructions.
- Alternatively, a solution of white vinegar and water (e.g., 1 part vinegar to 2 parts water) can be used.
- Run the descaling solution through a brew cycle without coffee.
- After descaling, run several cycles of plain water to thoroughly rinse the system.

TROUBLESHOOTING

Refer to the table below for common issues and their potential solutions. If the problem persists, contact Newco customer support.

Problem	Possible Cause	Solution
Brewer does not turn on.	No power supply.	Check power cord connection and wall outlet. Ensure power switch is ON.

Problem	Possible Cause	Solution
Coffee is not brewing.	Water supply issue; brewer not heated; brew button not pressed.	Verify water connection. Allow time for water to heat. Press the "START/BREW" button.
Slow brewing or weak coffee.	Mineral buildup (scale); clogged spray head.	Perform descaling procedure. Clean the spray head.
Water leaks from brewer.	Loose water line connection; damaged component.	Check all water line connections. If leak persists, discontinue use and contact support.
Hot water faucet not dispensing.	No hot water in tank; faucet clogged.	Ensure brewer is powered on and water is heated. Check for blockages in the faucet.

SPECIFICATIONS

Feature	Detail
Brand	Newco
Model	GXF-P
Color	Silver
Product Dimensions	19"D x 9.5"W x 25.1"H
Special Feature	Thermal
Coffee Maker Type	Pour Over
Operation Mode	Fully Automatic
Voltage	120 Volts, 240 Volts
ASIN	B00HXI41LG
First Available Date	December 30, 2013

WARRANTY AND SUPPORT

For information regarding the warranty coverage for your Newco GXF-P Automatic Airpot Coffee Brewer, please refer to the warranty card included with your purchase or visit the official Newco website.

If you require technical assistance, have questions about operation, or need to order replacement parts, please contact Newco customer support. Contact details can typically be found on the manufacturer's website or on the product packaging.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B00HXI41LG>

More documents and user manuals: **<https://manuals.plus/>**