

[Manuals.plus](#) /

› [Fujifilm](#) /

› Fujifilm X-T1 16 MP Mirrorless Digital Camera Instruction Manual

Fujifilm 16421452

Fujifilm X-T1 Mirrorless Digital Camera Instruction Manual

Brand: Fujifilm

INTRODUCTION

The Fujifilm X-T1 is a professional-quality mirrorless digital camera designed for serious enthusiasts and semi-professional photographers. It features an APS-C 16.3MP X-Trans CMOS II Sensor and EXR Processor II, offering exceptional image quality. The camera body is weather-resistant when used with compatible lenses, providing water, dust, and freeze resistance down to -10°C / 14°F.

WHAT'S IN THE BOX

- Fujifilm X-T1 Mirrorless Digital Camera (Body Only)
- Np-W126 Li-Ion Battery Pack
- Bc-W126 Battery Charger
- Ef-X8 Shoe-Mount Flash Unit
- Shoulder Strap
- Body Cap
- Metal Strap Clip
- Protective Cover
- Clip Attaching Tool
- Hot Shoe Cover

KEY FEATURES

- 16.3 MP APS-C X-Trans II CMOS sensor
- ISO 200-6400 (expandable to 51200)
- 1080/30fps HD video (.MOV/H.264)
- Water and dust resistant and freezeproof to -14C/+14F with weather resistant lenses
- Up to 8 FPS continuous shooting
- 3 inch tiltable LCD with 1,040,000 dots
- OLED viewfinder with 100% coverage and 2,360,000 dots
- Included hot shoe flash
- Built-in Wi-Fi connectivity and remote camera control via smartphone
- Fujifilm X-Mount compatible
- Raw, JPEG, and Raw+JPEG

- SD, SDHC, and SDXC memory

SETUP

Battery and Memory Card Installation

Insert the provided Np-W126 Li-Ion Battery Pack into the battery compartment located at the bottom of the camera. Ensure it clicks into place. Insert a compatible SD, SDHC, or SDXC memory card into the card slot. The camera supports UHS-II for faster performance.



Back view of the Fujifilm X-T1 camera, highlighting the tiltable LCD screen and the location of the battery and memory card compartment.

Attaching a Lens

Align the white dot on the lens with the white dot on the camera's lens mount. Rotate the lens clockwise until it clicks into place. To remove, press the lens release button on the camera body and rotate the lens counter-clockwise.



Front view of the Fujifilm X-T1 camera body, ready for lens attachment.

OPERATING THE CAMERA

Controls and Dials

The Fujifilm X-T1 features a classic design with dedicated analog dials for key settings. Adjust shutter speed, EV compensation, ISO, drive mode, and metering mode directly using the dials on the top plate. The 3-inch tiltable LCD screen and the high-magnification 0.77x OLED electronic viewfinder provide clear views for composing and reviewing shots.



Top view of the Fujifilm X-T1, showcasing the dedicated dials for shutter speed, ISO, and exposure compensation.

Autofocus System

The camera is equipped with a high-performance hybrid AF system, combining phase detection and contrast detection for fast and accurate focusing. It features 49 autofocus points, allowing for precise focus selection. Manual focus is also encouraged with large, well-damped focus rings on XF lenses, complemented by focus peaking and digital split image manual focus aids in the viewfinder.

Shooting Modes

The X-T1 supports various shooting modes including Program AE, Shutter Speed Priority AE, Aperture Priority AE, and Manual. It offers continuous shooting at up to 8 frames per second (FPS), ideal for capturing fast-moving subjects. Images can be saved in JPEG, Raw, or Raw+JPEG formats.

Wi-Fi Connectivity

The Fujifilm X-T1 features built-in Wi-Fi connectivity, allowing users to transfer images wirelessly to a smartphone or tablet. The dedicated Fujifilm Camera Remote app enables remote control of the camera, including live view, focus point selection, and shutter release, directly from a mobile device.

In-Camera RAW Conversion

The camera offers a versatile in-camera RAW conversion feature. This allows users to apply various film simulation effects, adjust dynamic range, white balance, highlight/shadow brightness, and overall exposure directly on the camera, without the need for a computer. The converted JPEG is saved directly to the memory card.

SPECIFICATIONS

Specification	Detail
Brand	Fujifilm
Model Name	Fujifilm X-T1
Photo Sensor Resolution	16 MP
Photo Sensor Size	APS-C
ISO Sensitivity	200-6400 (expandable to 51200)
Video Resolution	FHD 1080p
Continuous Shooting	8 fps
Screen Size	3 Inches
Display Type	LCD (Tiltable)
Viewfinder	Electronic (OLED)
Compatible Mountings	Fujifilm X
Supported File Format	JPEG, Raw
Item Weight	0.97 Pounds
Connectivity Technology	HDMI, Wi-Fi

MAINTENANCE

Cleaning the Camera

Regularly clean the camera body with a soft, dry cloth. For the lens, use a lens brush or air blower to remove dust, followed by a micro-fiber cloth and lens cleaning solution if necessary. Avoid touching the sensor directly; use a professional sensor cleaning kit or have it cleaned by a service center if dust is visible on images.

Battery Care

Always use the provided Bc-W126 Battery Charger to charge the Np-W126 Li-Ion Battery Pack. Store batteries in a cool, dry place when not

in use. Avoid exposing batteries to extreme temperatures.

TROUBLESHOOTING

Common Issues

- **Camera not powering on:** Ensure the battery is fully charged and correctly inserted.
- **Images not saving:** Check if the memory card has sufficient space or if it's locked. Reformat the card if issues persist (this will erase all data).
- **Autofocus issues:** Ensure sufficient light and contrast in the scene. Clean the lens and camera contacts.
- **Wi-Fi connection problems:** Restart both the camera and the smart device. Ensure the Fujifilm Camera Remote app is updated.

WARRANTY AND SUPPORT

Warranty Information

The Fujifilm X-T1 comes with a 1-year coverage for labor and 1-year coverage for parts. This warranty does not cover accessories not made by the manufacturer, batteries, or flash equipment. Please refer to the full warranty documentation included with your product for complete details.

Product Support

For further assistance, troubleshooting, or service inquiries, please visit the official Fujifilm support website or contact their customer service hotline. Keep your purchase receipt and product serial number handy for faster service.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

