

[Manuals.plus](#) /

› [Bestway](#) /

› Bestway Steel Pro MAX 10ft x 30in Round Above Ground Swimming Pool User Manual

Bestway 56407

Bestway Steel Pro MAX 10ft x 30in Round Above Ground Swimming Pool User Manual

Model: 56407

IMPORTANT SAFETY INFORMATION

WARNING: Drowning Hazard

- Children under 5 are at highest risk for drowning. Closely watch children who are in or near this pool.
- No diving.
- Keep all electrical lines, radios, speakers, and other electrical devices away from the pool.
- Do not place pool near or under overhead electrical lines.
- If drain or suction outlet cover is missing or broken, your hair, body, and jewelry can get sucked into the drain. You could be held under water & drown! Do not use pool if drain or suction outlet cover is missing or broken.

Disclaimer:

Please review your HOA rules and restrictions before purchasing and installing the product. Not all housing agencies permit private above-ground pools.

PRODUCT OVERVIEW

The Bestway Steel Pro MAX 10ft x 30in Round Above Ground Swimming Pool is designed for easy setup and durable use, providing a refreshing swimming experience for the whole family. It features a robust steel frame and a durable DuraPlus™ liner.



Image: Bestway Steel Pro MAX 10ft x 30in Round Above Ground Swimming Pool, showing the pool, filter pump, and filter cartridge.

Key Features:

- **Durable Steel Frame:** Constructed with a corrosion-resistant steel frame and the FrameLink System™ for strength and secure connections.
- **Supportive DuraPlus™ Liner:** Enhanced 3-ply PVC liner with an elegant design, providing a support band for additional stability and puncture resistance.
- **Integrated Filter Pump:** Includes a Bestway 58511E 330 GPH filter pump to maintain clean water.
- **Easy Setup:** Designed for simple assembly and disassembly for off-season storage, requiring no tools for hose connections.
- **Water Capacity:** 1,236 gallons (4,678 liters) at 90% fill.

SETUP INSTRUCTIONS

Follow these steps for proper assembly of your Bestway Steel Pro MAX pool. Ensure the chosen location is level and clear of debris.

1. **Prepare the Site:** Select a flat, level surface free of sharp objects, rocks, or roots. The ground should be firm enough to support the weight of the filled pool.
2. **Lay Liner Flat:** Unfold the pool liner and lay it flat in the chosen area. Ensure the drain valve is positioned correctly for future draining.

10 FT.
x 30 IN.

30 IN.
DEEP

STEEL PRO MAX®

ABOVE GROUND POOL SET





TRITECH MATERIAL™

Ultra-durable, 3-layer material reinforced for strength



STEEL FRAME CONSTRUCTION

Constructed with superior corrosion resistant steel




FRAMELINK SYSTEM™

Offers sturdy and secure pipe connection

Image: Step 1 of pool setup, showing two people laying the pool liner flat on a grassy area.

3. **Assemble the Frame:** Connect the steel frame components according to the included diagram. The FrameLink System™ ensures secure pipe connections. Insert the horizontal beams into the liner sleeves and connect them with the vertical legs.

Bestway



PRISMATIC STONE™
Realistic inner liner print

WATER CAPACITY (90%)
1,236 GAL. (4,678 L)



WHAT'S INCLUDED



FILTER PUMP



FILTER CARTRIDGE

Image: Step 2 of pool setup, showing two people assembling the steel frame of the pool.

4. **Connect Filter Pump:** Attach the 330 GPH filter pump to the designated inlet and outlet connections on the pool liner. Ensure all connections are tight to prevent leaks. The pump uses Type I filter cartridges.

EASY SETUP

NO TOOLS NEEDED



1

LAY
LINER
FLAT



2

ASSEMBLE
FRAME



3

FILL
WITH
WATER

Bestway



FLOWCLEAR™

The pump features an energy-saving plug, which allows you to set a timer for your pump to automatically shut off.

Image: Step 3 of pool setup, showing a person filling the pool with water from a garden hose.

5. **Fill with Water:** Begin filling the pool with water. As the water level rises, gently smooth out any wrinkles in the bottom of the liner. Stop filling when the water reaches approximately 90% capacity, indicated by the fill line on the liner.

Setup Video:

Your browser does not support the video tag.

Video: Official Bestway setup guide for the Steel Pro MAX pool. This video demonstrates the process of laying out the liner, assembling the frame, and filling the pool with water. (Source: Spreetail, a Seller)

OPERATING INSTRUCTIONS

Filter Pump Operation:

The included 330 GPH filter pump is essential for maintaining water clarity and hygiene. It features an energy-saving plug that allows you to set a timer for automatic shut-off.

Bestway

330 GAL. FILTER PUMP Type I



**2 Hoses
Included**



**Uses Type I
Filter Cartridges**



**Energy-Saving
On/Off Timer**

Image: Detailed view of the Bestway 330 GPH Filter Pump (Type I), showing its dimensions (8.3 in. height, 5.8 in. width), and indicating it includes 2 hoses, uses Type I filter cartridges, and has an energy-saving on/off timer.

- Ensure the pump is connected to a grounded electrical outlet.
- Run the filter pump daily for several hours to ensure proper water circulation and filtration. The exact duration depends on usage and water conditions.
- Refer to the pump's specific manual for detailed instructions on setting the timer and operation.

Water Chemistry:

Regularly test and balance your pool water chemistry to prevent algae growth and ensure a safe swimming environment. Key parameters include pH, chlorine, and alkalinity.

- Use a pool test kit to check water parameters at least twice a week.
- Adjust chemicals as needed to maintain recommended levels.

MAINTENANCE

Filter Cartridge Cleaning and Replacement:

The filter cartridge should be cleaned regularly and replaced every two weeks or sooner depending on usage.



Image: A Bestway Type I Filter Cartridge, which is used in the included filter pump.

1. Turn off and unplug the filter pump.
2. Open the filter housing and remove the cartridge.
3. Rinse the cartridge thoroughly with a garden hose to remove debris.
4. If the cartridge remains dirty or discolored after rinsing, replace it with a new Type I filter cartridge.
5. Reassemble the filter pump and restart.

Pool Cleaning:

- Skim debris from the water surface daily using a pool skimmer.
- Brush the pool walls and floor weekly to prevent algae buildup.
- Vacuum the pool floor as needed to remove settled debris.

Winterization and Storage:

Proper winterization is crucial for extending the life of your pool.

1. Completely drain the pool water using the flow control drain valve. No tools are required to connect a hose to the valve for efficient draining.
2. Clean and dry all pool components thoroughly.
3. Disassemble the frame and liner.
4. Store all parts in a dry, protected area, away from extreme temperatures.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Water is cloudy or green	Insufficient filtration; Imbalanced water chemistry; Algae growth	Run filter pump longer; Clean/replace filter cartridge; Test and adjust water chemicals (chlorine, pH); Shock treat the pool.
Filter pump not working	Power supply issue; Clogged filter; Motor malfunction	Check power connection and circuit breaker; Clean/replace filter cartridge; Contact Bestway support if motor issue persists.
Water leaking from connections	Loose connections; Damaged O-rings/gaskets	Tighten all hose clamps and connections; Inspect and replace any damaged O-rings or gaskets.
Pool liner puncture	Sharp object; Wear and tear	Locate the puncture and use the included repair patch to seal it. Ensure the area is clean and dry before applying the patch.

SPECIFICATIONS

- **Model:** 56407
- **Dimensions:** 10 ft (3.05 m) diameter x 30 in (76 cm) height
- **Water Capacity (90%):** 1,236 gallons (4,678 liters)
- **Material:** DuraPlus™ (3-ply PVC), Alloy Steel frame
- **Color:** Gray
- **Filter Pump:** Bestway 58511E, 330 GPH (1,249 L/h)
- **Filter Cartridge Type:** Type I
- **Item Weight:** 42.4 pounds (19.23 kg)
- **Assembly Required:** Yes
- **Indoor/Outdoor Usage:** Outdoor
- **UPC:** 821808564071

WARRANTY AND SUPPORT

For warranty information, product registration, or technical support, please visit the official Bestway website or contact their customer service directly. Keep your proof of purchase for any warranty claims.
You can also refer to the official user manuals provided by Bestway:

- [Installation Manual \(PDF\)](#)
- [User Manual \(PDF\)](#)
- [User Guide \(PDF\)](#)

For additional resources and product information, visit the[Bestway Store on Amazon](#).

© 2025 Bestway. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B00HZAM07U>

More documents and user manuals: <https://manuals.plus/>