

[Manuals.plus](#) /

> [T-Fal](#) /

> Tefal Ingenio Non-stick Elegance Cookware Set, 13 Pieces - Instruction Manual

T-Fal L23190AZ

Tefal Ingenio Non-stick Elegance Cookware Set (13 Pieces) - Instruction Manual

Model: L23190AZ

INTRODUCTION

Thank you for choosing the Tefal Ingenio Non-stick Elegance Cookware Set. This 13-piece set is designed for versatility and space-saving, featuring detachable handles that allow seamless transitions from hob to oven, table, and fridge. The non-stick coating ensures easy cooking and cleaning. Please read this manual carefully before first use to ensure proper operation and maintenance of your cookware.



Image: The complete 13-piece Tefal Ingenio Non-stick Elegance cookware set, showcasing its stackable design and detachable handles.

SET COMPONENTS

Your Tefal Ingenio Non-stick Elegance 13-piece set includes the following items:

- 16 cm Saucepan

- 20 cm Saucepan
- 22 cm Frying Pan
- 28 cm Frying Pan
- 24 cm Saute Pan
- 26 cm Wok
- 16 cm Glass Lid
- 20 cm Glass Lid
- 26 cm Glass Lid
- 16 cm Plastic Lid
- 20 cm Plastic Lid
- Two (2) Detachable Bakelite Handles

INGENIO ELEGANCE 13PC SET

CONTENTS



*COMPARED TO TEFAL FIXED HANDLE RANGES

Image: A visual breakdown of the 13-piece set, illustrating each component and its size for easy identification.

SETUP

Unpacking and Initial Cleaning

1. Carefully remove all cookware pieces and accessories from the packaging.
2. Remove any labels or protective films.
3. Wash all items with warm, soapy water using a soft sponge.
4. Rinse thoroughly and dry completely before first use.

Attaching and Detaching Handles

The Ingenio system features patented detachable handles for maximum versatility and space-saving. The handles are designed

to attach and detach with a single click.

- **To Attach:** Align the handle with the designated attachment point on the rim of the pan. Press the handle firmly until you hear a click, indicating it is securely locked.
- **To Detach:** Press the release button on the handle and pull it away from the pan.

Ensure the handle is securely attached before lifting or moving a pan, especially when it contains hot food. The handle is proven to hold a weight of up to 10kg.

OPERATING INSTRUCTIONS

Cooking on the Hob

- This cookware set is compatible with all hobs **excluding induction**.
- Always use a hob burner size that matches the base of the pan to ensure even heating and energy efficiency.
- Do not overheat empty pans.
- The frying pans, wok, and saute pan feature Tefal's Thermo-Spot technology. The Thermo-Spot indicator turns solid red when the pan has reached the optimum cooking temperature (approximately 180°C/350°F), signaling it is ready for food.



Image: A close-up view of the pan's interior, highlighting the Thermo-Spot indicator which signals optimal cooking temperature.



Image: Demonstrates cooking with the detachable handle securely attached to a frying pan on a stovetop.

Oven Use


- All Ingenio cookware pieces (pots and pans) are oven safe up to 260°C (500°F).
- **Always remove the detachable handle before placing cookware in the oven.**
- Glass lids are also oven safe, but plastic lids are not.

Serving and Storage

- After cooking, detach the handle to use the pan directly as a serving dish.
- For storing leftovers, allow the food to cool, then attach the appropriate plastic lid (16 cm or 20 cm) to the saucepan.
- The plastic lids are designed for refrigerator storage only and are not suitable for oven or hob use.



COOK IT



BAKE IT



SERVE IT



STORE IT

Image: A collage illustrating the multi-functional use of the cookware: cooking, baking, serving, and storing.

Utensil Compatibility

The Ingenio Elegance non-stick coating is durable and resistant. Metal utensils can be used, with the exception of whisks and knives, which may damage the non-stick surface. For best results and to prolong the life of your cookware, silicone or wooden utensils are recommended.

MAINTENANCE AND CARE

Cleaning

- All cookware pieces (pots and pans) are dishwasher safe.

- For hand washing, use warm, soapy water and a non-abrasive sponge. Avoid harsh scourers or abrasive cleaners, as these can damage the non-stick coating.
- The detachable handles should be hand washed and dried thoroughly. Do not immerse handles in water for extended periods or place them in the dishwasher, as this may affect their mechanism.
- Glass lids are dishwasher safe. Plastic lids should be hand washed.
- For stubborn food residues, soak the pan in warm, soapy water before cleaning.



Image: Ingenio pans positioned in a dishwasher, illustrating their compatibility with machine washing.

Storage

The Ingenio design allows for optimal space-saving storage. The pots and pans stack easily into one another when the handles are detached.

- Ensure all pieces are clean and dry before stacking.
- To protect the non-stick coating, you may place a soft cloth or paper towel between stacked pans.
- Store handles separately in a drawer or cabinet.



Image: The Ingenio cookware set, including lids and handles, compactly stored in a kitchen drawer.



TROUBLESHOOTING

- **Food Sticking:** Ensure you are using a small amount of cooking fat or oil. Overheating an empty pan can also damage the non-stick coating over time. Always allow the pan to cool before cleaning.
- **Handle Not Attaching Securely:** Check for any food debris or obstructions in the attachment mechanism on both the handle and the pan. Ensure the handle is correctly aligned before pressing to lock.
- **Discoloration:** Minor discoloration can occur over time due to high heat or certain foods. This typically does not affect the performance of the non-stick coating.
- **Scratches on Non-stick Coating:** While the coating is resistant, using sharp metal utensils (like knives or whisks) can cause scratches. These minor scratches usually do not affect the pan's non-stick properties or safety.

If you encounter issues not covered here, please refer to the Customer Support section.

SPECIFICATIONS

Brand	T-Fal
Model Number	L23190AZ
Number of Pieces	13
Material	Enamel (cookware body), Glass (lids), Bakelite (handles)
Color	Black
Non-stick Coating	Intensium (PFAS Free)
Hob Compatibility	All hobs excluding Induction
Oven Safe Temperature	Up to 260°C (500°F) (cookware and glass lids, without handles)
Dishwasher Safe	Yes (cookware and glass lids)
Utensil Compatibility	Metal (except whisks and knives)
Item Weight	6 Kilograms

WARRANTY INFORMATION

Tefal products are manufactured to high-quality standards. This product is covered by the manufacturer's warranty against defects in materials and workmanship. The specific terms and duration of the warranty may vary by region. Please refer to the warranty card included with your product packaging or visit the official T-Fal website for detailed information.

CUSTOMER SUPPORT

For further assistance, product inquiries, or warranty claims, please contact T-Fal customer service. You can find contact information on the official T-Fal website or through the retailer where you purchased the product. You may also visit the official T-Fal store on Amazon for more product information and support:[T-Fal Amazon Store](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B00HZVOBZM>

More documents and user manuals: <https://manuals.plus/>