Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Tesoro TS-G5NFL

Tesoro Lobera Supreme G5NFL Mechanical Gaming Keyboard User Manual

Introduction

This manual provides comprehensive instructions for the Tesoro Lobera Supreme G5NFL mechanical gaming keyboard. It covers setup, operation, maintenance, and troubleshooting to ensure optimal performance and longevity of your device. The Lobera Supreme G5NFL features full-color RGB illumination, N-Key rollover for precise input, a high-speed USB 2.0 hub, and programmable macro keys.

1. Setup

1.1 Package Contents

- Tesoro Lobera Supreme G5NFL Mechanical Gaming Keyboard
- Integrated USB Cable
- User Manual (this document)

1.2 Connecting the Keyboard

1. Locate an available USB port on your computer.
2. Connect the integrated USB cable from the Tesoro Lobera Supreme G5NFL keyboard to the USB port on your computer.
3. The operating system will automatically detect and install the necessary drivers.
4. For full functionality, including the USB hub and audio ports, ensure all connectors are securely plugged into the corresponding ports on your computer.



Figure 1: The Tesoro Lobera Supreme G5NFL keyboard connected via its integrated USB and audio cables.

The keyboard features a braided cable for enhanced durability. The USB connection provides both power and data transfer for the keyboard and its integrated USB hub.

2. Operating Instructions

2.1 Full-Color Illumination

The Tesoro Lobera Supreme G5NFL features full-color RGB illumination with 16.8 million color options and various lighting modes. The side panels of the keyboard are also illuminated.

- **Adjusting Illumination:** Specific key combinations (often involving the 'Fn' key or dedicated lighting keys) are used to cycle through colors, adjust brightness, and change lighting effects. Refer to the software utility for advanced customization.
- **Side Illumination:** The keyboard's side panels also feature customizable lighting, enhancing the overall aesthetic.



Figure 2: The Tesoro Lobera Supreme G5NFL keyboard displaying blue illumination along its side edge.



Figure 3: The Tesoro Lobera Supreme G5NFL keyboard displaying purple illumination along its side edge.

2.2 All Key Rollover (N-Key Rollover)

The keyboard supports Full N-Key Rollover (NKRO), an advanced anti-ghosting technology. This feature ensures that every key press is registered accurately, even when multiple keys are pressed simultaneously. This is particularly

beneficial for fast-paced gaming and typing, preventing missed inputs.

2.3 USB Hub & Audio Ports

The Tesoro Lobera Supreme G5NFL includes a 2-port USB 2.0 hub and dedicated audio jacks for a headset and microphone. These ports are located on the keyboard for convenient access.

- **USB Hub:** Connect USB peripherals such as mice, flash drives, or other accessories directly to the keyboard's USB ports.
- **Audio Ports:** Plug in your headset's 3.5mm audio and microphone jacks into the corresponding ports on the keyboard for direct audio passthrough.



Figure 4: A close-up view of the integrated USB hub and audio ports on the Tesoro Lobera Supreme G5NFL keyboard.

2.4 Memory & Macros

Every key on the Tesoro Lobera Supreme G5NFL keyboard is programmable. The keyboard features 512 KB of onboard memory, allowing for the storage of up to 300 macros and 5 game profiles. This ensures your personalized settings are available regardless of the computer you use.

- **Macro Programming:** Use the Tesoro software utility to record and assign macros to any key.
- **Profile Management:** Create and switch between up to 5 distinct game profiles, each with its own key assignments and lighting configurations.
- **Onboard Memory:** All settings are stored directly on the keyboard, eliminating the need for software installation on every computer.

3. Maintenance

Regular maintenance helps preserve the performance and appearance of your keyboard.

- **Cleaning the Keyboard:**
  - Disconnect the keyboard from your computer before cleaning.
  - Use a soft, lint-free cloth slightly dampened with water or a mild cleaning solution to wipe the keycaps and chassis.
  - For dust and debris between keys, use compressed air.
  - Avoid harsh chemicals, abrasive cleaners, or excessive moisture.
- **Cable Care:** The braided cable is designed for durability. Avoid sharp bends or excessive pulling to prevent internal damage.

4. Troubleshooting

If you encounter issues with your Tesoro Lobera Supreme G5NFL keyboard, refer to the following common solutions:

Problem	Possible Solution
Keyboard is not responding.	Ensure the USB cable is securely connected to both the keyboard and the computer. Try connecting the keyboard to a different USB port on your computer. Restart your computer. Test the keyboard on another computer to rule out system-specific issues.
Illumination is not working or incorrect.	Check the keyboard's brightness settings using the dedicated function keys. Ensure the Tesoro software utility is installed and updated, and check lighting profiles. A specific key's LED may malfunction over time. If a single LED is stuck or off, contact support.
Keys are sticking or not registering.	Clean the keyboard thoroughly, especially around the affected keys, using compressed air to remove debris. If a mechanical switch is faulty, it may require professional repair or replacement.
USB hub or audio ports are not functioning.	Ensure all USB and audio cables from the keyboard are fully plugged into the computer. Test with different devices in the USB hub ports. Check your computer's audio settings to ensure the correct output/input device is selected.

5. Specifications

Feature	Detail
Brand	Tesoro
Model Number	TS-G5NFL (B) BL
Keyboard Description	Mechanical
Connectivity Technology	USB

Feature	Detail
Number of Keys	104
Special Feature	Braided Cable, Full-Color RGB Illumination, N-Key Rollover, USB Hub, Audio Ports, Programmable Macros
Onboard Memory	512 KB (for 300 macros, 5 profiles)
Compatible Operating System	Windows
Item Weight	2.8 pounds
Included Components	USB Cable

6. Warranty and Support

For detailed warranty information, please refer to the warranty card included with your product packaging or visit the official Tesoro website. The warranty period and terms may vary by region.
If you require technical assistance or have questions not covered in this manual, please contact Tesoro customer support through their official website. Be prepared to provide your product model number (TS-G5NFL) and proof of purchase.
Online Resources:

- Official Tesoro Website: www.tesorotec.com (*Note: This is a placeholder URL as no specific support link was provided. Users should verify the current official website.*)
- Driver Downloads: Check the support section of the official website for the latest drivers and software utilities for your keyboard.

© 2023 Tesoro. All rights reserved. Tesoro Lobera Supreme G5NFL User Manual.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00I3W7ROY

More documents and user manuals: **https://manuals.plus/**