Rii X1

Rii 2.4G Mini Wireless Keyboard with Touchpad Mouse X1 User Manual

Model: X1 | Brand: Rii

Introduction

This user manual provides comprehensive instructions for the Rii 2.4G Mini Wireless Keyboard with Touchpad Mouse, Model X1. This compact and versatile device combines a full QWERTY keyboard, a multi-touch touchpad, and mouse functions, designed for seamless control across various platforms.
The Rii X1 is ideal for use with PCs, notebooks, smart TVs, HTPCs, Android TV boxes, PS3, and Xbox consoles, offering a convenient and portable input solution.



Image: The Rii X1 Mini Wireless Keyboard, showcasing its compact design with a QWERTY layout and integrated touchpad.

Package Contents

Before you begin, please ensure all items are present in your package:

- 1 x Rii X1 Wireless Keyboard
- 1 x Wireless USB Dongle/Receiver (located inside the keyboard's battery compartment)
- 1 x Charging Data Cable

- 1 x User Manual (this document)



Image: Contents of the Rii X1 package, including the keyboard, USB receiver, charging cable, and user manual.

Setup Guide

1. Charging the Keyboard

The Rii X1 keyboard comes with a built-in rechargeable Lithium-ion battery. For optimal performance, fully charge the keyboard before first use.

1. Locate the charging port on the side of the keyboard.
2. Connect the provided charging data cable to the keyboard's charging port.
3. Connect the other end of the USB charging cable to a standard USB power source (e.g., computer USB port, USB wall adapter).
4. The charging indicator light on the keyboard will illuminate during charging and turn off when fully charged.



Image: Diagram showing the rechargeable port and the USB charging cable. Also displays the keyboard's dimensions.

2. Connecting the USB Receiver

The Rii X1 uses a 2.4G wireless connection via a USB receiver. No drivers are required for installation.

1. Open the battery compartment cover on the back of the keyboard.
2. Carefully remove the mini USB receiver stored inside.
3. Insert the USB receiver into an available USB port on your device (PC, Smart TV, Android TV BOX, PS3, Xbox, etc.).
4. Turn on the keyboard using the power switch located on the side.
5. The device should automatically recognize the keyboard.




Image: Detailed diagram of the Rii X1 keyboard, highlighting the location of the USB Mini Receiver and various indicators.



Image: Visual representation of the Rii X1's wireless connection and its compatibility with various devices like Smart TVs, Android TV Boxes, PCs, PS3/Xbox, and HTPCs.

Operating Instructions

Keyboard Functions

The Rii X1 features a full QWERTY keyboard layout. All standard keys function as expected. Special function keys (F1-F8) may require the 'Fn' key to be pressed simultaneously, depending on the specific function and operating system.




Image: A user holding the Rii X1 keyboard, demonstrating its use with a desktop monitor, highlighting its QWERTY layout.

Touchpad Functions

The integrated touchpad supports multi-touch gestures for intuitive navigation.

- **Single Click:** Use one finger to tap the touchpad for a left mouse click.
- **Double Click:** Use one finger to quickly tap the touchpad twice for a double left mouse click.
- **Right Click:** Use two fingers to tap the touchpad for a right mouse click.
- **Scrolling:** Use two fingers and drag them up or down on the touchpad to scroll vertically.
- **Zoom In/Out:** Use two fingers and pinch or spread them on the touchpad to zoom in or out.
- **Mouse Movement:** Drag one finger across the touchpad to move the mouse cursor.




Image: Diagram illustrating various touchpad gestures, including single click, double click, right click, and two-finger drag for scrolling/zooming.

Power Management

The Rii X1 features an auto sleep and wake-up function to conserve battery life. If the keyboard is inactive for a period, it will enter sleep mode. Press any key to wake it up.



Image: A person using the Rii X1 keyboard as a remote control while relaxing on a couch, demonstrating its convenience for media consumption.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the keyboard surface. Avoid using liquid cleaners or abrasive materials.
- **Storage:** When not in use for extended periods, turn off the keyboard and store it in a cool, dry place.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge it when the low battery indicator appears.
- **USB Receiver:** Always store the USB receiver inside the keyboard's compartment when transporting to prevent loss.

Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Keyboard not responding	Low battery Keyboard is off USB receiver not connected or faulty Out of range	Charge the keyboard. Turn on the keyboard using the power switch. Ensure the USB receiver is securely plugged into a working USB port. Try a different USB port. Move the keyboard closer to the USB receiver (within 30 meters).
Touchpad not working correctly	Dirty touchpad surface Incorrect gesture	Clean the touchpad with a soft, dry cloth. Refer to the "Touchpad Functions" section for correct gestures.
Lag or delayed response	Interference from other wireless devices Distance from receiver	Move the keyboard and receiver away from other 2.4GHz wireless devices. Ensure there are no large metal objects between the keyboard and receiver. Reduce the distance between the keyboard and receiver.

Specifications

- **Model:** Rii X1
- **Wireless Technology:** 2.4 GHz RF
- **Operating Range:** Up to 30 meters (approx. 98 feet)
- **Keyboard Layout:** QWERTY
- **Number of Keys:** 87
- **Touchpad:** Ultra-sensitive multi-touch touchpad with 90-degree flip design
- **Battery Type:** Built-in Rechargeable Polymer Lithium-ion Battery
- **Power Source:** Battery Powered
- **Supported Operating Systems:** Windows 2000/XP/Vista/CE/7/8, Linux (Debian-3.1, Redhat-9.0 Ubuntu-8.10, Fedora-7.0 tested), Android OS (with standard USB interface), Mac OS
- **Hardware Platform Compatibility:** PC, Notebook, Smart TV, HTPC, Android TV BOX, PS3, XBOX
- **Dimensions:** 5.91" L x 2.28" W x 0.43" H (150mm x 58mm x 11mm)
- **Weight:** 1.9 ounces (approx. 54 grams)
- **Color:** Black
- **Special Feature:** Backlit

Warranty and Support

For warranty information and technical support, please refer to the official Rii website or contact your retailer. Keep your purchase receipt as proof of purchase for warranty claims.
For further assistance, you may visit the Rii Store on Amazon:Rii Official Store

© 2024 Rii. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question