

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› [JACQUES LEMANS](#) /

› JACQUES LEMANS 1-1820C Miami Men's Watch Instruction Manual

JACQUES LEMANS 1-1820C

JACQUES LEMANS 1-1820C Miami Men's Watch Instruction Manual

Model: 1-1820C Miami Series

INTRODUCTION

This manual provides essential information for the proper use and care of your JACQUES LEMANS 1-1820C Miami men's watch. This sporty and elegant timepiece features an oversized stainless steel case, a precise quartz movement, a date display, and a durable silicone strap. It is equipped with hardened Crystex glass for protection and includes a chronograph function.

SETUP

1. Setting the Time

1. Pull the crown (central knob) out to the second click position.
2. Turn the crown to set the hour and minute hands to the desired time.
3. Push the crown back into the normal position.

2. Setting the Date

1. Pull the crown out to the first click position.
2. Turn the crown clockwise or counter-clockwise (depending on the model) to set the date. Avoid setting the date between 9 PM and 3 AM, as this may interfere with the automatic date change mechanism.
3. Push the crown back into the normal position.

3. Strap Adjustment

The silicone strap is designed for comfort and durability. Adjust the buckle to ensure a snug yet comfortable fit on your wrist. Avoid overtightening, which can restrict circulation.



Front view of the JACQUES LEMANS 1-1820C Miami watch, showing the dial, hands, and chronograph sub-dials.

OPERATING INSTRUCTIONS

1. Using the Chronograph Function

Your watch is equipped with a chronograph (stopwatch) function.

1. **Start/Stop:** Press the upper pusher (button) to start and stop the chronograph.
2. **Reset:** With the chronograph stopped, press the lower pusher to reset all chronograph hands to their zero positions.

2. Water Resistance

This watch has a water resistance rating of 50 meters (5 ATM). This means it is suitable for short periods of recreational swimming, showering, and general daily use involving water splashes. It is **not** suitable for diving, snorkeling, or high-impact water sports. Do not operate the crown or pushers when the watch is wet or submerged.



Side view of the watch, highlighting the crown and chronograph pushers used for setting and operating functions.

1. Cleaning

Regularly wipe your watch with a soft, dry cloth to remove dust and dirt. For the silicone strap, a mild soap solution and water can be used, followed by thorough rinsing and drying. Avoid harsh chemicals or abrasive materials.

2. Battery Replacement

As a quartz watch, it is powered by a battery. When the watch stops or the second hand begins to jump erratically (End-of-Life indicator), the battery needs to be replaced. It is recommended to have the battery replaced by a qualified watchmaker to ensure proper sealing and maintain water resistance.

3. Storage

When not wearing your watch, store it in a cool, dry place, away from direct sunlight, extreme temperatures, and strong magnetic fields. The original watch box is ideal for storage.



Rear view of the watch, showing the stainless steel case back and the silicone strap with buckle.

TROUBLESHOOTING

- **Watch not running:** Check if the crown is fully pushed in. If the watch still does not run, the battery may need replacement.
- **Date not changing:** Ensure the time is set correctly, especially the AM/PM cycle. The date typically changes around midnight. If the date is set between 9 PM and 3 AM, manually adjust it outside this window.
- **Condensation under the crystal:** This indicates moisture ingress. Immediately seek professional service to prevent damage to the movement.
- **Chronograph hands not resetting to zero:** This may require a chronograph reset procedure, which can vary by movement. Consult a professional watchmaker if the issue persists after attempting a basic reset.

SPECIFICATIONS

Feature	Detail
Brand	JACQUES LEMANS
Model Number	1-1820C (Miami)
Department	Men's
Watch Movement Type	Quartz
Display Type	Chronograph
Special Features	Chronograph
Power Source	Battery Powered
Water Resistance Depth	50 Meters
Clasp Type	Pin Buckle
Item Shape	Round
Band Color	White
Dial Color	Silver
Band Material Type	Silicone
Case Material Type	Stainless Steel
Dial Window Material Type	Mineral
Case Diameter	50 Millimeters
Band Width	29 Millimeters
Case Thickness	15 Millimeters
Product Dimensions (L x W x H)	1.09 x 0.71 x 1.09 cm
Item Weight	0.12 Grams

WARRANTY AND SUPPORT

Information regarding specific warranty terms and customer support contacts for the JACQUES LEMANS 1-1820C Miami watch was not available in the provided product data. Please refer to the documentation included with your purchase or visit the official JACQUES LEMANS website for detailed warranty information and support options.