

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› [Boland](#) /

› Boland Faceless Ghost Spectrum Decoration User Manual

Boland 74551

Boland Faceless Ghost Spectrum Decoration User Manual

Model: 74551

INTRODUCTION

This manual provides essential information for the safe and effective use of your Boland Faceless Ghost Spectrum Decoration. This chained Reaper Halloween decoration measures 100cm long. The black head is made from polystyrene and the limbs are moveable. The figure is wearing a white robe with plastic chains around their skeleton hands. Suspend this decoration for a Halloween party!

SAFETY INFORMATION

- **Keep away from fire:** This item is flammable. Do not expose to open flames or high heat sources.
- **Not a toy:** This product is intended for decoration purposes only and is not suitable for children. Keep out of reach of children.
- **Handle with care:** The decoration contains delicate components. Avoid excessive force when handling or adjusting.
- **Indoor/Sheltered Outdoor Use:** While durable, prolonged exposure to harsh weather conditions (heavy rain, strong winds) may damage the product.

PACKAGE CONTENTS

Verify that all components are present upon opening the package:

- 1 x Faceless Ghost Spectrum Decoration (100 cm)
- Attached plastic chains
- Integrated hanging loop



Image: Front of the product packaging, displaying the Boland logo and the ghost decoration.



Image: Back of the product packaging, featuring multi-language safety warnings and the product barcode.

SETUP AND INSTALLATION

Follow these steps to set up your Faceless Ghost decoration:

1. Carefully remove the decoration from its packaging.
2. Gently unfold the white robe and adjust the movable limbs (skeleton hands) to your desired position. The plastic chains are attached to the hands.
3. Locate the hanging loop at the top of the ghost's head.
4. Use a sturdy hook, string, or wire (not included) to suspend the decoration from a suitable location. Ensure the hanging point can support the decoration's weight (approximately 3.52 ounces).





Image: The Faceless Ghost decoration, ready for display, showcasing its full form and attached chain.





Image: A side view of the ghost, illustrating the flow of its white robe and the articulation of its skeleton hands.



Image: Detailed view of the ghost's skeleton hands and the plastic chain they hold.

Video: A closer look at the Boland Faceless Ghost Spectrum Decoration, demonstrating its features and how to unfold and prepare it for display.

OPERATION AND DISPLAY

Once hung, the ghost decoration can be positioned to create various effects:

- **Adjust Limbs:** The skeleton hands are movable, allowing you to pose them for a more dynamic or eerie appearance.
- **Lighting:** For enhanced effect, consider placing the ghost under appropriate lighting to highlight its features and create shadows.
- **Placement:** Ideal for Halloween occasions, horror nights, or themed parties. It can be suspended indoors or in sheltered outdoor areas like porches or covered patios.



Image: The Faceless Ghost decoration displayed outdoors, hanging from a tree, demonstrating its visual impact in a natural setting.




Image: A size comparison diagram showing the ghost decoration next to a human figure, illustrating its 100 cm (approximately 39.37 inches) length.

MAINTENANCE AND CARE

- **Cleaning:** To clean, gently wipe with a soft, dry cloth. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** When not in use, store the decoration in its original packaging or a clean, dry place away from direct sunlight and extreme temperatures to preserve its materials and color.
- **Handling:** Avoid pulling or tugging on the fabric or chains to prevent damage.

TROUBLESHOOTING

While this decoration is simple in design, here are some common considerations:

- **Ghost not hanging straight:** Ensure the hanging point is level and the fabric is evenly distributed around the head. Gently adjust the robe.
- **Limbs not holding position:** The limbs are designed to be somewhat flexible. If they do not hold a specific pose, try gently bending them into place or supporting them with a thin wire if a rigid pose is desired (wire not included).
- **Fabric appears creased:** The fabric may be creased from packaging. Gently smooth it out by hand. Do not iron.

SPECIFICATIONS

Brand	Boland
Model Number	74551
Product Dimensions	39.37 x 11.81 x 11.81 inches (100 cm length)
Item Weight	3.52 ounces

Materials	Gauze, Plastic, Polyexpan
Recommended Age	14 years and up

WARRANTY AND SUPPORT

For any questions, concerns, or support regarding your Boland Faceless Ghost Spectrum Decoration, please contact the retailer or manufacturer directly. Please retain your proof of purchase for any warranty claims.