

## Snow Peak TP-770R

# Snow Peak Tortue Pro. TP-770R 4-Person Tent Instruction Manual

Model: TP-770R | Brand: Snow Peak

[Overview](#)

[Components](#)

[Setup](#)

[Operating](#)

[Maintenance](#)

[Troubleshooting](#)

[Specifications](#)

[Warranty &  
Support](#)

## 1. OVERVIEW

The Snow Peak Tortue Pro. is an all-in-one shelter designed compactly, based on the popular Land Lock model. Developed for families of up to 4 people, it inherits the multi-mesh panel style released in 2011. This tent is suitable for all seasons, providing warmth in cooler autumn/winter months and excellent ventilation for hot seasons, ensuring a comfortable sleeping environment in the inner tent. Standard features include upright poles for panel lift-up, a shield roof with blackout properties, a ground sheet for the inner tent, and side walls to cover the panel sides when lifted. The Pro. series features a unified all-gray color scheme, offering a sophisticated aesthetic suitable for adult camping.

### Key Features:

- **All-Season Comfort:** Designed for both cool and warm weather with excellent ventilation.
- **Spacious Design:** Accommodates up to 4 people comfortably with dedicated living and sleeping areas.
- **Advanced Materials:** Features blackout pigment PU coating for superior light blocking and UV protection, along with high water pressure resistance.
- **Integrated Shelter:** Combines sleeping and living spaces into a single, compact unit.
- **Versatile Configuration:** Multiple mesh panels and lift-up options for customizable airflow and shade.

## 2. COMPONENTS

Verify that all components are present before proceeding with setup.

- Main Body (Flysheets)
- Inner Tent
- Ridge Pole
- A Frame (x2)

- Center Frame (x2)
- C Frame (x2)
- Tent Frame (x1)
- Upright Poles (190cm x2)
- Duralumin Pegs (21cm x30)
- Guy Ropes (3.0m x4, 2.5m x10, 1.5m x2)
- Seam Grip Agent
- Peg Case
- Frame Case
- Main Body Carry Bag
- Instruction Manual

### 3. SETUP INSTRUCTIONS

---

Follow these steps for proper tent setup. It is recommended to practice setup in a familiar environment before your first trip.

1. **Choose a Site:** Select a flat, clear area free from sharp objects. Lay out the main body (flysheets) on the ground.
2. **Assemble Poles:** Connect the sections of each frame pole (A, Center, C, Tent, Ridge) according to their color coding or markings.
3. **Insert Frames:** Slide the assembled frame poles into their corresponding sleeves on the flysheet. Ensure they are fully inserted.
4. **Raise the Tent:** Gradually raise the tent by securing the poles. Attach the pole clips to the frame for stability.
5. **Peg Down:** Secure the tent corners and guy ropes with the duralumin pegs. Ensure all ropes are taut to maximize stability.
6. **Install Inner Tent:** Attach the inner tent to the designated hooks inside the main body. Lay out the ground sheet inside the inner tent.
7. **Optional Upright Poles:** Use the upright poles to lift the front or side panels, creating an extended canopy for shade or ventilation.



Image: The Snow Peak Tortue Pro. tent fully set up by a lake, demonstrating its spacious design and natural integration.



Image: The Tortue Pro. tent pitched in a grassy area, showcasing its overall structure and multiple entry points.



Image: A close-up view of one of the tent's entrances, showing the mesh panel and zippered door.

Tortue Pro.  
トルテュ Pro.

360 cm

インナーテント

580 cm

Shelter Product

# Tortue Pro.

トルテュ Pro.

3~4人家族を想定した快適オールインワンシェルター。



「ランドロック」をひと回りコンパクトにデザインしたシェルターです。リビングの奥にセットするインナーテントも必要最低限の高さに抑えてあります。無駄なスペースを削ったリビング&ベッドルームスペースを持ちます。Pro.モデルとして生地スペックや耐水圧、などワンレベル上のスペックを備えています。フロントパネルを跳ね上げて、快適で開放的なスペースを楽しむことができます。



Image: Technical diagram illustrating the dimensions of the Tortue Pro. tent, including length, width, and height.



Image: A person laying out the ground sheet inside the tent, preparing for the inner tent setup.



Image: Close-up showing the attachment of a tent pole to a peg, illustrating the secure anchoring system.



Image: Detail of a pole clip, used to secure the tent fabric to the frame poles.

## 4. OPERATING INSTRUCTIONS

---

Maximize your comfort and the tent's functionality with these operating tips.

- **Ventilation:** Utilize the multiple mesh panels and roof vents to control airflow. Open panels during warm weather to prevent condensation and ensure comfort.
- **Panel Lift-Up:** Use the included upright poles to lift the front or side panels. This creates a shaded living area and improves air circulation.
- **Privacy and Weather Protection:** Close all panels and zippers during rain or strong winds, or for privacy. The blackout pigment coating on the roof provides excellent shade and reduces internal temperature.
- **Interior Storage:** Use the mesh pockets inside the inner tent for organizing small personal items.
- **Lighting:** Hang a lantern from the designated hook inside the inner tent for nighttime illumination.



Image: The tent with a side panel lifted, creating an open living space and demonstrating ventilation.



Image: Interior shot of the tent's living area, furnished with a table and chairs, illustrating the comfortable space.



Image: A person adjusting a window flap on the tent, showing the mesh and fabric options for ventilation and privacy.



Image: Interior view of the inner tent, showing convenient mesh storage pockets for small items.



Image: An interior hook for hanging a lantern or other lighting, providing illumination inside the tent.

## 5. MAINTENANCE

---

Proper care and maintenance will extend the life of your tent.

- **Cleaning:** After each use, gently brush off dirt and debris. For stubborn stains, use a mild soap and water solution with a soft cloth. Do not use harsh detergents or abrasive cleaners.
- **Drying:** Always ensure the tent is completely dry before packing it away. Packing a damp tent can lead to mold, mildew, and fabric degradation. Air dry in a shaded, well-ventilated area.
- **Storage:** Store the tent in its carry bag in a cool, dry place away from direct sunlight and extreme temperatures.
- **Seam Sealing:** Periodically inspect seams for wear. Use the included seam grip agent or a suitable seam sealer to re-seal any areas showing signs of leakage.
- **Pole Care:** Keep poles clean and free of dirt. If poles become bent or damaged, replace them promptly to maintain tent structure.

# 03

Snow Peak Standard

Tent Product

## Tent Fabric 1

テントの壁に課せられた雨対策の機能



### 高次元で実現する防水と耐水圧ミニマムというスペック

ベッドルームであるインナーテントを屋根として守るフライシートは、自然の中で起こる気象の変化にさらされます。

日本は三寒四温と昔から言われ、降雨に対して高いレベルで防水機能、撥水機能を備え対処するスペックが必要です。

スノーピークの耐水圧表記にはミニマムという単語が付いています。

どこの1点を計測しても最低この数値を保証するという意味です。

スノーピークの3つのカテゴリーに分けられるテントシリーズ、

エントリーシリーズでもフライシート、グランドシートともに耐水圧は1,800mmミニマムに設計されています。

Proシリーズに至っては、フライシート3,000mmミニマム、グランドシート10,000mmミニマムの

最強の耐水圧を誇ります。

自然の中での安眠を約束するスノーピークのスタンダードスペックです。




Image: Close-up image demonstrating the water-repellent properties of the tent fabric, with water beading on the surface.

## 6. TROUBLESHOOTING

Refer to this section for solutions to common issues.

Problem	Possible Cause	Solution
<b>Condensation inside tent</b>	Insufficient ventilation, high humidity, temperature difference.	Increase ventilation by opening mesh panels and roof vents. Ensure proper airflow.
<b>Tent unstable in wind</b>	Improper pegging, loose guy ropes, incorrect pole setup.	Ensure all pegs are fully driven into the ground. Tighten all guy ropes evenly. Verify poles are correctly seated.
<b>Water leakage</b>	Damaged fabric, worn seam sealing, improper flysheet tension.	Inspect fabric for tears; repair if necessary. Re-seal seams with seam grip agent. Adjust flysheet tension to shed water effectively.
<b>Zippers sticking</b>	Dirt/debris in zipper teeth, fabric caught in zipper.	Clean zipper teeth with a brush. Apply a silicone-based zipper lubricant. Carefully free any caught fabric.

## 7. SPECIFICATIONS

---

Detailed technical specifications for the Snow Peak Tortue Pro. TP-770R tent.

Feature	Detail
<b>Brand</b>	Snow Peak
<b>Model Number</b>	TP-770R
<b>Recommended Use</b>	Camping & Hiking
<b>Capacity</b>	4 people
<b>Seasons</b>	4 Season
<b>Weight</b>	28.0 kg (44.09 pounds)
<b>Main Body (Fly) Material</b>	150D Polyester Oxford, Blackout Pigment PU Coating (Roof), PU Coating (Wall), Teflon Water Repellent, UV Cut
<b>Fly Water Pressure Resistance</b>	3,000mm minimum (Roof), 1,800mm minimum (Wall)
<b>Inner Tent Material</b>	68D Polyester Ripstop
<b>Bottom Material</b>	300D Polyester Oxford PU Coating
<b>Bottom Water Pressure Resistance</b>	10,000mm minimum
<b>Frame Material</b>	A6061 (φ16mm, 17.5mm, 19mm)
<b>Storage Case Size (Main Body)</b>	W78 x D30 x H34cm
<b>Storage Case Size (Frame)</b>	W80 x D20 x H20cm
<b>Color</b>	Gray / Brown
<b>Assembly Type</b>	Freestanding
<b>Closure Type</b>	Zipper




Image: Another diagram showing the tent's dimensions from a different perspective, including height and footprint.




Image: Diagram comparing standard PU processing with blackout pigment PU processing (Shield type) for light blocking.



Image: Image comparing the amount of light passing through standard fabric versus Shield fabric, demonstrating superior light blocking.



Image: Chart illustrating the temperature difference on a table surface under direct sunlight, normal fabric, and Shield fabric, showing the cooling effect of Shield.

## 8. WARRANTY & SUPPORT

---

### Warranty Information:

Snow Peak products are designed for durability and performance. This product is covered by a limited warranty against manufacturing defects in materials and workmanship. The warranty period and terms may vary by region. Please retain your proof of purchase for warranty claims.

### Customer Support:

For technical assistance, spare parts, or warranty service, please contact Snow Peak customer support through their official website or your local distributor. Provide your product model number (TP-770R) and a detailed description of the issue when contacting support.

Official Snow Peak Website: [www.snowpeak.com](http://www.snowpeak.com)

