Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

havit MS60WB

Havit MS60WB Wireless Mouse User Manual

Model: MS60WB

1. Introduction

This manual provides detailed instructions for the setup, operation, maintenance, and troubleshooting of your Havit MS60WB Wireless Mouse. Please read this manual thoroughly before using the product to ensure proper functionality and to prevent damage.

2. Safety Information

- Do not expose the mouse to water or excessive moisture.
- Avoid dropping or subjecting the mouse to strong impacts.
- Do not attempt to disassemble or repair the mouse yourself. Refer to qualified service personnel.
- Keep out of reach of children.
- Dispose of batteries according to local regulations.

3. Package Contents

Please check the package for the following items:

- Havit MS60WB Wireless Mouse
- USB Receiver
- User Manual (this document)
- AA Battery (may or may not be included depending on region)



Figure 3.1: Havit MS60WB Wireless Mouse in its retail packaging, showing the mouse and its box.

4. Product Overview

Familiarize yourself with the components of your Havit MS60WB Wireless Mouse.



Figure 4.1: Top-down view of the Havit MS60WB Wireless Mouse, highlighting its ergonomic design and button layout.



Figure 4.2: Comparison of Havit MS60WB mouse in black and grey colors, showing the overall shape and button placement.

4.1 Mouse Buttons and Features

- **Left Click Button:** Standard left mouse button.
- **Right Click Button:** Standard right mouse button.
- **Scroll Wheel:** For scrolling up and down, also functions as a middle click button.



Figure 4.3: Close-up view of the mouse scroll wheel, located between the left and right click buttons.

- **DPI Adjustment Button:** Located behind the scroll wheel, allows cycling through different DPI settings for cursor speed.



Figure 4.4: Close-up view of the DPI adjustment button, labeled "DPI", positioned behind the scroll wheel.

- **Forward/Backward Buttons:** Located on the side for quick navigation in web browsers or file explorers.
- **Battery Compartment:** Located on the underside of the mouse.
- **USB Receiver Storage:** A slot on the underside of the mouse to store the USB receiver when not in use.

5. Setup

5.1 Installing the Battery

1. Flip the mouse over to access the underside.
2. Locate the battery compartment cover.
3. Slide or lift the cover to open the compartment.
4. Insert one AA battery, ensuring the polarity (+/-) matches the diagram inside the compartment.
5. Close the battery compartment cover securely.

5.2 Connecting the USB Receiver

1. Locate the USB receiver, usually stored in a slot next to the battery compartment on the underside of the mouse.
2. Remove the USB receiver from its storage slot.
3. Plug the USB receiver into an available USB port on your computer.
4. Your computer should automatically detect and install the necessary drivers. This may take a few moments.
5. Once the drivers are installed, the mouse is ready for use.

6. Operating Instructions

6.1 Basic Operation

- **Moving the Cursor:** Move the mouse on a flat surface to control the cursor on your screen.
- **Clicking:** Press the left button for a primary click, and the right button for a secondary click (context menu).

- **Scrolling:** Roll the scroll wheel up or down to navigate through documents or web pages.

6.2 Adjusting DPI (Sensitivity)

The DPI (Dots Per Inch) button allows you to change the sensitivity of the mouse cursor. Higher DPI means the cursor moves faster across the screen with less physical mouse movement.

1. Press the DPI adjustment button (located behind the scroll wheel).
2. Each press will cycle through available DPI settings. Observe the cursor speed to find your preferred setting.

6.3 Power Saving Mode

The Havit MS60WB mouse is designed with an automatic power-saving feature. If the mouse is inactive for a period, it will enter sleep mode to conserve battery life. To wake it up, simply move the mouse or click any button.

7. Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the surface of the mouse. For stubborn dirt, a slightly damp cloth can be used, but ensure no moisture enters the mouse.
- **Battery Replacement:** When the mouse performance degrades or the cursor becomes erratic, it's likely time to replace the battery. Follow the steps in Section 5.1.
- **Storage:** When not in use for extended periods, remove the battery to prevent leakage and store the USB receiver in its designated slot.

8. Troubleshooting

Problem	Possible Cause	Solution
Mouse not responding	Low or dead battery	Replace the battery.
Mouse not responding	USB receiver not properly connected	Ensure the USB receiver is firmly plugged into a working USB port. Try a different USB port.
Mouse not responding	Driver issue	Restart your computer. Check device manager for driver status.
Erratic cursor movement	Dirty optical sensor	Clean the optical sensor on the underside of the mouse with a soft, dry cloth.
Erratic cursor movement	Mouse used on unsuitable surface	Use the mouse on a non-reflective, opaque surface or a mouse pad.
Short battery life	Frequent use or old battery	Replace with a new, high-quality battery. Ensure the mouse enters sleep mode when idle.

9. Specifications

- **Model:** Havit MS60WB
- **Connectivity:** 2.4GHz Wireless (USB Receiver)
- **DPI Settings:** Multiple adjustable levels (e.g., 800/1200/1600 DPI)
- **Buttons:** 6 (Left, Right, Scroll Wheel, DPI, Forward, Backward)

- **Power:** 1 x AA Battery
- **Compatibility:** Windows, macOS, Linux (standard USB HID device)
- **Dimensions:** (Approximate, based on typical mouse size)
- **Weight:** (Approximate, based on typical mouse weight)

Note: Specific DPI values, dimensions, and weight may vary slightly. Refer to product packaging for precise details.

10. Warranty and Support

Havit products typically come with a limited warranty. Please refer to the warranty card included with your product or visit the official Havit website for detailed warranty terms and conditions.
For technical support, troubleshooting assistance beyond this manual, or warranty claims, please contact Havit customer service through their official website or the contact information provided on your product packaging.
Official Havit Website: www.havit.com

© 2024 Havit. All rights reserved.
This manual is subject to change without prior notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00ID5PAYU

More documents and user manuals: **https://manuals.plus/**