

[Manuals.plus](#) /

› [Konstsmide](#) /

› Konstsmide 3607-002 Outdoor Light Set Add-On Timer Instruction Manual

Konstsmide 3607-002

Konstsmide Outdoor Light Set Add-On Timer

Model: 3607-002

INTRODUCTION

Thank you for choosing the Konstsmide Outdoor Light Set Add-On Timer. This device is designed to provide convenient automatic operation for your Konstsmide 24V static light sets, allowing them to switch on and off at a set time each day. Please read this manual carefully before installation and use to ensure safe and optimal performance.

IMPORTANT SAFETY INFORMATION

- This timer is designed for outdoor use with Konstsmide 24V static light sets only. Do not use with other voltage systems or non-Konstsmide products.
- Ensure all connections are secure and protected from moisture.
- Do not attempt to open or modify the timer unit. Refer servicing to qualified personnel.
- Keep out of reach of children.
- Disconnect power before making any connections or disconnections.

PACKAGE CONTENTS

- 1 x Konstsmide Outdoor Light Set Add-On Timer (Model 3607-002)
- 1 x Instruction Manual

PRODUCT OVERVIEW

The Konstsmide Add-On Timer features a simple button interface for setting the 9-hour timer function or manually controlling your lights.




Figure 1: Konstsmide 3607-002 Outdoor Light Set Add-On Timer. This image displays the white timer unit with its input and output connectors, and the single control button with its three labeled functions: Timer (9 hours), On, and Off.

SETUP INSTRUCTIONS

1. Ensure your Konstsmide 24V static light set is disconnected from its power source.
2. Connect the timer's input cable (the one with the male connector) to your existing Konstsmide transformer's output.
3. Connect your Konstsmide 24V static light set to the timer's output cable (the one with the female connector).
4. Once all connections are secure, plug your Konstsmide transformer into a suitable outdoor power outlet.

OPERATING INSTRUCTIONS

The timer unit features a single button to cycle through its operating modes:

- **1. Timer 9 hours:** Press the button once to activate the 9-hour timer. The lights will turn on at the moment you press the button and remain on for 9 hours. They will then turn off for 15 hours. This cycle will repeat daily at the same time.
- **2. On:** Press the button a second time to set the lights to remain continuously on.
- **3. Off:** Press the button a third time to turn the lights off completely.

To reset the timer start time, simply unplug the transformer from the power outlet, wait a few seconds, plug it back in, and then press the button at your desired start time for the 9-hour timer function.

MAINTENANCE

- Periodically inspect the timer and all connections for any signs of damage or wear.

- Clean the unit with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Ensure the unit is kept free from excessive dirt, debris, and standing water.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Lights do not turn on.	No power to transformer. Loose connections. Timer set to 'Off'. Light set malfunction.	Check power outlet and transformer. Ensure all cables are securely connected. Press button to cycle to 'On' or 'Timer' mode. Test light set directly with transformer if possible.
Timer function not working as expected.	Incorrect timer setting. Power interruption.	Ensure the timer is in 'Timer 9 hours' mode. Reset the timer by unplugging and replugging the transformer, then setting the timer at the desired start time.
Lights flicker or dim.	Loose connection. Overloaded circuit (unlikely with this timer, but possible with light set). Damaged light set.	Check all connections. Ensure the total LED count does not exceed 400 LEDs for the connected light set. Inspect light set for damage.

SPECIFICATIONS

- **Model:** 3607-002
- **Brand:** Konstsmide
- **Function:** 9-hour timer, Continuous On, Continuous Off
- **Compatibility:** Konstsmide 24V static low voltage outdoor connected items (excluding 46XX connectable range)
- **Maximum Load:** Up to 400 LEDs
- **Color:** White
- **Item Weight:** 0.04 Kilograms

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the official Konstsmide website or contact their customer service department. Keep your purchase receipt as proof of purchase.