

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

- › [Home Decorators Collection](#) /
- › [Home Decorators Collection Espresso Floating Corner Shelf \(Model 9084618\) Instruction Manual](#)

Home Decorators Collection 9084618

Home Decorators Collection Espresso Floating Corner Shelf

MODEL: 9084618

Introduction

This instruction manual provides essential information for the safe and proper installation, use, and maintenance of your Home Decorators Collection Espresso Floating Corner Shelf. Please read this manual thoroughly before beginning installation and retain it for future reference.

Product Overview

The Home Decorators Collection Espresso Floating Corner Shelf is designed to provide a stylish and space-saving storage solution for small rooms. Crafted from durable wood with an espresso finish, this corner shelf is functional for displaying decorative items, small lamps, or bathroom accessories. Its floating design offers a clean, modern aesthetic.



Image: The Espresso Floating Corner Shelf, showcasing its design and potential use with a decorative

Package Contents

Please verify that all components are present before beginning installation. If any parts are missing or damaged, do not proceed with installation and contact customer support.

- 1x Espresso Floating Corner Shelf
- 1x Mounting Bracket (if applicable)
- Screws and Wall Anchors (quantity may vary based on design)
- Installation Template (if included)

Safety Information

- Always ensure the shelf is securely mounted to a sturdy wall stud or using appropriate wall anchors for your wall type. Failure to do so may result in the shelf falling and causing injury or damage.
- Do not exceed the recommended weight capacity of the shelf. Overloading can cause the shelf to detach from the wall.
- Keep small parts and hardware away from children to prevent choking hazards.
- Wear appropriate safety gear, such as eye protection, during installation.
- If drilling into walls, be aware of hidden electrical wires or plumbing. Use a stud finder and a non-contact voltage detector if unsure.

Setup and Installation

Tools Required: Pencil, Level, Measuring Tape, Drill, Drill Bits (appropriate for anchors), Stud Finder (recommended), Screwdriver (Phillips head).

1. **Choose Location:** Select a corner on a wall suitable for mounting. Ensure there are no obstructions (e.g., electrical outlets, pipes) behind the wall where you plan to drill.
2. **Mark Mounting Points:** Hold the shelf or mounting bracket against the wall in the desired position. Use a level to ensure it is perfectly horizontal. Mark the screw hole locations with a pencil. If using an installation template, tape it to the wall and mark through the designated holes.
3. **Drill Pilot Holes:** Using a drill bit appropriate for your wall anchors (refer to anchor instructions), drill pilot holes at the marked locations. If mounting into a wood stud, a smaller pilot hole may be sufficient.
4. **Insert Wall Anchors:** If not drilling into a stud, gently tap the wall anchors into the pilot holes until they are flush with the wall surface.
5. **Attach Mounting Bracket:** Align the mounting bracket with the drilled holes/anchors. Insert screws through the bracket and tighten them securely into the wall or anchors using a screwdriver. Do not overtighten.
6. **Mount Shelf:** Carefully slide the corner shelf onto the installed mounting bracket. Ensure it is fully seated and stable. Some designs may include small set screws on the underside of the shelf to secure it to the bracket; tighten these if present.
7. **Verify Stability:** Gently test the shelf's stability by applying light downward pressure. Ensure it is firmly attached to the wall before placing any items on it.

Usage

Once securely installed, your floating corner shelf is ready for use. It is ideal for displaying lightweight decorative items such as small vases, picture frames, figurines, or small plants. Always distribute weight evenly on the shelf and adhere to the maximum weight capacity specified in the 'Specifications' section to prevent damage or accidents.

Maintenance

To maintain the appearance and longevity of your espresso floating corner shelf, follow these simple cleaning guidelines:

- Dust regularly with a soft, dry cloth.
- For deeper cleaning, wipe with a damp cloth using a mild, non-abrasive cleaner. Immediately dry with a clean, soft cloth to prevent water spots or damage to the finish.
- Avoid using harsh chemicals, abrasive cleaners, or scouring pads, as these can damage the wood finish.
- Periodically check the mounting screws and tighten if necessary to ensure the shelf remains secure.

Troubleshooting

- **Shelf is not level:** Ensure the mounting bracket was installed perfectly level. If not, remove the shelf, adjust the bracket, and re-mount. Use a level during installation.
- **Shelf feels loose:** Check all mounting screws to ensure they are securely tightened into the wall or anchors. If using wall anchors, ensure they are appropriate for your wall type and installed correctly. Overloading the shelf can also cause it to feel loose; reduce the weight.
- **Damage to wall during installation:** If the wall is damaged, repair it before re-attempting installation in a new location or with appropriate repair materials.

Specifications

Attribute	Detail
Brand	Home Decorators Collection
Model Number	9084618
Product Dimensions	30.73 x 5.33 x 31.24 cm (11.8 x 11.8 x 2 inches approx.)
Item Weight	1.29 kg
Material	Wood
Mounting Type	Wall Mount
Shelf Type	Corner Shelf, Floating Shelf
Special Feature	Space Saving
Color	Espresso

Warranty and Support

For warranty information and customer support, please refer to the documentation provided at the time of purchase or visit the official Home Decorators Collection website. Keep your proof of purchase for any warranty claims.

© 2023 Home Decorators Collection. All rights reserved.