

Brady 127183

Brady 127183 Fire Safety Sign User Manual

Model: 127183

1. PRODUCT OVERVIEW

The Brady 127183 Fire Safety Sign is designed to clearly identify the location of a fire alarm and instruct individuals to call the fire department during an emergency. This sign serves as a crucial visual aid for emergency procedures and helps guide personnel to appropriate actions.

Key features of this sign include:

- Constructed from B-401 plastic material for durability.
- Features round-cornered panels with pre-punched holes for easy application to rigid surfaces.
- Offers good resistance to chemicals and abrasion, ensuring longevity.
- Designed for an average expected outdoor life of 3-5 years.

The sign prominently displays the legend: **"FIRE ALARM CALL FIRE DEPT."**



FIRE ALARM
CALL FIRE DEPT.

BRADY® #127184 BRADYID.COM Y2426807



Figure 1: Brady Fire Safety Sign, Model 127183. This image displays the Brady Fire Safety Sign. The sign is rectangular with a white background. Prominently displayed in large, bold red capital letters are the words 'FIRE ALARM' on the top line and 'CALL FIRE DEPT.' on the bottom line. In the bottom center, smaller text includes 'BRADY® #127184 BRADYID.COM Y2426807' and a barcode. Please note the model number in the image is 127184, while this manual refers to model 127183.

2. INSTALLATION (SETUP)

The Brady 127183 Fire Safety Sign is designed for wall mounting. Follow these guidelines for proper installation:

1. **Select Location:** Choose a highly visible location near the fire alarm or in an area where emergency instructions are critical. Ensure the sign is not obstructed by other objects.
2. **Prepare Surface:** The sign is intended for application to rigid surfaces. Ensure the mounting surface is clean, dry, and smooth.
3. **Mounting:** The sign panels are pre-punched. Use appropriate fasteners (screws, rivets, etc., not included) that are suitable for your chosen mounting surface and the sign's pre-drilled holes. Securely attach the sign to prevent accidental dislodgement.
4. **Orientation:** Ensure the sign is mounted in a landscape orientation, as designed, for correct readability.

3. CARE AND MAINTENANCE

To ensure the longevity and continued effectiveness of your Brady Fire Safety Sign, follow these simple care and maintenance instructions:

- **Cleaning:** Periodically wipe the sign surface with a soft, damp cloth to remove dust and dirt. Avoid using abrasive cleaners or solvents, as these may damage the sign's material or legend.
- **Inspection:** Regularly inspect the sign for any signs of damage, fading, or wear. Ensure the mounting remains secure. If the sign becomes illegible or damaged, replace it promptly to maintain safety standards.
- **Durability:** The B-401 plastic material provides good chemical and abrasion resistance, contributing to its durability in various environments.

4. SPECIFICATIONS

Attribute	Detail
Brand	Brady
Model Number	127183
Product Dimensions	7" Height x 10" Width x 0.39" Depth (17.78 cm x 25.4 cm x 0.99 cm)
Item Weight	0.07 Kilograms (2.47 ounces)
Material	B-401 Plastic
Color	Red on White
Mounting Type	Wall Mount
Orientation	Landscape
Pre-printed Legend	Fire Alarm Call Fire Dept.
Recommended Uses	Property, Office, Instruction, Warning
Average Outdoor Life	3-5 years

5. SAFETY INFORMATION

This sign is a critical component of a facility's fire safety plan. Ensure it is installed correctly and maintained to remain effective. Its purpose is to provide clear, immediate instructions during a fire emergency, directing individuals to activate the fire alarm and contact emergency services.

- Always ensure the sign is visible and unobstructed.
- Regularly check for damage or fading that could impair readability.
- Adhere to local fire safety codes and regulations regarding sign placement and type.

6. SUPPORT AND WARRANTY

For technical support, product information, or warranty inquiries regarding your Brady 127183 Fire Safety Sign, please

contact Brady customer service. You can find more information on the official Brady website.

Manufacturer: Brady

Official Website: www.bradyid.com





Product Information Link: bradyid.com/Y2426807 (as seen on product image)

Please refer to your purchase documentation for specific warranty details.



© 2023 Brady Corporation. All rights reserved.
This manual is for informational purposes only.

Related Documents - 127183

	<p>Brady M211 Label Printer Quick Start Guide</p> <p>Get started quickly with the Brady M211 Label Printer. This guide covers charging, label insertion, app download, power on, and Bluetooth connection.</p>
	<p>Brady M611 Label Printer User Manual - Features, Setup, and Support</p> <p>Explore the Brady M611 Label Printer with this comprehensive user manual. Learn about its rugged design, wireless connectivity (Bluetooth, Wi-Fi), touchscreen interface, and software integration for creating professional labels. Find setup guides, maintenance tips, and technical support resources.</p>
	<p>Brady M410 Label Printer: Frequently Asked Questions</p> <p>Comprehensive FAQ for the Brady M410 Label Printer, covering its features, connectivity, label compatibility, software integration with Brady Workstation, and support information.</p>
	<p>Manuale Utente Stampante Etichette Brady M410</p> <p>Guida completa al Manuale Utente della stampante etichette Brady M410, che copre configurazione, funzionamento, manutenzione e risoluzione dei problemi per un uso efficiente.</p>



[Brady BBP31 Sign & Label Printer User's Manual](#)

Comprehensive user manual for the Brady BBP31 Sign & Label Printer, covering setup, operation, maintenance, and troubleshooting.



[Brady BMP21-PLUS Label Printer Quick Start Guide](#)

This guide provides essential information for setting up and operating the Brady BMP21-PLUS handheld label printer. Learn how to install batteries, connect AC power, change label cartridges, use the keypad, create, save, open, and print labels.