

[Manuals.plus](#) /

› [Eurofase](#) /

› Eurofase 26359-014 Casa Bathbar Instruction Manual

Eurofase 26359-014

Eurofase 26359-014 Casa Bathbar Instruction Manual

Model: 26359-014

IMPORTANT SAFETY INFORMATION

Please read and understand all instructions before beginning installation. Failure to do so may result in electric shock, fire, or other injuries that could be hazardous or fatal.

- Always disconnect power at the main circuit breaker before installation or maintenance.
- Consult a qualified electrician if you are unsure about the installation process.
- Ensure all electrical connections comply with local codes and ordinances.
- Do not install this fixture in wet locations unless specifically rated for such use. This bathbar is designed for bathroom vanity use.
- Handle crystal components with care to prevent breakage.

PACKAGE CONTENTS

Verify that all components listed below are present before beginning installation.

- Light Fixture (1)
- G9 Light Bulbs (5)
- Mounting Hardware (screws, wire nuts, etc.)
- Faceted Crystal Shade Orbs (5)



Image 1: Eurofase 26359-014 Casa Bathbar with crystal orbs and chrome finish.

SETUP AND INSTALLATION

Professional installation by a licensed electrician is recommended for safety and proper functionality.

1. **Turn off Power:** Locate the main circuit breaker and turn off the power to the junction box where the fixture will be installed.
2. **Prepare Mounting Surface:** Ensure the wall surface is clean, dry, and structurally sound to support the fixture's weight.
3. **Install Mounting Bracket:** Attach the mounting bracket to the junction box using the provided screws. Ensure it is securely fastened.
4. **Wire Connections:** Connect the fixture's wires to the household electrical wires according to standard wiring practices (black to black, white to white, ground to ground). Secure connections with wire nuts.
5. **Mount Fixture:** Carefully align the fixture with the mounting bracket and secure it in place using the provided screws.
6. **Install G9 Bulbs:** Insert the five G9 light bulbs into their respective sockets. Handle bulbs by their base to avoid touching the glass.
7. **Attach Crystal Orbs:** Carefully attach the faceted crystal shade orbs to the fixture as per the design.
8. **Restore Power:** Once installation is complete and all components are secure, restore power at the main circuit breaker.



Image 2: Example installation of Eurofase bathbars above a bathroom vanity with mirrors and sinks.

OPERATING INSTRUCTIONS

The Eurofase Casa Bathbar is designed for simple operation.

- **Power On/Off:** Use the wall switch connected to the fixture to turn the light on or off.
- **Dimming Function:** This fixture is dimmable. If connected to a compatible dimmer switch (sold separately), you can adjust the light intensity by operating the dimmer control.
- **Touch Control:** The fixture features a touch control method. Refer to your specific wall switch or dimmer for detailed touch operation instructions.

MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your bathbar.

- **Cleaning:** Disconnect power before cleaning. Use a soft, dry cloth to wipe the chrome finish and crystal orbs. Do not use abrasive cleaners or solvents, as these may damage the finish.
- **Bulb Replacement:**
 - a. Turn off power at the circuit breaker.
 - b. Allow bulbs to cool completely before handling.
 - c. Carefully remove the old G9 bulb by pulling it straight out.
 - d. Insert a new G9 halogen bulb (max 40W) by pushing it straight into the socket. Avoid touching the glass of the new bulb with bare hands; use a cloth or glove.
 - e. Restore power.

TROUBLESHOOTING

If you encounter issues with your Eurofase Casa Bathbar, refer to the following common problems and solutions.

Problem	Possible Cause	Solution
Light does not turn on.	No power to the fixture. Loose wire connection. Faulty bulb.	Check circuit breaker and wall switch. Ensure all wire connections are secure (power off first). Replace bulb with a new G9 halogen bulb.

Problem	Possible Cause	Solution
Light flickers.	Loose bulb.	Ensure bulbs are fully seated in sockets.
	Incompatible dimmer switch.	Verify dimmer switch compatibility with halogen G9 bulbs.
Crystal orbs are dull.	Dust or residue buildup.	Clean crystal orbs with a soft, dry, lint-free cloth.

If the problem persists after trying these solutions, contact Eurofase customer support or a qualified electrician.

SPECIFICATIONS

Brand	Eurofase
Model Number	26359-014
Model Name	CASA
Fixture Type	Vanity Light / Bathbar
Finish	Chrome
Material	Glass (Crystal Orbs)
Number of Light Sources	5
Bulb Base	G9
Bulb Type	Halogen (included)
Max Wattage per Bulb	40 watts
Voltage	120 Volts
Dimmable	Yes
Mounting Type	Wall Mount
Item Weight	8.64 Pounds
UPC	784497627567, 773546246552

WARRANTY AND SUPPORT

Eurofase products are backed by warranties, reflecting a commitment to craftsmanship, durability, and exceptional service. For specific warranty details, product support, or to inquire about replacement parts, please visit the official Eurofase website or contact their customer service department.

Online Support: www.eurofase.com

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question