

NEMO Equipment FBA_814041013581

NEMO Galaxi 2 Person Backpacking Tent User Manual

Model: FBA_814041013581

Brand: NEMO Equipment

INTRODUCTION

The NEMO Galaxi 2 Person Backpacking Tent is designed to provide reliable shelter for backpackers and campers. This manual provides essential information for the proper setup, operation, maintenance, and troubleshooting of your tent, ensuring its longevity and your comfort in the outdoors.

PACKAGE CONTENTS

Before beginning setup, ensure all components are present:

- Tent Body
- Rainfly
- Tent Poles (Aluminum)
- Tent Stakes
- Guylines
- Footprint
- Stuff Sack



Figure 1: Included Footprint and Stuff Sack. The footprint provides an additional layer of protection for the tent floor, and the stuff sack is used for compact storage and transport of the tent components.

SETUP INSTRUCTIONS

Follow these steps for proper tent setup:

- 1. Choose a Site:** Select a flat, clear area free of sharp objects and debris.
- 2. Lay Out Footprint:** Unfold the footprint and lay it flat on the chosen site. Ensure the coated side faces up.
- 3. Position Tent Body:** Lay the tent body over the footprint, aligning the corners.
- 4. Assemble Poles:** Connect the aluminum pole sections. The Galaxi tent typically uses a hubbed pole system for easy assembly.
- 5. Attach Poles to Tent Body:** Insert the pole ends into the grommets at the tent corners. Clip the tent body to the poles using the attached clips.



Figure 2: The tent body with poles assembled, showing the internal structure before the rainfly is added. This image illustrates the spacious interior and mesh walls for ventilation.

6. **Drape Rainfly:** Place the rainfly over the tent body, ensuring the vestibules are positioned correctly over the doors.
7. **Secure Rainfly:** Attach the rainfly buckles to the corresponding buckles on the tent body at each corner.
8. **Stake Out Tent:** Use the provided stakes to secure the tent corners and vestibule points. For optimal stability, utilize all guylines, especially in windy conditions.



Figure 3: The NEMO Galaxi tent fully pitched with the rainfly in place, ready for use. This view highlights the tent's compact and aerodynamic design, suitable for various outdoor conditions.

OPERATING THE TENT

To maximize your tent's performance and lifespan:

- **Zippers:** Always use two hands when operating zippers to prevent snagging fabric. Keep zipper paths clear.
- **Ventilation:** Utilize the tent's vents and mesh panels to reduce condensation. Open vestibule zippers partially for airflow when conditions allow.
- **Vestibules:** Store gear in the vestibules to keep the interior clear. Ensure gear does not press against the rainfly, which can compromise waterproofing.
- **Interior Space:** The tent is designed for two occupants. Organize your gear efficiently to maintain comfort.

MAINTENANCE

Proper care extends the life of your tent:

- **Cleaning:**

After each trip, clean your tent. Hand wash with a sponge, mild soap (non-detergent), and lukewarm water. Do not machine wash or dry clean. Rinse thoroughly.

- **Drying:**

Always ensure the tent, rainfly, and footprint are completely dry before packing away to prevent mildew and fabric degradation. Hang in a shaded, well-ventilated area.

- **Storage:**

Store your tent loosely in a cool, dry place, away from direct sunlight and extreme temperatures. Avoid compressing it tightly for long periods.

- **Pole Care:**

Inspect poles for bends or cracks. Clean dirt from pole sections and shock cord. If shock cord loses elasticity, it can be replaced.

TROUBLESHOOTING

Issue	Possible Cause	Solution
Condensation inside tent	Lack of ventilation, high humidity	Increase ventilation by opening vents or partially unzipping vestibules. Ensure proper airflow.
Zipper snagging	Fabric caught in zipper teeth	Gently pull fabric away from zipper. Use two hands to operate zippers smoothly. Apply zipper lubricant if needed.
Poles not connecting easily	Dirt in pole ferrules, bent sections	Clean pole ends. Inspect for damage; replace bent sections if necessary.
Water pooling on rainfly	Improper tensioning, saggy rainfly	Re-tension guylines and adjust stake points to ensure rainfly is taut and sheds water effectively.

SPECIFICATIONS

Feature	Detail
Brand	NEMO Equipment
Model Name	FBA_814041013581
Occupancy	2 Person
Seasons	3 Season

Feature	Detail
Item Weight	6 Pounds
Product Dimensions	21" L x 8" W x 8" H (Packed)
Water Resistance Technology	1200 meter
Pole Material Type	Aluminum
Number of Doors	2
Included Components	Tent, Rainfly, Poles, Stakes, Guylines, Footprint, Stuff Sack

WARRANTY AND SUPPORT

NEMO Equipment stands behind the quality of its products. For specific warranty details and to register your product, please visit the official NEMO Equipment website or contact their customer service directly.

For technical support, replacement parts, or any inquiries not covered in this manual, please contact NEMO Equipment customer service:

- **Online Support:** Visit the [NEMO Equipment Store on Amazon](#) or their official website.
- **Contact Information:** Refer to the NEMO Equipment official website for the most current contact methods (phone, email, etc.).

Please have your model number (FBA_814041013581) and purchase date ready when contacting support.

© 2024 NEMO Equipment. All rights reserved.

This manual is for informational purposes only. Specifications are subject to change without notice.