

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Sunbeam](#) /

› [Sunbeam SS Belgian Waffle Maker User Manual](#)

Sunbeam B00IPHAPG4

Sunbeam SS Belgian Waffle Maker User Manual

Model: B00IPHAPG4

IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed, including the following:

- Read all instructions before operating the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner. Return appliance to the nearest authorized service facility for examination, repair, or adjustment.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.

PRODUCT OVERVIEW

The Sunbeam SS Belgian Waffle Maker is designed to create delicious, thick Belgian waffles with ease. It features non-stick cooking plates for easy food release and cleanup, and a compact design for convenient storage.



Figure 1: The Sunbeam SS Belgian Waffle Maker in its closed position, showcasing its stainless steel exterior and control knob.



Figure 2: The waffle maker opened, revealing the non-stick cooking plates designed to create four sections of Belgian waffles.

Key Features:

- Non-stick coating for easy waffle removal and cleaning.
- Adjustable temperature control for desired browning.

- Indicator lights for "Power" and "Ready".
- Compact design for easy storage.
- Durable stainless steel construction.

SETUP

1. **Unpack:** Carefully remove the waffle maker and all packaging materials.
2. **Clean:** Before first use, wipe the cooking plates with a damp cloth or sponge. Dry thoroughly.
3. **Position:** Place the waffle maker on a clean, dry, flat, heat-resistant surface. Ensure there is adequate ventilation around the appliance.
4. **Plug In:** Insert the power plug into a standard 230V AC electrical outlet. The Power indicator light (red) will illuminate.

OPERATING INSTRUCTIONS

1. **Preheat:** Close the waffle maker and turn the temperature control knob to your desired setting (Min to Max). The Ready indicator light (green) will illuminate when the waffle maker has reached the optimal cooking temperature.
2. **Prepare Batter:** While the waffle maker preheats, prepare your waffle batter according to your recipe.
3. **Add Batter:** Once the Ready light illuminates, carefully open the waffle maker. Pour approximately 1 to 1.5 cups of batter onto the center of the lower cooking plate. Distribute the batter evenly across the four sections. *Do not overfill.*
4. **Close:** Gently close the lid of the waffle maker.
5. **Cook:** Allow the waffles to cook until the Ready light illuminates again, indicating they are done. Cooking time will vary based on batter type and desired crispness. For crispier waffles, you may cook for a slightly longer duration after the Ready light illuminates.
6. **Remove Waffles:** Once cooked, open the lid and carefully remove the waffles using a heat-resistant plastic or wooden utensil. *Do not use metal utensils, as they can damage the non-stick coating.*
7. **Repeat:** Close the lid to allow the waffle maker to reheat for the next batch. The Ready light will illuminate again when it's ready.
8. **Turn Off:** When finished, turn the temperature control knob to "Off" and unplug the appliance from the wall outlet.

CLEANING AND MAINTENANCE

Proper cleaning and maintenance will ensure the longevity and optimal performance of your Sunbeam SS Belgian Waffle Maker.

1. **Cool Down:** Always unplug the waffle maker and allow it to cool completely before cleaning.
2. **Wipe Plates:** Use a soft, damp cloth or sponge to wipe the non-stick cooking plates. For stubborn batter residue, dampen a cloth with a small amount of cooking oil and gently rub the area, then wipe clean with a fresh damp cloth.
3. **Clean Exterior:** Wipe the exterior of the waffle maker with a soft, damp cloth. Do not use abrasive cleaners or scouring pads, as they may scratch the surface.

4. **Do Not Immerse:** Never immerse the waffle maker, its cord, or plug in water or any other liquid.
5. **Storage:** Once clean and dry, store the waffle maker in an upright position to save space, or lay flat in a cabinet.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Waffle maker does not heat up.	Not plugged in; power outlet not working; appliance malfunction.	Ensure the plug is securely inserted into a working outlet. Check your circuit breaker. If the issue persists, contact customer support.
Waffles stick to the plates.	Insufficient oil/butter on plates; non-stick coating worn; batter too thick.	Lightly brush or spray cooking oil on the plates before each use. Ensure plates are clean. Adjust batter consistency.
Waffles are not crispy.	Temperature setting too low; insufficient cooking time.	Increase the temperature setting. Allow waffles to cook for a longer period after the Ready light illuminates.
Waffles are too dark/burnt.	Temperature setting too high; excessive cooking time.	Decrease the temperature setting. Reduce cooking time.

SPECIFICATIONS

- **Brand:** Sunbeam
- **Model:** B00IPHAPG4
- **Special Feature:** Non Stick Coating
- **Color:** Stainless Steel
- **Material:** Stainless Steel
- **Wattage:** 1000 watts
- **Included Components:** Power Cord
- **Style:** Modern
- **Voltage:** 230 Volts
- **Number of settings:** 2

WARRANTY AND SUPPORT

This Sunbeam SS Belgian Waffle Maker comes with **alimited warranty**. For detailed warranty information, product registration, or technical support, please refer to the warranty card included with your purchase or visit the official Sunbeam website. You can also contact Sunbeam customer service for assistance.

For more information, visit the [Sunbeam Store on Amazon](#).



