

[Manuals.plus](#) /

› [Zoomer](#) /

› Zoomer DOG 2.0 Dalmatian Instruction Manual

Zoomer 6024488

Zoomer DOG 2.0 Dalmatian Instruction Manual

Brand: Zoomer

Model: 6024488

INTRODUCTION

Zoomer is a playful, funny, and interactive robotic pet designed to steal your heart. Much like a real dog, Zoomer requires training and interaction to learn new tricks and commands. This manual provides essential information for setting up, operating, and maintaining your Zoomer DOG 2.0 Dalmatian.



Figure 1: The Zoomer DOG 2.0 Dalmatian, a white robot dog with black spots.

WHAT'S INCLUDED

Your Zoomer DOG 2.0 Dalmatian package includes the following items:

- 1 Zoomer DOG 2.0 Dalmatian Interactive Pet Robot
- 1 USB Charging Cable
- 1 Instruction Guide (this manual)
- 1 Reference Guide

SETUP

1. Charging Zoomer

Before first use, ensure Zoomer is fully charged. Locate the charging port on Zoomer's belly. Connect the included USB charging cable to Zoomer and then to a compatible USB power source (e.g., computer USB port, USB wall adapter). The charging indicator light will show the charging status. A full charge typically takes approximately one hour.



Figure 2: Zoomer's underside, revealing the charging port and power switch.

2. Powering On/Off

To power on Zoomer, locate the power switch on its belly, near the charging port. Flip the switch to the 'ON' position. Zoomer will activate and be ready for interaction. To power off, flip the switch back to the 'OFF' position.

OPERATING INSTRUCTIONS

1. Interaction and Commands

Zoomer is designed to respond to your voice and touch. Speak clearly and directly to Zoomer. He understands

commands in English, Spanish, and French. You can teach him various tricks such as 'speak', 'sit', 'lay down', 'rollover', and 'shake a paw'. Reward him with a belly scratch for good behavior, and he will show his excitement by wagging his tail. Zoomer also follows your movement with his expressive puppy eyes, enhancing the interactive experience.



Figure 3: Zoomer ready for interaction.

2. Using the Companion App

For an enhanced training experience, download the free iOS or Android companion app. The app provides additional guidance and tips for teaching Zoomer new tricks and maximizing your interaction.

MAINTENANCE

1. Cleaning

To clean Zoomer, gently wipe the surface with a soft, damp cloth. Do not submerge Zoomer in water or use harsh chemicals, as this can damage the electronic components.

2. Battery Care

Always use the provided USB charging cable to recharge Zoomer. Avoid overcharging. If Zoomer will not be used for an extended period, ensure it is fully charged before storage and periodically recharge it to maintain battery health. Note:

Zoomer provides approximately 20-25 minutes of interactive play per charge and requires approximately one hour for a full recharge.

TROUBLESHOOTING

- **Zoomer is not responding:** Ensure Zoomer is powered on and fully charged. Speak clearly and within close proximity.
- **Zoomer is not moving correctly:** Check that all limbs and wheels are free from obstructions. If Zoomer's ears are detachable, ensure they are securely attached, as they contain sensors vital for proper operation.
- **Charging issues:** Verify that the USB charging cable is properly connected to both Zoomer and the power source. Ensure the charging port is clean and free from debris.
- **Unexpected behavior:** Try turning Zoomer off and then on again to reset its system.

SPECIFICATIONS

Product Dimensions	8.5 x 11.5 x 10.16 inches
Item Weight	1.94 pounds
Model Number	6024488
Recommended Age	5 - 10 years
Power Source	Rechargeable via USB Cable (included)
Manufacturer	Spinmaster

WARRANTY AND SUPPORT

For warranty information or technical support, please contact Spinmaster, the manufacturer of Zoomer DOG 2.0 Dalmatian. Refer to the contact details provided in the separate Reference Guide included with your product.

Important Note: This product is recommended for ages 5 years and older. Adult supervision is advised.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question