Falk 2040N

FALK Claas Pedal Tractor with Excavator and Trailer User Manual

Model: 2040N

1. Introduction

Thank you for choosing the FALK Claas Pedal Tractor with Excavator and Trailer. This product is designed to provide hours of fun and imaginative play for young children, allowing them to transport materials and operate construction equipment just like real professionals. This manual provides important information regarding assembly, operation, maintenance, and safety.



Image 1.1: The FALK Claas Pedal Tractor with front loader, detachable trailer, and rear excavator arm.

2. Safety Information

WARNING: Not suitable for children under 36 months due to small parts and potential hazards. Adult supervision is required at all times.

- Always ensure the child is wearing appropriate safety gear, such as a helmet, when operating the tractor.
- Do not use on public roads, near motor vehicles, or on steep inclines.

- Ensure the play area is clear of obstacles and hazards.
- The maximum weight capacity for this product is 30 kg.
- Regularly inspect the product for any damaged or loose parts before each use.
- Keep hands and feet clear of moving parts, especially the pedals, wheels, and articulated excavator/loader.
- This product is intended for outdoor use on flat, stable surfaces.

3. Package Contents

Before assembly, please ensure all components are present and undamaged. The package should contain:

- Claas Pedal Tractor main body with front loader
- Detachable Trailer
- Articulated Rear Excavator Arm
- Steering Wheel with Horn
- Pedal mechanism
- Various assembly hardware (screws, nuts, washers, pins)
- Instruction manual (this document)

4. Setup and Assembly

Assembly of the FALK Claas Pedal Tractor requires adult supervision and may take some time. Please follow these general steps. Refer to the included pictorial instructions for detailed guidance.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, flat surface. Verify all parts are present against the package contents list.
2. **Attach Wheels:** Securely attach the wheels to the tractor body and trailer using the provided axles, washers, and pins/nuts. Ensure they rotate freely.
3. **Install Pedal Mechanism:** Connect the pedal assembly to the drive mechanism of the tractor. Ensure the chain or belt is properly aligned and tensioned.
4. **Mount Steering Wheel:** Attach the steering column and steering wheel to the tractor's front axle mechanism. Test for smooth steering.
5. **Assemble Front Loader:** Attach the front loader arm and bucket to the designated points on the tractor. Ensure all pivot points are secure.
6. **Assemble Rear Excavator:** Connect the articulated excavator arm to the rear of the tractor. Ensure all joints are secure and the arm moves freely.
7. **Attach Trailer:** Connect the trailer to the hitch point at the rear of the tractor.
8. **Final Inspection:** Before first use, double-check all connections, screws, and moving parts to ensure they are securely fastened and functioning correctly.



Image 4.1: A child interacting with the rear excavator arm, demonstrating its articulated nature.

5. Operating Instructions

The FALK Claas Pedal Tractor is designed for intuitive operation by young children. Adult supervision is always recommended during play.

5.1. Pedaling

- Seat the child comfortably on the tractor seat.
- Instruct the child to place their feet on the pedals.
- To move forward, the child should pedal in a circular motion, similar to a bicycle.
- To move backward, the child can pedal in reverse.

5.2. Steering

- The steering wheel controls the direction of the front wheels.
- Turn the steering wheel left to go left, and right to go right.
- The integrated horn can be pressed for sound effects.



Image 5.1: A child demonstrating the operation of the pedal tractor, including pedaling and steering.

5.3. Front Loader Operation

- The front loader is manually operated.
- Use the handles or levers (if present) to raise, lower, and tilt the bucket.
- Ideal for scooping up light materials like sand, leaves, or small toys.

5.4. Rear Excavator Operation

- The rear excavator arm is fully articulated and manually controlled.
- Use the handles and levers to extend, retract, and pivot the arm and bucket.
- Practice digging and lifting motions with the excavator.



Image 5.2: A child using the rear excavator arm to scoop hay, showcasing its functionality.

5.5. Trailer Use

- The detachable trailer can be used to transport materials collected by the loader or excavator.
- Ensure the trailer is securely attached before use.
- Do not overload the trailer beyond its capacity.

6. Maintenance

Regular maintenance will extend the life of your FALK Claas Pedal Tractor.

- **Cleaning:** Wipe down the tractor with a damp cloth and mild soap. Do not use abrasive cleaners or solvents. Rinse thoroughly and dry.
- **Lubrication:** Periodically check and lubricate moving parts such as the pedal chain/mechanism and wheel axles with a suitable lubricant (e.g., silicone spray).
- **Inspection:** Regularly inspect all screws, nuts, and bolts to ensure they are tight. Check for any cracks or damage to the

plastic components. Replace damaged parts immediately.

- **Storage:** Store the tractor in a dry, sheltered area away from direct sunlight and extreme temperatures to prevent material degradation.

7. Troubleshooting

If you encounter issues with your pedal tractor, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Pedals not moving wheels	Chain/belt dislodged or broken; pedal mechanism jammed.	Check and re-align the chain/belt. Clear any obstructions from the pedal mechanism.
Steering is stiff or unresponsive	Steering column loose; debris in steering mechanism; lack of lubrication.	Tighten steering column connections. Clean out any debris. Apply lubricant to steering pivot points.
Excavator/Loader not moving smoothly	Joints are stiff; debris in joints.	Clean joints and apply lubricant. Check for any bent or damaged parts.
Product unstable or wobbly	Loose wheel nuts; uneven assembly.	Check and tighten all wheel nuts and assembly bolts. Ensure all parts are correctly aligned.

8. Specifications

- **Product Dimensions (L x W x H):** 181 x 42 x 62 cm (71.3 x 16.5 x 24.4 inches)
- **Product Weight:** 10.46 kg (23.06 lbs)
- **Recommended Age:** 24 months - 5 years
- **Maximum Supported Weight:** 30 kg (66 lbs)
- **Main Material:** Plastic
- **Model Number:** 2040N
- **ASIN:** B00IQ6MUW6
- **Educational Value:** Manipulation, Motor Skills, Walking, Running, Movement

9. Warranty and Support

FALK products are manufactured to high standards. While specific warranty details are not provided in this manual, please retain your proof of purchase. For any questions, missing parts, or support needs, please contact FALK customer service or the retailer where you purchased the product. Many retailers offer support for assembly issues or missing components.
We are committed to ensuring your satisfaction with our products.

© 2024 FALK. All rights reserved.
For more information, visit www.falk-toys.com