

[Manuals.plus](#) /

› [Fagor](#) /

› Fagor Oven Door Seal 6H220X Instruction Manual

Fagor NF6837466

Fagor Oven Door Seal 6H220X Instruction Manual

Model: NF6837466

INTRODUCTION

This manual provides essential information for the installation, maintenance, and troubleshooting of your Fagor Oven Door Seal, model 6H220X. Please read these instructions carefully before proceeding to ensure proper function and longevity of the product.

PRODUCT OVERVIEW



Figure 1: Fagor Oven Door Seal (Model 6H220X). This image shows the black rubber seal, designed to fit around the oven door to maintain heat and prevent leaks.

The Fagor Oven Door Seal is an original replacement part designed to ensure optimal thermal insulation and sealing for compatible Fagor oven models. A properly functioning door seal is crucial for maintaining oven temperature, improving energy efficiency, and preventing heat escape during operation.

COMPATIBILITY

This oven door seal is compatible with a wide range of Fagor oven models. Please verify your oven's model number against the list below to ensure compatibility. The model number is typically found on a label inside the oven door frame or on the back of the appliance.

Applicable Models:

- CA7A009A5

- 5H-103 B (90111684)
- 5H-103 B1 (901112077)
- 5H-103 X (90111693)
- 5H-103X1 (901112086)
- 5H-104 B (90111700)
- 5H-104 B1 (901112095)
- 5H-104 N (9011719)
- 5H-104 X (90111728)
- 5H-104 X1 (901112102)
- 5H-105 X (90501112139)
- 5H-113 B1 (901015422)
- 5H-113 N1 (901015431)
- 5H-113 X (901014986)
- 5H-114 B1 (901015440)
- 5H-114 N1 (901015459)
- 5H-114X (901015011)
- 5H-126 X (901112415)
- 5H-16 X (90111862)
- 5H-185B (901015020)
- 5H-185DG EPOC (901015075)
- 5H-185N (901015039)
- 5H-185X (901015048)
- 5H-185H X AUS (901112629)
- 5H-186 X (901112148)
- 5H-196B (901015084)
- 5H-196N (901015093)
- 5H-196X (901015100)
- 5H-196X AUS (901112638)
- 5H-197 AL (901015146)
- 5H-197B (901015119)
- 5H-197N (901015128)
- 5H-197X (901015137)
- 5H-199 BT X (901015379)
- 5H-200LX (901015413)
- 5H-200LX AUS (901112647)
- 5H-200RX (901015404)
- 5H-213B (901111595)
- 5H-213 N (901111602)
- 5H-213X (901111611)
- 5H-215B (901111620)
- 5H-215N (901111639)
- 5H-215X (901111648)
- 5H-285 N (901111666)

- 5H-285B (901111657)
- 5H-385 X (901111960)
- 5H-404 B1 (901112111)
- 5H-404 X1 (901112120)
- 5H-413 B1 (901015468)
- 5H-47 X (901112683)
- 5H-49 X (901111979)
- 5H-51 X (901112442)
- 5H-53X (901112380)
- 5H-54 X (901112399)
- 5H-810X (901015164)
- 5HA-196 X (901111997)
- 5HA-200LX (901112601)
- 5HA-200RX (901112594)
- 5HE-11 B (901112488)
- 5HE-12 X (901112497)
- 6H-103XCN (901010056)
- 6H-113 B (901015565)
- 6H-113 N (901015574)
- 6H-113 AX (901010096)
- 6H-113X (901015583)
- 6H-114AB (901010101)
- 6H-114AN (901010110)
- 6H-114AX (901010129)
- 6H-114B (901015592)
- 6H-114N (901015609)
- 6H-114X (901015618)
- 6H-114X1 (901015618)
- 6H-114X CN (901010057)
- 6H-130W (901112273)
- 6H-130X (901112282)
- 6H-14X (901010011)
- 6H-174BB (901010075)
- 6H-174BN (901010076)
- 6H-174BX (901010084)
- 6H-174BX1 (901010084)
- 6H-175 B (901015627)
- 6H-175 N (901015636)
- 6H-175BB (901010081)
- 6H-175BN (901010082)
- 6H-175BX (901010083)
- 6H-175X (901015645)
- 6H-176 X (901112709)

- 6H-180AB (901010035)
- 6H-180AB1 (901010035)
- 6H-180AWG (901010033)
- 6H-180AX (901010036)
- 6H-180AX1 (901010036)
- 6H-180B (901112503)

INSTALLATION INSTRUCTIONS

Replacing an oven door seal is a straightforward process, but it requires careful handling to avoid damage to the new seal or the oven. Always ensure the oven is cool and disconnected from the power supply before beginning any installation or maintenance.

Tools Required:

- New Fagor Oven Door Seal (Model 6H220X)
- Gloves (optional, for grip)
- Small flat-head screwdriver (for stubborn clips, if applicable)

Procedure:

1. **Disconnect Power:** Before starting, ensure the oven is completely cool and unplugged from the electrical outlet or the circuit breaker is turned off. This is a critical safety step.
2. **Remove Old Seal:** Open the oven door. The old seal is typically held in place by small metal clips or hooks that fit into holes around the oven frame. Gently pull the old seal away from these clips. If it's stuck, a small flat-head screwdriver can be used carefully to pry the clips out, but avoid damaging the oven frame.
3. **Clean the Frame:** Once the old seal is removed, thoroughly clean the channel or area where the seal sits. Remove any food debris, grease, or residue that might prevent the new seal from seating properly. A damp cloth with mild detergent can be used, followed by drying.
4. **Install New Seal:** Begin by locating the corners of the new seal. The Fagor oven door seal is designed to fit snugly. Start by pressing the clips or hooks of the new seal into the corresponding holes in the oven frame, usually starting from the top corners and working your way around. Ensure each clip is fully seated.
5. **Check Fit:** Once installed, gently press along the entire length of the seal to ensure it is uniformly seated and there are no gaps or loose sections. Close the oven door slowly to check for proper compression. The door should close firmly but without excessive force.
6. **Reconnect Power:** After confirming the seal is correctly installed, reconnect the oven to the power supply.
7. **Test:** Perform a quick test by heating the oven to a moderate temperature (e.g., 150°C / 300°F) and observing if any heat escapes around the door. A properly installed seal will prevent significant heat loss.

MAINTENANCE

Regular maintenance of your oven door seal will extend its lifespan and ensure optimal oven performance.

- **Regular Cleaning:** Periodically wipe down the oven door seal with a damp cloth and mild soap to remove food splatters and grease. Avoid abrasive cleaners or harsh chemicals, as these can degrade the rubber material.
- **Inspect for Damage:** Routinely inspect the seal for any signs of wear, tears, cracks, or hardening. A damaged seal will compromise the oven's efficiency and can lead to heat loss.
- **Avoid Pinching:** Be careful not to pinch the seal when closing the oven door, especially if there are oven racks or trays protruding.

TROUBLESHOOTING

If you experience issues after installing the new oven door seal, consider the following common problems and solutions:

Problem	Possible Cause	Solution
Heat escaping from oven door	Seal not properly seated; Seal is twisted or pinched; Incorrect seal for model.	Re-check installation, ensure all clips are secure and seal is not twisted. Verify seal compatibility with your oven model.
Oven door not closing completely	Seal is too thick or improperly installed; Obstruction.	Ensure seal is fully pushed into its channel. Check for any foreign objects preventing the door from closing.
Seal appears loose or sagging	Clips not fully engaged; Seal stretched.	Press firmly on all clips to ensure they are securely in place. If the seal is stretched or damaged, it may need replacement.

SPECIFICATIONS

Attribute	Detail
Brand	Fagor
Model Number	NF6837466 (6H220X)
Part Number	NF6837466
Item Weight	250 g
Manufacturer	FAGOR
ASIN	B00ISX1ALE
Date First Available	25 Jan. 2017

WARRANTY AND SUPPORT

As an original Fagor part, this oven door seal is manufactured to high standards. For specific warranty information, please refer to the documentation provided with your original Fagor oven or contact Fagor customer support directly. Keep your purchase receipt as proof of purchase.

For further assistance or to inquire about other Fagor spare parts, please visit the official Fagor website or contact their authorized service centers.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B00ISX1ALE>

More documents and user manuals: <https://manuals.plus/>