

[Manuals.plus](#) /

› [Mattel](#) /

› Mattel Monster High Freaky Fusion Catacombs Playset Instruction Manual BJR18

Mattel BJR18

Mattel Monster High Freaky Fusion Catacombs Playset Instruction Manual

Model: BJR18

1. PRODUCT OVERVIEW

The Monster High Freaky Fusion Catacombs Playset is a multi-level play environment designed for Monster High dolls (sold separately). This playset features three distinct levels and multiple play spaces, allowing for the display of over 15 dolls. It includes various interactive elements to enhance play.



Image 1.1: The complete Monster High Freaky Fusion Catacombs Playset, showcasing its multi-level design and various play areas.

Included Components:

- Catacombs Playset structure
- 5 Pieces of Furniture
- 14 Accessories (including 2 Lab Tables, Chair, Dining Chairs, Settee Container, Laptop, Textbook, Notebook, Feather Pen, Candelabras, 1 Candle, Skeleton Torches, Bowl, Mug, Magazine, Tray Cupcakes)
- Doll Clips (extra clips for display)

2. SETUP INSTRUCTIONS

The Monster High Freaky Fusion Catacombs Playset requires minimal assembly. Most structural components are

pre-assembled. Follow these steps to prepare the playset for use:

1. **Unpack Components:** Carefully remove all pieces from the packaging. Ensure all listed components are present.
2. **Position the Playset:** Place the main catacombs structure on a flat, stable surface.
3. **Arrange Furniture and Accessories:** Distribute the 5 pieces of furniture and 14 accessories within the playset's various rooms and levels as desired.
4. **Attach Doll Clips:** Utilize the provided doll clips to secure dolls (sold separately) in various positions for display.



Image 2.1: The product packaging, indicating the playset and included items.

3. OPERATING FEATURES

The Catacombs Playset offers several interactive features for dynamic play:

- **Elevator Operation:** Use the elevator to transport dolls between the different levels of the playset. Gently slide the elevator platform up or down to move dolls.



Image 3.1: A doll being moved on the playset's elevator platform.

- **Stairway Access:** Open the decorative gate to reveal a set of stairs, providing an alternative path between levels.



Image 3.2: A doll interacting with the playset's gate, which opens to reveal a staircase.

- **Courtyard Table and Chandelier:** Spin the courtyard table to activate the rotating column, which reveals eerie eyes, and simultaneously illuminates the party chandelier.
- **Pool to Party Scene Transformation:** Flip the pool section to reveal a hidden party scene underneath.



Image 3.3: A hand demonstrating how to flip the pool section to access the hidden party scene.

- **Secret Lab Access:** To gain entry into the secret lab, position the clock hands on the numbers 1 and 3.

Product Video:

Your browser does not support the video tag.

Video 3.4: An official product video demonstrating the features and play possibilities of the Monster High Freaky Fusion Catacombs Playset.

4. MAINTENANCE

To ensure the longevity and cleanliness of your playset, follow these maintenance guidelines:

- **Cleaning:** Wipe the playset surfaces with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these may damage the plastic.
- **Storage:** When not in use, store the playset in a clean, dry environment away from direct sunlight to prevent fading or material degradation.
- **Inspection:** Periodically check all components for any signs of wear or damage. Replace any broken or worn parts if necessary.

5. TROUBLESHOOTING

If you encounter any issues with your playset, consider the following common solutions:

- **Pieces Not Fitting:** Ensure all pieces are oriented correctly according to the visual guides on the product packaging or online images. Do not force pieces together.
- **Feature Malfunction:** If a specific feature (e.g., elevator, spinning table) is not working, check for any obstructions or misalignments. Gently clear any blockages.
- **Missing Components:** If any components are missing upon unboxing, refer to the 'Included Components' list and contact customer support if necessary.

6. SPECIFICATIONS

Brand	Mattel
Model Number	BJR18
Age Range	6 years and up
Item Dimensions	26 x 17 x 16 inches
Item Weight	11.6 Pounds
Number of Pieces	29
Material Type	Plastic
Color	Purple
Assembly Required	No

7. WARRANTY INFORMATION

This product is sold without a manufacturer's warranty. Please refer to the retailer's return policy for any issues regarding product defects or dissatisfaction upon purchase.

8. CUSTOMER SUPPORT

For further assistance or inquiries regarding the Monster High Freaky Fusion Catacombs Playset, please contact Mattel Customer Service through their official website or the retailer from which the product was purchased.