Game Face ASRGTH

Game Face ASRGTH Electric Airsoft Submachine Gun User Manual

Model: ASRGTH

1. Important Safety Information

WARNING: THIS IS NOT A TOY.

Adult supervision is required. Misuse or careless use may cause serious injury, especially to the eye. Eye protection must be used by the user and any person within range. This product may be dangerous up to 100 yards (91.44 meters). Read the owner's manual before using.

Do not brandish or display this airsoft gun in public. It may confuse people and may be a crime. Police and others may think it is a firearm. Do not change the coloration and markings to make it look more like a firearm. That is dangerous and may be a crime.

Buyer and user have the duty to obey all laws about the use and ownership of this airsoft gun.

WARNING: Proposition 65

This product can expose you to chemicals including Lead, which is known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to WWW.P65WARNINGS.CA.GOV.

Recommended for individuals 18 years or older to purchase. Intended for use by those 16 years or older.




Image 1.1: Safety and warning information label.

2. Product Overview

The Game Face ASRGTH Electric Airsoft Submachine Gun is designed for recreational airsoft use, offering both full-automatic and semi-automatic firing modes. This replica model features a durable synthetic construction and an 800-round drum magazine, providing extended play without frequent reloading. It operates on an electric power system, delivering consistent performance.



Image 2.1: Side view of the Game Face ASRGTH Electric Airsoft Submachine Gun.

Key Features:

- **Full/Semi-Automatic Action:** Offers versatile firing modes for different scenarios.
- **Electric Powered:** Provides consistent firing speeds up to 320 feet per second (fps).
- **High-Capacity Drum Magazine:** 800-round capacity for 6mm airsoft BBs (BBs not included).
- **Durable Construction:** Features a synthetic stock and foregrip.

- **Included Accessories:** Comes with a rechargeable battery and battery charger.

3. Package Contents

Upon opening your Game Face ASRGTH package, please verify that all the following items are present:

- Game Face ASRGTH Electric Airsoft Submachine Gun
- 800-Round Drum Magazine
- Rechargeable Battery
- Battery Charger
- Sling Mounts
- User Manual (this document)

4. Setup

4.1. Battery Installation and Charging

1. Locate the battery compartment, typically in the stock of the airsoft gun.
2. Open the compartment cover.
3. Connect the included rechargeable battery to the airsoft gun's internal connector. Ensure the connection is secure.
4. Close the battery compartment cover.
5. Before first use, fully charge the battery using the provided battery charger. Follow the charger's instructions for proper charging times and indicators. Do not overcharge the battery.



Image 4.1: Rear view of the airsoft gun, indicating the battery compartment location.

4.2. Loading BBs into the Drum Magazine

1. Ensure the airsoft gun is on the "SAFE" setting.
2. Remove the drum magazine from the airsoft gun.
3. Locate the BB loading port on the drum magazine.
4. Open the loading port cover and carefully pour 6mm airsoft BBs into the magazine. Do not overfill.
5. Close the loading port cover.
6. Wind the spring mechanism on the drum magazine until resistance is felt. This feeds BBs into the ready position. You may need to wind it periodically during use.
7. Insert the loaded drum magazine firmly into the airsoft gun until it clicks into place.

5. Operating Instructions

5.1. Safety Selector

The safety selector is a critical component for preventing accidental discharge. Always ensure the airsoft gun is on the "SAFE" setting when not actively firing or when handling.

- **SAFE:** Prevents the airsoft gun from firing.
- **SEMI-AUTO:** Fires one BB per trigger pull.
- **FULL-AUTO:** Fires continuously as long as the trigger is held down.



Image 5.1: Close-up view of the airsoft gun's safety selector and firing mode markings.

5.2. Firing the Airsoft Gun

1. Ensure you are wearing appropriate eye protection and are in a safe firing area.
2. Point the airsoft gun in a safe direction.
3. Move the safety selector from "SAFE" to your desired firing mode ("SEMI-AUTO" or "FULL-AUTO").
4. Gently squeeze the trigger to fire.
5. After firing, always return the safety selector to the "SAFE" position.

5.3. Hop-Up Adjustment

The ASRGTH features an adjustable hop-up system to improve accuracy and range. The hop-up applies backspin to the BB, causing it to fly straighter and further. Consult the specific location of the hop-up adjustment dial in your model's diagram (if provided) and adjust incrementally while test firing to achieve optimal trajectory.

6. Maintenance

Regular maintenance ensures the longevity and optimal performance of your Game Face ASRGTH airsoft gun.

6.1. Cleaning

- **Barrel Cleaning:** Use a cleaning rod with a small piece of cloth or paper towel lightly moistened with silicone oil. Gently push through the barrel from the breech end to remove any residue. Do not use petroleum-based lubricants.
- **Exterior Cleaning:** Wipe down the exterior with a clean, damp cloth. Avoid harsh chemicals.

6.2. Lubrication

Apply a small amount of silicone oil to moving parts, such as the magazine release and selector switch, to ensure smooth operation. Avoid applying oil to the hop-up bucking as this can negatively affect performance.

6.3. Storage

- Always store the airsoft gun with the safety engaged and the magazine removed.
- Store in a cool, dry place away from direct sunlight and extreme temperatures.
- Keep out of reach of children and unauthorized users.
- Disconnect the battery if storing for extended periods.

7. Troubleshooting

This section addresses common issues you might encounter with your Game Face ASRGTH airsoft gun.

Problem	Possible Cause	Solution
Airsoft gun does not fire.	Battery is dead or not connected; Safety is engaged; Magazine is empty or not properly inserted.	Charge battery and ensure connection; Disengage safety; Load BBs and insert magazine correctly.
BBs are not feeding.	Magazine not wound; Incorrect BB size; Damaged magazine.	Wind the drum magazine; Use only 6mm airsoft BBs; Inspect magazine for damage.
Low velocity or inconsistent shots.	Low battery; Dirty barrel; Hop-up misadjusted.	Recharge battery; Clean the barrel; Adjust hop-up incrementally.
Airsoft gun jams.	Poor quality BBs; Foreign object in barrel.	Use high-quality, seamless 6mm BBs; Carefully clear barrel obstruction with cleaning rod.

8. Specifications

Brand	Game Face
Model Name	GFSMG Electric, Full or Semi-Auto Submachine Gun
Part Number	ASRGTH
Power Type	Electric, Battery
Caliber	6mm Airsoft BBs
Magazine Capacity	800 Rounds (Drum Magazine)
Max Velocity	Up to 320 fps
Rate of Fire	Up to 300 rounds per minute
Product Dimensions (LxWxH)	25.75" x 3" x 12"
Item Weight	3.3 Pounds
Material	Synthetic (Frame, Stock, Foregrip)
Barrel Material	Plastic
UPC	028478143005

9. Warranty and Support

9.1. Manufacturer's Warranty

This Game Face ASRGTH Electric Airsoft Submachine Gun is covered by a**1 Year Manufacturer's Warranty**. This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims.

9.2. Customer Support

For technical assistance, warranty claims, or inquiries regarding your Game Face product, please visit the official Game Face website or contact their customer service department. Contact information can typically be found on the product packaging or the brand's official website.
For additional resources and product information, you may visit theGame Face Store on Amazon.

© 2025 Game Face. All rights reserved. Information subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question