

[Manuals.plus](#) /

› [Coolaroo](#) /

› Coolaroo Outdoor Roller Shade with Wand - User Manual

Coolaroo 460000

Coolaroo Outdoor Roller Shade with Wand

Model: 460000

INTRODUCTION

The Coolaroo Outdoor Roller Shade with Wand is designed to provide UV protection, heat block, and glare reduction for outdoor living spaces such as patios, porches, and pergolas. It features a smooth operating roller clutch mechanism and durable, UV-stabilized components. The fabric is made from 100% recyclable HDPE, ensuring fade resistance and easy cleaning.



Image: Coolaroo Outdoor Roller Shade in a patio setting, providing shade.

Key Features:

- **UV Block Fabric:** Blocks up to 95% of harmful UV rays, reducing heat and glare.
- **Wand Operated:** Cord-free operation for smooth raising and lowering, enhancing safety.
- **Durable Construction:** UV-stabilized components, aluminum head rail and bottom rail prevent sagging.
- **Fade Resistant:** Engineered to withstand outdoor elements without fading or staining.
- **Easy Clean:** Fabric is simple to clean, maintaining appearance season after season.
- **Safe Materials:** Made from 100% recyclable HDPE, free of lead, phthalates, and harmful toxins.

SAFETY INFORMATION

Please read all safety instructions before installation and use. Failure to follow these instructions may result in injury or product damage.

- Ensure all mounting hardware is securely fastened to a stable surface.
- Do not allow children or pets to play with the shade or its operating wand.
- Avoid hanging heavy objects from the shade.
- In strong winds, it is recommended to retract the shade or secure it with the included tie-downs to prevent damage.
- Do not attempt to modify the shade or its components. Use only original replacement parts if needed.

PACKAGE CONTENTS

Verify that all components are present before beginning installation.

- Coolaroo Outdoor Roller Shade (1)
- Operating Wand (1)
- Mounting Hardware (Brackets, Wood Screws, Wall Anchors)
- Bungees & Receivers (for securing bottom rail)
- User Manual (this document)




Image: All components included in the package, such as brackets, wand, bungees, receivers, and wood screws.

SETUP AND INSTALLATION

This section provides step-by-step instructions for installing your Coolaroo Outdoor Roller Shade. Ensure you have the necessary tools: drill, measuring tape, pencil, and screwdriver.

1. Measure and Mark Mounting Points

Determine the desired location for your shade. For inside mount, measure the width of the opening. For outside mount, ensure sufficient space for the shade to cover the desired area. Mark the positions for the mounting brackets.



Image: A diagram illustrating the overall width and fabric width of the shade, essential for accurate measurement during installation.

2. Install Mounting Brackets

Using a drill, create pilot holes at the marked locations. Secure the mounting brackets using the provided wood screws. If mounting into masonry or drywall, use appropriate wall anchors (not always included, may need to be purchased separately).

3. Mount the Roller Shade

Carefully lift the roller shade and insert it into the installed brackets. Ensure it is securely seated and can roll freely.

4. Install Bottom Rail Tie-Downs (Optional but Recommended)

For added stability and to prevent the shade from swaying in the wind, install the bungee receivers on the posts or wall below the shade. Attach the bungees from the bottom rail of the shade to these receivers.

Your browser does not support the video tag.

Video: A detailed guide on installing and securing outdoor roller shades, demonstrating the process of mounting and using tie-downs for stability.

OPERATING INSTRUCTIONS

The Coolaroo Outdoor Roller Shade is operated using the included wand.

- **To Lower the Shade:** Gently pull down on the wand. The shade will unroll smoothly. Release the wand at the desired height.
- **To Raise the Shade:** Gently push up on the wand. The shade will retract smoothly. Release the wand when the shade is fully retracted or at the desired height.
- The wand is removable for convenience and safety.

MAINTENANCE

Proper care will extend the life and appearance of your Coolaroo Outdoor Roller Shade.

- **Cleaning:** The fabric is easy to clean. Simply spot clean with mild soap and water. For more thorough cleaning, you can hose down the shade. Allow it to air dry completely before retracting.
- **Inspection:** Periodically check the mounting hardware and operating mechanism for any signs of wear or damage. Tighten screws if necessary.
- **Winter Storage:** In areas with harsh winters, it is recommended to retract the shade and store it indoors or cover it to protect it from extreme weather conditions.



Image: A person cleaning the outdoor roller shade using a garden hose, demonstrating the ease of maintenance.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Shade does not roll up or down smoothly.	Obstruction in the mechanism; fabric caught; mechanism dirty.	Check for obstructions. Ensure fabric is aligned. Clean the mechanism if necessary.
Shade sways excessively in light wind.	Bottom rail not secured.	Ensure bungees and receivers are properly installed and connected to the bottom rail.
Mounting brackets feel loose.	Screws have loosened over time.	Tighten all mounting screws. If holes are stripped, relocate brackets or use larger anchors.

SPECIFICATIONS

Brand	Coolaroo
Model Number	460000
Material	Aluminum (head rail/bottom rail), High Density Polyethylene (HDPE) fabric
Product Dimensions	2.44L x 1.83W Meters (183W x 244H cm)
Colour	Pebble
Opacity	Light Filtering (95% UV Block)
Recommended Use	Outdoor (Patio, Porch, Pergola, Window, Door)
Operation Mode	Manual, Cordless (Wand Operated)
Special Features	Fade Resistant, UV Protection, Breathable, Water Resistant
Item Weight	3.63 Kilograms
Included Components	Mounting Hardware, User Manual

WARRANTY INFORMATION

Coolaroo products are manufactured to high-quality standards. For specific warranty details, please refer to the warranty card included with your purchase or visit the official Coolaroo website. Keep your proof of purchase for any warranty claims.

CUSTOMER SUPPORT

If you have any questions, require assistance with installation, or need troubleshooting support, please contact Coolaroo customer service. Contact information can typically be found on the product packaging or the official Coolaroo website. For more information and product registration, visit:www.coolaroo.com

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question