

Nuwave Bravo XL

NUWAVE Bravo XL Air Fryer Convection Toaster Oven with Grill Instruction Manual

Model: Bravo XL

1. INTRODUCTION

The NUWAVE Bravo XL is a versatile countertop appliance designed to simplify your cooking experience. It combines the functions of an air fryer, convection oven, and toaster oven, featuring a smart grill combo for a wide range of culinary tasks. This manual provides essential information for safe and efficient operation of your appliance.

2. SAFETY INFORMATION

Please read all instructions carefully before using the appliance. Keep this manual for future reference.

- Always place the appliance on a stable, heat-resistant surface.
- Ensure adequate ventilation around the unit during operation.
- Do not touch hot surfaces. Use oven mitts or handles.
- Unplug the appliance when not in use and before cleaning.
- Do not immerse the appliance, cord, or plug in water or other liquids.
- Keep children and pets away from the appliance during operation.

3. WHAT'S INCLUDED

Your NUWAVE Bravo XL package includes the following components:

- NUWAVE Bravo XL Air Fryer Toaster Smart Oven
- 1 Non-stick Reversible Grill/Griddle Plate
- 1 Grill/Griddle Rack
- 1 Heavy-duty Wire Cooking Rack
- 1 Crumb Tray
- 1 Smart Digital Thermostat
- 1 Owner's Manual (this document)
- 1 Quick Start Guide

- 1 Recipe Book

Included with the Bravo XL



Cooking Rack

Great for baking pizza, toast, meat and more



Temperature Probe

Adjustable in 5° increments from 50°-500°F



Stainless Steel Rack & Grill/Griddle Plate

Great for steaks, fish, veggies and more



Figure 3.1: Included accessories for the NUWAVE Bravo XL, featuring a cooking rack, temperature probe, and stainless steel rack with grill/griddle plate.

4. SETUP

1. **Unpacking:** Carefully remove all packaging materials, including any protective films or inserts from inside the oven.
2. **Placement:** Place the oven on a flat, stable, heat-resistant countertop. Ensure there is at least 4 inches of clearance on all sides and above the oven for proper ventilation.
3. **Initial Cleaning:** Before first use, wipe down the interior and exterior of the oven with a damp cloth. Wash all accessories (racks, trays, probe) with warm, soapy water, rinse thoroughly, and dry completely.
4. **Power Connection:** Plug the power cord into a grounded electrical outlet.



Figure 4.1: The NUWAVE Bravo XL oven on a countertop, ready for use.

5. OPERATING INSTRUCTIONS

The NUWAVE Bravo XL features intuitive digital controls and a variety of cooking functions.

5.1 Control Panel Overview



Figure 5.1: Digital control panel with preset functions and adjustment knob.

The control panel features a digital display, a central knob for adjustments, and various buttons for specific functions:

- **ON/OFF:** Powers the unit on or off.
- **MENU:** Cycles through main cooking functions (Air Fry, Bake, Broil, Dehydrate, Frozen, Grill, Pizza, Reheat, Roast, Slow Roast, Toast, Yogurt).
- **TEMP/TIME:** Adjusts temperature and cooking time using the central knob.
- **TOP/BTM:** Independently controls top and bottom heating elements.
- **PROBE:** Activates the smart digital thermostat.
- **PREHEAT:** Initiates the preheating cycle.
- **FAN:** Controls the convection fan speed.
- **LIGHT:** Turns the interior oven light on/off.

5.2 Basic Operation

1. **Power On:** Press the ON/OFF button. The display will illuminate.
2. **Select Function:** Use the MENU button to cycle through desired cooking functions. The selected function will flash.

3. **Adjust Settings:** Use the central knob to adjust temperature and time. Press the TEMP/TIME button to toggle between adjusting temperature and time.

4. **Start Cooking:** Press the central knob (START/PAUSE) to begin the cooking cycle.

5.3 Advanced Features

- **Linear Thermal (Linear T) Technology:** The oven continuously monitors temperature fluctuations and makes constant adjustments to maintain the set temperature, ensuring consistent results.
- **Dual Heat Zones:** Customize the top and bottom heaters and convection fan independently. For example, for pizza, set bottom heaters to full power and top heaters to 30% for a crispy crust and melted toppings.
- **Integrated Smart Digital Thermometer:** Insert the probe into your food. Set the desired internal temperature. The oven will automatically end the cooking process when the food reaches the target temperature.
- **Carryover Cooking Mode:** This feature compensates for residual cooking that occurs after the oven turns off, preventing overcooking.
- **Multi-Layer Cooking:** With 4 rack positions and heavy-duty racks, you can cook multiple items simultaneously.
- **112 Presets:** Utilize 12 pre-programmed cooking functions and 100 additional recipe presets for convenience.



Figure 5.2: Illustration of Dual Heat Zone technology for even cooking.



Figure 5.3: Smart Digital Thermometer in use.

5.4 Official Product Videos

The following videos provide further guidance on using your NUWAVE Bravo XL:

Your browser does not support the video tag.

Video 5.4.1: **NuWave Bravo Instructional Video** - A comprehensive guide to operating the NuWave Bravo XL oven, demonstrating its various functions and features.

Your browser does not support the video tag.

Video 5.4.2: **Nuwave Bravo XL Smart Oven** - An overview of the Nuwave Bravo XL Smart Oven, highlighting its smart capabilities and design.

Your browser does not support the video tag.

Video 5.4.3: **Nuwave Bravo XL Grill - No More Guess Work - Full of Flavor** - Demonstrates the grilling capabilities of the Nuwave Bravo XL, focusing on achieving flavorful results.

Your browser does not support the video tag.

Video 5.4.4: **Nuwave Bravo XL Pro for Even Cooking and Pizza** - Highlights the even cooking performance of the Nuwave Bravo XL Pro, particularly for pizza.

Your browser does not support the video tag.

Video 5.4.5: **Nuwave Bravo XL Oven - Grill** - Showcases the combined oven and grill functions of the Nuwave Bravo XL.

6. CLEANING AND MAINTENANCE

Regular cleaning ensures optimal performance and longevity of your NUWAVE Bravo XL.

- **Before Cleaning:** Always unplug the appliance and allow it to cool completely.
- **Interior:** Wipe the interior with a damp cloth and mild detergent. For stubborn stains, use a non-abrasive sponge.
- **Exterior:** Wipe the exterior with a soft, damp cloth. Do not use abrasive cleaners or scouring pads.
- **Crumb Tray:** The removable crumb tray should be emptied and cleaned after each use to prevent grease buildup and odors.
- **Accessories:** The cooking rack, grill/griddle plate, and air fryer basket are dishwasher safe for easy cleaning.

Dishwasher Safe For Accessories



Figure 6.1: Dishwasher safe accessories for convenient cleaning.

7. TROUBLESHOOTING

If you encounter issues with your NUWAVE Bravo XL, refer to the following common troubleshooting tips:

- **Appliance Not Turning On:** Ensure the power cord is securely plugged into a working electrical outlet. Check your circuit breaker.
- **Food Not Cooking Evenly:** Ensure the convection fan is active for even heat distribution. Adjust rack positions as needed. Avoid overcrowding the oven.
- **Temperature Inaccuracy:** Ensure the smart digital thermostat is properly inserted into the food and calibrated according to the manual.
- **Excessive Smoke:** This may be due to food residue or grease buildup. Clean the interior and accessories thoroughly.

For more detailed troubleshooting or persistent issues, please contact customer support.

8. SPECIFICATIONS


Feature	Specification
Brand	Nuwave






Model Name	Nuwave Bravo XL Air Fryer Toaster Smart Oven
Product Dimensions	12.88"D x 20"W x 11.13"H
Interior Depth	12.5"
Color	Brushed Stainless Steel
Control Type	Button Control
Door Style	Dropdown Door
Power Source	Electric
Temperature Range	50-500 Degrees Fahrenheit (adjustable in 5°F increments)
Number of Shelves	4 Rack Positions
Item Weight	17.8 pounds
Special Features	112 One-touch Presets, 50 Memory Slots, 30QT XL Large Capacity, 3X Faster Cooking, 90% Less Oil, Heaters Adjustable From 0-100, Indoor Grill with Original Flavor and Marks, Linear Thermal Technology, Dual Heat Zones, Integrated Smart Digital Thermometer, Carryover Cooking Mode

9. WARRANTY AND SUPPORT

For warranty information, please refer to the documentation included with your product or visit the official Nuwave website. For customer support, please contact Nuwave directly through their official channels.

Related Documents - Bravo XL

 <p>The image shows the cover of the NuWave Brio 3Q Digital Air Fryer Owner's Manual & Recipe Book. It features a red and white design with the NuWave logo at the top left. Below the logo, it says 'NuWave Brio 3Q Digital Air Fryer'. In the center, there is a black air fryer with a basket of golden-brown fries. At the bottom, it says 'Owner's Manual & Complete Recipe Book'. There is also a small circular icon with the word 'RECIPES' inside.</p>	<p>NuWave Brio 3Q Digital Air Fryer Owner's Manual & Recipe Book</p> <p>Comprehensive guide for the NuWave Brio 3Q Digital Air Fryer, covering operation, safety, troubleshooting, and including a full recipe book for healthy cooking.</p>
--	--

	<p>NuWave Brio Healthy Digital 10Q Air Fryer Owner's Manual and Recipe Book</p> <p>Comprehensive guide for the NuWave Brio Healthy Digital 10Q Air Fryer, including operating instructions, safety precautions, maintenance, troubleshooting, and a complete recipe book. Learn how to use your air fryer for optimal results and explore various cooking options.</p>
	<p>NuWave Bravo™ XL Smart Oven: Owner's Manual & Recipe Book</p> <p>Discover the NuWave Bravo™ XL Smart Oven, a versatile kitchen appliance combining air frying, toasting, and convection oven functions. This comprehensive guide includes operating instructions, safety tips, care guidelines, troubleshooting, and a collection of recipes to maximize your cooking experience.</p>
	<p>NuWave Bravo Quickstart Guide: Cooking Instructions and Settings</p> <p>Comprehensive quick start guide for the NuWave Bravo countertop oven, including setup, menu options, and detailed cooking times and temperatures for various foods. Learn how to use your NuWave Bravo for air frying, baking, grilling, and more.</p>
	<p>NuWave Bravo XL Smart Oven Quick Start Guide</p> <p>A quick start guide for the NuWave Bravo XL Smart Oven, detailing its functions, presets, and troubleshooting tips. Includes information on cooking various foods, using combination functions, and understanding oven beeps.</p>
	<p>NuWave Bravo XL Air Fryer/Grill: Quick Start Guide & Troubleshooting (Model 20850)</p> <p>Comprehensive guide for the NuWave Bravo XL Air Fryer/Grill (Model 20850). Includes troubleshooting common issues, detailed button functions, and a complete list of 100 presets with cooking parameters for optimal results.</p>