

[manuals.plus](#) /› [Meliconi](#) /› [Meliconi Personal 2 Plus LG TV Remote Control User Manual](#)

Meliconi Personal 2 Plus (806066)

Meliconi Personal 2 Plus LG TV Remote Control User Manual

INTRODUCTION

The Meliconi Personal 2 Plus is a universal remote control specifically designed for LG digital televisions. This remote is engineered for immediate use without the need for complex programming. Its durable, shockproof rubber body provides enhanced protection against accidental drops and impacts. Beyond standard TV control, it incorporates a 'LEARN' function, allowing it to replicate commands from other infrared devices such as soundbars or home theater systems. For detailed information and support, please refer to the official Meliconi website.



Image: The Meliconi Personal 2 Plus remote control displayed in its retail packaging, highlighting its shockproof feature and compatibility with LG TVs.

1. SETUP

1.1 Battery Installation

The Meliconi Personal 2 Plus remote control requires two AAA batteries (not included). Follow these steps to install them:

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals match the diagrams inside the compartment.
4. Replace the battery compartment cover, sliding it back into place until it clicks securely.

1.2 Initial Use (No Programming Required)

This remote control is pre-programmed for all digital LG televisions and does not require any initial setup or code entry. Once batteries are installed, it is ready for immediate use with your LG TV.

- Point the remote control towards your LG television.
- Press the Power button (**POWER**) to turn on your TV.
- Test other functions like Channel Up/Down (**CH+ / CH-**) and Volume Up/Down (**VOL+ / VOL-**) to confirm functionality.

2. OPERATING INSTRUCTIONS

2.1 Button Functions Overview

The Meliconi Personal 2 Plus remote control features a comprehensive set of buttons for controlling your LG television. Refer to the image below for a visual guide to the button layout and their primary functions.




Image: Detailed diagram of the Meliconi Personal 2 Plus remote control, illustrating the function of each button. Key functions include power, channel navigation, volume control, menu access, and numeric input.

- **Power Button:** Turns the TV on or off.
- **Numeric Keypad (0-9):** For direct channel selection and inputting numbers/letters.
- **Channel Up/Down (CH+/CH-):** Navigates through TV channels.
- **Volume Up/Down (VOL+/VOL-):** Adjusts the TV volume.
- **Mute:** Mutes or unmutes the TV sound.
- **Menu/Settings:** Accesses the TV's main menu or settings.
- **Navigation Buttons (Up, Down, Left, Right, OK):** Used to navigate menus and confirm selections.
- **Source/Input:** Changes the input source (HDMI, AV, etc.).
- **Back/Exit:** Returns to the previous screen or exits a menu.
- **Guide:** Displays the electronic program guide (EPG).
- **Text/Teletext:** Activates or deactivates teletext functions (if supported by TV).
- **Color Buttons (Red, Green, Yellow, Blue):** Used for specific functions within menus or interactive services.

2.2 LEARN Function

The remote control includes a 'LEARN' function, allowing it to acquire and store functions from other infrared remote controls. This is useful for consolidating control of multiple devices (e.g., a soundbar or home theater system) onto your Meliconi remote.

Note: Specific instructions for activating and using the LEARN function are typically found on the manufacturer's website or in the detailed product manual. Generally, the process involves placing the two remotes head-to-head and pressing corresponding buttons to transfer the signal.

3. MAINTENANCE

3.1 Cleaning the Remote Control

To maintain the remote control's appearance and functionality, clean it regularly:

- Use a soft, dry cloth to wipe the surface of the remote.
- For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid excessive moisture.
- Do not use harsh chemicals, solvents, or abrasive cleaning pads, as these can damage the remote's finish or internal components.

3.2 Battery Replacement

Replace the batteries when the remote control's response becomes sluggish or stops working. Low battery power can also reduce the remote's operating range.

- Follow the battery installation steps outlined in Section 1.1.
- Always replace both batteries at the same time with new AAA alkaline batteries.
- Dispose of used batteries responsibly according to local regulations.

4. TROUBLESHOOTING

Problem	Possible Cause	Solution
Remote control does not work.	Dead or incorrectly installed batteries.	Check battery polarity and replace with fresh AAA batteries.
Remote control has short range or intermittent response.	Low battery power; Obstruction between remote and TV; Infrared sensor on TV is blocked.	Replace batteries. Ensure a clear line of sight to the TV's infrared sensor. Remove any obstructions.
Specific buttons do not work.	Button stuck or damaged; TV does not support the function.	Gently press the button multiple times. If the button is physically damaged, contact support. Confirm your TV supports the function.
LEARN function not working.	Incorrect learning procedure; Original remote's signal is weak.	Refer to the detailed LEARN function instructions on the Meliconi website. Ensure original remote has fresh batteries and is held correctly.

5. SPECIFICATIONS

- **Brand:** Meliconi
- **Model Name:** Gumbody Personal 2 Plus (806066)
- **Color:** Black/Anthracite
- **Connectivity Technology:** Infrared
- **Special Feature:** No programming needed, Shockproof rubber body, LEARN function
- **Compatible Devices:** LG Televisions
- **Maximum Number of Supported Devices:** 1 (with LEARN function for additional IR devices)
- **Number of Buttons:** 25
- **Controller Type:** Button Control
- **Maximum Range:** 10 Meters
- **Batteries Required:** 2 AAA batteries

6. WARRANTY INFORMATION

Meliconi products are designed for reliability and durability. For specific warranty terms and conditions applicable to your region, please refer to the warranty card included with your product or visit the official Meliconi website. Keep your proof of purchase for warranty claims.

7. SUPPORT

7.1 Web Support

For comprehensive support, including detailed instructions, FAQs, and the latest product information, please visit the official Meliconi website:

www.cme.it

The website offers resources such as button-to-function correspondence tables and guides for advanced features like the LEARN function.

7.2 Technical Assistance

For direct technical assistance, Meliconi provides dedicated support. Please refer to the contact information provided on the official website or in your product packaging for the most up-to-date phone numbers and service hours.