

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

- › [Acce2S](#) /
- › Acce2S SFR 1180 Micro USB Wall Charger Instruction Manual

Acce2S SFR 1180

Acce2S SFR 1180 Micro USB Wall Charger Instruction Manual

Model: SFR 1180 | Brand: Acce2S

1. INTRODUCTION

This manual provides essential instructions for the safe and efficient use of your Acce2S Micro USB Wall Charger, designed for the SFR 1180 device. This charger delivers 1000 mAh of power, enabling faster charging even during intensive device usage.

2. SAFETY INFORMATION

Please read all safety instructions before using the charger. Failure to follow these instructions may result in electric shock, fire, or damage to the product or connected devices.

- Do not expose the charger to water, moisture, or extreme temperatures.
- Do not attempt to disassemble, repair, or modify the charger.
- Ensure the wall outlet voltage matches the charger's specifications (100-240V).
- Unplug the charger from the wall outlet when not in use or during electrical storms.
- Keep out of reach of children.
- Do not use if the cable or plug is damaged.

3. PACKAGE CONTENTS

- 1 x Acce2S Micro USB Wall Charger (SFR 1180 compatible)

4. SETUP

Follow these steps to set up your charger:

1. Locate a standard wall power outlet (100-240V).
2. Plug the charger's AC prongs into the wall outlet.
3. Connect the Micro USB connector end of the charger cable into the charging port of your SFR 1180 device.



Figure 1: Overview of the Acce2S Micro USB Wall Charger. This image shows the compact black charger unit with its integrated cable and Micro USB connector, ready for use.

5. OPERATING INSTRUCTIONS

Once connected, the charger will automatically begin charging your device. A charge indicator light on the charger unit will illuminate to confirm power delivery.

- The 1000 mAh output ensures efficient and rapid charging for your SFR 1180.
- The charger is designed to provide full power even when your device is in active use (e.g., Bluetooth, internet connection).
- Disconnect the charger from your device once charging is complete to conserve energy.



Figure 2: Close-up view of the Micro USB connector. This image highlights the specific Micro USB plug, which is compatible with the SFR 1180 device.

6. MAINTENANCE AND CARE

- Clean the charger with a dry, soft cloth. Do not use liquid cleaners or aerosols.
- Store the charger in a cool, dry place when not in use.
- Avoid bending or twisting the cable excessively to prevent damage.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Device not charging.	Charger not properly plugged into wall outlet.	Ensure the charger is securely plugged into a working wall outlet.
	Micro USB connector not fully inserted into device.	Verify the Micro USB connector is firmly seated in the device's charging port.
	Damaged cable or charger.	Inspect the cable and charger for visible damage. Discontinue use if damaged.
Charging is slow.	Device is in heavy use during charging.	While the charger supports charging during use, closing unnecessary applications can optimize charging speed.

8. SPECIFICATIONS

- **Brand:** Acce2S
- **Model:** SFR 1180 (Compatible Device)
- **Input:** 100-240V, 50/60Hz, 5W, 100mA
- **Output:** 5.0V, 1000mA (1A)
- **Connector Type:** Micro USB
- **Certifications:** CE, RoHS
- **Power Source:** Electrical Cord

9. WARRANTY AND SUPPORT

Specific warranty details are not provided in the product information. For warranty claims, technical support, or further assistance, please contact the manufacturer, Acce2S, directly or refer to the product packaging for contact information.

