

[Manuals.plus](#) /

› [Bella](#) /

› Bella Mini Donut Baking Maker Instruction Manual

Bella Mini Donut Baking Maker

Bella Mini Donut Baking Maker Instruction Manual

Model: Mini Donut Baking Maker (ASIN: B00IZHO2KY)

INTRODUCTION AND SAFETY INFORMATION

Thank you for purchasing the Bella Mini Donut Baking Maker. This appliance is designed for baking mini donuts quickly and efficiently. Please read this instruction manual thoroughly before first use to ensure safe operation and optimal performance. Keep this manual for future reference.

Important Safety Precautions

- Read all instructions before operating the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.

SETUP AND FIRST USE

1. **Unpacking:** Carefully remove the Mini Donut Baking Maker from its packaging. Retain the packaging for storage or

disposal.

2. **Initial Cleaning:** Before first use, wipe the non-stick baking plates with a damp cloth or sponge. Dry thoroughly. The exterior of the appliance can be wiped with a damp cloth. Do not immerse the appliance in water.
3. **Placement:** Place the appliance on a stable, heat-resistant, and dry surface, away from the edge of the counter. Ensure there is adequate ventilation around the unit.
4. **Power Connection:** Ensure the appliance is unplugged. The Bella Mini Donut Baking Maker operates on 110 Volts (DC). Plug the power cord into a standard electrical outlet.



Image: The Bella Mini Donut Baking Maker (purple) with donuts on its non-stick plates, alongside its packaging.

OPERATING INSTRUCTIONS

1. **Preheating:** Close the lid and plug the appliance into a wall outlet. The indicator light will illuminate, signaling that the unit is preheating. Once the light turns off (or changes color, depending on the model), the donut maker has reached its optimal baking temperature. This typically takes 3-5 minutes.
2. **Preparing Batter:** While the unit preheats, prepare your favorite mini donut batter. For best results, use a batter that is not too thin.
3. **Baking Donuts:**
 - Carefully open the lid. Lightly grease the non-stick baking plates with cooking spray or a small amount of oil, if desired, though the non-stick coating generally prevents sticking.
 - Pour or spoon approximately 1 tablespoon of batter into each donut cavity. Do not overfill, as the batter will expand.
 - Close the lid. Do not force the lid shut.
 - Bake for 3-5 minutes, or until the donuts are golden brown and cooked through. Baking time may vary depending on the batter consistency and desired crispness.
4. **Removing Donuts:** Once baked, carefully open the lid. Use a heat-resistant, non-metallic utensil (such as a wooden or silicone spatula) to gently remove the donuts from the cavities. Do not use metal utensils, as they can damage the non-stick coating.

- 5. **Continuous Baking:** If baking multiple batches, close the lid between batches to maintain temperature. Repeat steps 3 and 4.
- 6. **Finishing:** When finished baking, unplug the appliance from the wall outlet and allow it to cool completely before cleaning and storage.

CLEANING AND MAINTENANCE

Proper cleaning and maintenance will extend the life of your Bella Mini Donut Baking Maker.

- 1. **Unplug and Cool:** Always unplug the appliance from the power outlet and allow it to cool completely before cleaning.
- 2. **Cleaning Baking Plates:** Once cooled, wipe the non-stick baking plates with a damp cloth or sponge. For stubborn residue, a small amount of mild dish soap can be used. Avoid abrasive cleaners or scouring pads, as these can damage the non-stick surface.
- 3. **Cleaning Exterior:** Wipe the exterior of the appliance with a soft, damp cloth. Do not use harsh chemicals or abrasive materials.
- 4. **Do Not Immerse:** Never immerse the Mini Donut Baking Maker, its cord, or plug in water or any other liquid.
- 5. **Storage:** Ensure the appliance is clean and dry before storing. Store it in a cool, dry place. The cord can be wrapped around the base for compact storage.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; power outlet malfunction.	Ensure the power cord is securely plugged into a working electrical outlet. Check the circuit breaker.
Donuts are sticking to the plates.	Plates not properly greased; residue buildup; damaged non-stick coating.	Lightly grease plates with cooking spray or oil before each batch. Ensure plates are clean. Avoid using metal utensils.
Donuts are not cooking evenly or are undercooked.	Not preheated sufficiently; too much batter; incorrect cooking time.	Allow the appliance to fully preheat until the indicator light signals readiness. Do not overfill cavities. Adjust baking time as needed.
Smoke or unusual odor during first use.	Protective oils burning off.	This is normal for first use. Ensure good ventilation. If smoke persists after initial use, unplug and contact customer support.

SPECIFICATIONS

- Brand:** Bella
- Model:** Mini Donut Baking Maker
- ASIN:** B00IZHO2KY
- Special Feature:** Non Stick Coating

Color: Purple

Material: Aluminum

Product Dimensions: 6.88"D x 3.54"W x 6.88"H

Included Components: Donut Mold

Voltage: 110 Volts (DC)

Item Weight: 5.04 pounds

WARRANTY AND SUPPORT

Warranty information is not provided in the product details. For specific warranty terms or customer support, please refer to the product packaging or contact Bella customer service directly.

© 2023 Bella. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B00IZHO2KY>

More documents and user manuals: <https://manuals.plus/>