

Viega 83151

Viega Visign for Style 10 Flush Plate Instruction Manual

Model: 83151

1. INTRODUCTION

This manual provides essential information for the proper installation, operation, and maintenance of your Viega Visign for Style 10 Flush Plate, Model 83151. Please read these instructions carefully before installation and retain them for future reference. This product is designed for use with specific Viega concealed cisterns and urinal carriers.

2. SAFETY INFORMATION

Always observe the following safety precautions:

- Ensure all water supply lines are shut off before beginning installation.
- If you are unsure about any part of the installation process, consult a qualified plumber.
- Do not use abrasive cleaners or solvents on the flush plate, as this may damage the plastic finish.
- Keep small parts away from children to prevent choking hazards.

3. PACKAGE CONTENTS

Verify that all components are present before beginning installation:

- Viega Visign for Style 10 Flush Plate (Alpine White)

Note: Additional components for the concealed cistern or urinal carrier are sold separately.

4. SETUP AND INSTALLATION

The Viega Visign for Style 10 Flush Plate is designed for easy installation with compatible Viega systems.

4.1 Compatibility

This flush plate is compatible with the following Viega concealed cisterns:

- Concealed cistern
- 2L Concealed cistern
- 2C Concealed cistern
- Concealed cistern standard 2S (model 8180.26)

It can also be used with the Viega Eco Plus urinal carrier Model 8164.5US.

4.2 Installation Steps

1. Ensure the concealed cistern or urinal carrier is correctly installed according to its specific instructions.
2. Carefully align the flush plate with the mounting frame of the cistern/carrier.
3. Secure the flush plate using the provided screws or attachment mechanism. The handle attachment mechanism is screw-based.
4. Verify that the flush actuation rods are correctly engaged with the cistern's flushing mechanism.
5. Test the flush function to ensure proper operation.



Figure 1: Viega Visign for Style 10 Flush Plate in Alpine White. This image shows the rectangular plastic flush plate designed for manual actuation from the front.

5. OPERATING INSTRUCTIONS

The Viega Visign for Style 10 Flush Plate provides manual flush actuation from the front.

- To activate a flush, press the designated flush buttons on the plate.
- The plate typically features two buttons for dual-flush cisterns (full flush and half flush), allowing for water conservation. Refer to your cistern's manual for specific flush volumes.

6. MAINTENANCE

To ensure the longevity and appearance of your flush plate, follow these maintenance guidelines:

- **Cleaning:** Clean the flush plate regularly with a soft, damp cloth and mild soap.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, scouring pads, or chemical solvents, as these can scratch or damage the plastic surface.
- **Inspection:** Periodically check the flush plate for any signs of looseness or damage. Tighten screws if necessary.

7. TROUBLESHOOTING

If you encounter issues with your flush plate, consider the following common solutions:

- **Flush Not Actuating:**
 - Check if the flush rods are correctly connected to the cistern's mechanism.
 - Ensure the flush plate is securely mounted and not obstructing the buttons.
- **Flush Plate is Loose:**
 - Tighten the mounting screws that secure the flush plate to the frame.
- **Buttons Sticking:**
 - Clean around the buttons to remove any debris or residue.
 - Ensure the flush plate is not overtightened, which could cause binding.

If problems persist, contact Viega customer support or a qualified plumber.

8. SPECIFICATIONS

Feature	Specification
Model Number	83151
Material	Plastic
Color	Alpine White
Product Dimensions (L x W x H)	10.67"L x 0.51"W x 5.512"H
Item Weight	10.83 ounces
Handle Type	Flush Plate
Actuation	Manual, from front
Indoor/Outdoor Usage	Indoor
Additional Features	Easy to Install

9. WARRANTY AND SUPPORT

Viega offers a **10-year warranty** on its flush plates, reflecting the product's quality and reliability. For warranty claims or technical support, please contact Viega customer service through their official website or the contact information provided with your purchase documentation.

For further assistance, please visit the official Viega website or consult your local plumbing professional.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question