

[Manuals.plus](#) /

› [REVLON](#) /

› Revlon RVST2084F Ceramic Tourmaline Flat Iron User Manual

REVLON RVST2084FN3

Revlon RVST2084F Ceramic Tourmaline Flat Iron User Manual

Model: RVST2084FN3

1. INTRODUCTION

This manual provides comprehensive instructions for the safe and effective use of your Revlon RVST2084F Ceramic Tourmaline Flat Iron. Please read all instructions before use and retain this manual for future reference. This flat iron is designed to help you achieve sleek, straight hair with ease, featuring ceramic-coated plates and multiple heat settings suitable for various hair types.



Figure 1: Revlon RVST2084F Ceramic Tourmaline Flat Iron

2. IMPORTANT SAFETY INFORMATION

To reduce the risk of burns, electrocution, fire, or injury to persons, always follow these basic safety precautions:

- **Burn hazard:** Surfaces get extremely hot during use. Avoid contact with skin.
- **Electric shock risk:** Keep away from water. Do not use near bathtubs, sinks, or other water sources.
- **Fire risk:** Unplug when not in use. Do not leave unattended when plugged in.
- Keep out of reach of children.
- Do not use this appliance with a voltage converter.
- Always unplug the appliance immediately after use.
- Never block the air openings of the appliance or place it on a soft surface, such as a bed or couch, where the air openings may be blocked.
- Never use while sleeping.

- Never drop or insert any object into any opening.
- Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.
- Do not use an extension cord with this appliance.

3. PRODUCT FEATURES

The Revlon RVST2084F Ceramic Tourmaline Flat Iron is engineered with advanced features for optimal hair styling:

- **Ceramic Tourmaline Coating:** Helps reduce damage from over-styling by providing even heat distribution. This coating also boosts shine and helps minimize frizz.
- **1-Inch Plates:** Ideal for creating sleek, straight styles and can also be used for gentle waves.
- **30 Heat Settings:** Offers precise temperature control to suit all hair types, from fine to thick.
- **Fast Heat-Up:** Quickly reaches desired temperature for efficient styling.
- **True Grip Plates:** Designed to eliminate gaps, ensuring smooth gliding through hair without snagging.
- **High Heat, Constant Heat Sensors:** Monitors temperature to maintain consistent heat levels for effective styling.
- **Dual Voltage:** Suitable for international travel (requires appropriate adapter, not included).
- **Tangle-Free Swivel Cord:** Provides flexibility and ease of use, preventing cord tangles during styling.
- **Silicone Finger Grips:** Enhances comfort and control during use.



Tourmaline Ceramic Coating

because we care
about your hair as
much as you do.
Boosts shine and
helps reduce damage
from overstyling with
even heat distribution
making styling safe,
fast, and easy.

©2021 Helen of Troy. All rights reserved.

Figure 2: Tourmaline Ceramic Coating for reduced damage and enhanced shine.

30 Heat Settings
precise control for
all hair types.



©2021 Helen of Troy. All rights reserved.

Figure 3: Adjustable dial for 30 precise heat settings.



©2021 Helen of Troy. All rights reserved.

Figure 4: Key features and components of the flat iron.

4. SETUP AND FIRST USE

1. **Unpack:** Carefully remove the flat iron from its packaging. Ensure all components are present and undamaged.
2. **Inspect:** Before each use, inspect the appliance for any signs of damage, especially the cord and plates. Do not use if damaged.
3. **Placement:** Place the flat iron on a heat-resistant surface, away from water and flammable materials.
4. **Plug In:** Insert the plug into a suitable electrical outlet. The appliance is dual voltage, but ensure the outlet voltage is compatible.
5. **Power On:** Locate the ON/OFF switch (refer to Figure 4) and slide it to the 'ON' position.
6. **Select Temperature:** Adjust the temperature dial (refer to Figure 3) to your desired heat setting. Start with a lower setting for fine or damaged hair and increase as needed for thicker or coarser hair.
7. **Heat Up:** Allow the flat iron to heat up. The indicator light will typically stop flashing or change color when the

desired temperature is reached.

5. OPERATING INSTRUCTIONS

Preparing Your Hair:

- Ensure your hair is clean, dry, and free of tangles.
- Apply a heat protectant spray evenly throughout your hair to minimize heat damage.
- Section your hair into manageable portions, approximately 1-2 inches wide, using clips.

Straightening Your Hair:

1. Take one section of hair and place it between the heated plates, close to the roots.
2. Gently clamp the plates together, ensuring even pressure.
3. Slowly glide the flat iron down the hair section from root to tip. Do not hold the iron in one place for too long to avoid heat damage.
4. Repeat the process on the same section if necessary, but typically one or two passes are sufficient due to the efficient heat transfer.
5. Continue with the remaining sections of hair until your desired style is achieved.

Creating Waves/Curls:

The rounded edges of the flat iron allow for versatile styling, including waves and curls.

1. Take a section of hair and clamp the flat iron near the roots.
2. Rotate the flat iron 180 degrees away from your face.
3. Slowly glide the iron down the hair shaft, maintaining the rotation.
4. Release the hair and allow the curl to cool before touching it to set the style.

6. MAINTENANCE

1. **Cleaning:** Ensure the appliance is unplugged and completely cool before cleaning. Wipe the plates and exterior with a soft, damp cloth. Do not use abrasive cleaners or immerse the appliance in water.
2. **Storage:** Unplug the appliance and allow it to cool completely. The flat iron features a locking mechanism to keep the plates closed for compact storage. Store in a dry, safe place, out of reach of children. Do not wrap the cord around the appliance, as this can damage the cord.
3. **Cord Care:** Regularly inspect the cord for any damage. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent, or similarly qualified persons to avoid a hazard.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in, power switch off, or power outlet issue.	Ensure the appliance is securely plugged into a working outlet. Check the ON/OFF switch. Test the outlet with another device.
Appliance not heating up.	Temperature setting too low, or internal malfunction.	Increase the temperature setting. If the issue persists, contact customer support.

Problem	Possible Cause	Solution
Hair is snagging or pulling.	Hair is not properly detangled, or plates are not clean.	Ensure hair is thoroughly brushed and detangled before styling. Clean the plates as per maintenance instructions.
Hair not straightening effectively.	Temperature too low, or sections of hair are too large.	Increase the temperature setting. Work with smaller, thinner sections of hair. Ensure hair is completely dry.

8. SPECIFICATIONS

Model Number: RVST2084FN3

Plate Material: Ceramic Tourmaline

Plate Size: 1 Inch

Heat Settings: 30

Max. Temperature: 400°F (204°C)

Voltage: Dual Voltage (120V/240V)

Power Source: Corded Electric

Color: Black

Item Weight: 485 g

Product Dimensions: 14.61 x 6.99 x 33.02 cm

Manufacturer: Helen of Troy (for REVLON)

Country of Origin: China

9. WARRANTY AND SUPPORT

For warranty information, product registration, or customer support, please refer to the warranty card included with your purchase or visit the official Revlon Hair Tools website. Keep your proof of purchase for any warranty claims.

© 2024 Revlon. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question