

[Manuals.plus](#) /

› [Thule](#) /

› Thule TCBP-417 Crossover 32 L Backpack Instruction Manual

Thule TCBP-417

Thule TCBP-417 Crossover 32 L Backpack Instruction Manual

INTRODUCTION

This manual provides comprehensive instructions for the Thule TCBP-417 Crossover 32 L Backpack. Designed for durability and organization, this backpack offers dedicated protection for electronics and ample space for your essentials. Please read through this guide to understand the features and proper use of your new backpack.

KEY FEATURES

- Padded, zippered laptop compartment holds up to a 15" MacBook Pro/PC and a tablet.
- Water-resistant fabrics and zippers combine to create a lightweight, protective bag.
- The Shove-it Pocket with compression straps provides additional external storage for a jacket or newspaper.
- Multiple grab-and-go handles allow for easy transport.
- Organization compartment keeps cords and other accessories at hand but out of the way.

PRODUCT OVERVIEW

The Thule TCBP-417 Crossover 32 L Backpack is designed for versatility and protection. It features multiple compartments and durable construction to keep your belongings secure and organized.



Figure 1: Front view of the Thule TCBP-417 Crossover 32 L Backpack, showcasing its sleek design and main zippered compartments.



Figure 2: Detailed view of the open front organization compartment, featuring various pockets and elastic loops for accessories, cords, and small items.

SETUP

Adjusting Shoulder Straps

1. Place the backpack on your back.

2. Loosen all straps.
3. Pull the bottom ends of the shoulder straps to tighten them until the backpack sits comfortably on your back, with the weight evenly distributed.
4. Adjust the sternum strap (if present) for added stability and comfort across your chest.

Utilizing Grab-and-Go Handles

The backpack features multiple grab-and-go handles. Use these handles for quick lifting, carrying, or when placing the backpack in overhead compartments or tight spaces.

OPERATING

Laptop and Tablet Compartment

Locate the padded, zippered compartment designed for electronics. Carefully slide your 15-inch MacBook Pro/PC and tablet into their respective sleeves within this compartment. Ensure zippers are fully closed to secure devices.

Organization Compartment

The front organization compartment is ideal for smaller items. Use the various pockets and elastic loops to store pens, notebooks, chargers, cables, and other accessories, keeping them easily accessible and tangle-free.

Shove-it Pocket

The Shove-it Pocket, located externally, provides quick access storage. Utilize the compression straps to secure items like a jacket, newspaper, or other gear that needs to be readily available.

Water Resistance

The backpack is constructed with water-resistant fabrics and zippers. While it offers protection against light rain and splashes, it is not fully waterproof. Avoid prolonged exposure to heavy rain or submersion to protect contents.

MAINTENANCE

Cleaning Instructions

- **Hand Wash Only:** Do not machine wash, tumble dry, iron, or dry clean the backpack.
- Use a soft brush or cloth with mild soap and cool water to clean soiled areas.
- Rinse thoroughly with cool water.
- Air dry the backpack completely before storing or reusing it. Avoid direct sunlight or heat sources.

Storage

Store the backpack in a cool, dry place away from direct sunlight when not in use. Ensure it is clean and completely dry before storage to prevent mold or mildew.

TROUBLESHOOTING

The Thule TCBP-417 Crossover 32 L Backpack is designed for reliability. No specific troubleshooting steps are typically required for this product. If you encounter any issues with zippers, straps, or fabric integrity, please refer to the warranty information.

SPECIFICATIONS

Feature	Detail
Model Number	32019911
Storage Volume	32 liters
Item Dimensions (D x W x H)	12.2"D x 12.4"W x 18.5"H
Item Weight	1 kg
Color	Black
Material Type	Nylon (Dobby nylon fabric)
Water Resistance Level	Water Resistant
Compatible Device Size Maximum	15 inches (for laptop)
Number of Compartments	6
Number of Pockets	7
Strap Type	Shoulder Strap
Recommended Uses	Leisure, Sport
Care Instructions	Hand Wash Only

WHAT'S IN THE BOX

- 1 x Thule TCBP-417 Crossover 32 L Backpack

WARRANTY AND SUPPORT

The Thule TCBP-417 Crossover 32 L Backpack comes with a**limited lifetime warranty**. For detailed warranty terms, claims, or product support, please visit the official Thule website or contact their customer service directly.
Official Thule Website: www.thule.com

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B00J3IRI14>

More documents and user manuals: <https://manuals.plus/>