

Remington H5600H

Remington H5600H Ionic Conditioning Hair Setter User Manual

Model: H5600H

1. IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, especially when children are present, basic safety precautions should always be followed, including the following:

- **DANGER** - As with most electrical appliances, electrical parts are electrically live even when the switch is off. To reduce the risk of death by electric shock:
 - Always unplug this appliance from the electrical outlet immediately after using.
 - Do not use while bathing or in a shower.
 - Do not place or store this appliance where it can fall or be pulled into a tub or sink.
 - Do not place in or drop into water or other liquid.
 - Do not reach for an appliance that has fallen into water. Unplug it immediately.
- **WARNING** - To reduce the risk of burns, electrocution, fire, or injury to persons:
 - This appliance should never be left unattended when plugged in.
 - Close supervision is necessary when this appliance is used by, on, or near children or individuals with certain disabilities.
 - Use this appliance only for its intended use as described in this manual. Do not use attachments not recommended by the manufacturer.
 - Never operate this appliance if it has a damaged cord or plug, if it is not working properly, or if it has been dropped or damaged, or dropped into water.
 - Keep the cord away from heated surfaces. Do not wrap the cord around the appliance.
 - Never use while sleeping.
 - Never drop or insert any object into any opening.
 - Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.
 - Do not use an extension cord with this appliance.
 - This appliance is hot when in use. Do not let eyes or bare skin touch heated surfaces.
 - Do not place the heated unit directly on any surface while it is operating or cooling.

2. PRODUCT OVERVIEW

The Remington H5600H Ionic Conditioning Hair Setter is designed to create long-lasting curls with reduced frizz and enhanced shine. It features 20 velvet rollers with a thermal wax core for consistent heat retention and includes color-coded J-clips for secure placement.



Image: The Remington H5600H Hair Setter with its lid open, displaying the 20 velvet rollers in various sizes and colors.

Key Components:

- **20 Velvety Rollers:** Includes 6 large (1 1/4"), 10 medium (1"), and 4 small (3/4") rollers.
- **Thermal Wax Core:** Each roller contains a wax core designed to retain high heat for extended periods, contributing to durable curls.
- **Ionic Conditioning:** The rollers incorporate ionic conditioning to help reduce frizz and increase hair shine.
- **Color-Coded J-Clips:** Specially designed clips to secure rollers in place with minimal creasing.
- **Ready Indicator Light:** Illuminates when rollers have reached the optimal temperature for use.
- **Cool Touch Ends:** Designed for comfortable handling during use.



3 Color Coded Clips

& ROLLER SIZES ($\frac{3}{4}$ ", 1", & 1 $\frac{1}{4}$ ")

Image: A close-up view of the various sized rollers and the accompanying J-clips, illustrating the color-coding.

EXCLUSIVE

Thermal Wax Core

ALLOWS THE ROLLER TO RETAIN HIGH HEAT LONGER



Image: A cross-section of a roller, highlighting the internal thermal wax core responsible for heat retention.



Exclusive J-Clips

SPECIALLY DESIGNED TO SECURELY HOLD
THE ROLLER WITHOUT DENTS OR CREASES

Image: A detailed view of the exclusive J-clips, designed to hold rollers securely without leaving creases.

3. SETUP

1. Place the hair setter on a flat, heat-resistant surface.
2. Ensure the unit is unplugged before placing rollers into the heating wells.
3. Plug the Remington Ionic Conditioning Hair Setter into a standard electrical outlet.
4. The ready indicator light will illuminate once the rollers have reached the optimal temperature for styling. This typically takes several minutes.

4. OPERATING INSTRUCTIONS

Preparation:

- Ensure hair is clean, dry, and free of tangles.
- For best results, apply a heat protectant spray evenly through your hair.

Applying Rollers:

1. Once the ready indicator light is on, carefully remove a heated roller from the unit, holding it by its cool-touch ends.

2. Choose the appropriate roller size for your desired curl: large rollers for looser curls and volume, medium for classic curls, and small for tighter curls or shorter hair sections.
3. Take a section of hair that is no wider than the roller.
4. Place the roller at the end of the hair section and roll upwards towards the scalp.
5. Secure the roller in place using a color-coded J-clip, ensuring the clip holds the roller firmly against the scalp without creasing the hair.
6. Repeat this process until all desired sections of hair have rollers.

Setting and Removal:

1. Allow the rollers to cool completely in your hair. This typically takes 10-20 minutes, depending on hair type and desired curl intensity. The longer the rollers remain in, the more defined and long-lasting the curls will be.
2. Gently remove the J-clips, then carefully unroll each roller from your hair. Avoid pulling or tugging.
3. Once all rollers are removed, allow your curls to cool for a few minutes before styling. This helps to set the curls.
4. Style your hair as desired, using your fingers or a wide-tooth comb to gently separate curls for a softer look.




Image: A woman with styled, shiny, and frizz-free curly hair, illustrating the benefits of ionic conditioning.

5. MAINTENANCE

Cleaning:

- Always unplug the hair setter and allow it to cool completely before cleaning.
- Wipe the exterior of the unit with a damp cloth. Do not immerse the unit in water.
- To clean the rollers, gently wipe them with a damp cloth. Ensure they are completely dry before storing or reusing.
- Remove any hair strands or product residue from the rollers and heating wells regularly.

Storage:

- Store the appliance in a cool, dry place.
- Do not wrap the cord around the appliance. This can cause premature wear and breakage of the cord.
- Keep out of reach of children.

6. TROUBLESHOOTING

- **Rollers not heating:** Ensure the unit is properly plugged into a functioning electrical outlet. Check if the power switch is on. Allow sufficient time for the rollers to heat up (the ready indicator light should illuminate).
- **Curls not holding:** Ensure hair is completely dry before applying rollers. Allow rollers to cool completely in hair before removal. For longer-lasting curls, use a styling product before rolling and a light hairspray after styling.
- **Hair frizzes after styling:** Ensure rollers are fully heated. The ionic conditioning feature helps reduce frizz; ensure hair is not over-dried or damaged. Consider using a leave-in conditioner or anti-frizz serum.
- **Rollers leaving creases:** Ensure J-clips are applied correctly, securing the roller without pinching the hair too tightly at the base. The J-clips are designed to minimize creasing.

7. SPECIFICATIONS

Feature	Detail
Model Number	H5600H
Roller Quantity	20 (6 Large, 10 Medium, 4 Small)
Roller Sizes	Large: 1¼" (Pink), Medium: 1" (Purple), Small: ¾" (White)
Roller Material	Velvet-flocked, Ceramic-coated
Core Technology	Thermal Wax Core
Conditioning	Ionic Conditioning
Clips	Color-Coded J-Clips
Product Dimensions	6.5 x 9.4 x 5.4 inches
Item Weight	2.6 Pounds
Manufacturer	Remington

Feature	Detail
UPC	074590534337

8. WARRANTY AND SUPPORT

Warranty Information:

This Remington H5600H Ionic Conditioning Hair Setter comes with **atwo-year limited warranty** from the date of purchase. Please retain your proof of purchase for warranty claims. The warranty covers defects in materials and workmanship under normal use.

Customer Support:

For product support, troubleshooting assistance, or to inquire about warranty service, please visit the official Remington website or contact their customer service department. You can also find more information and products on the [Remington Store on Amazon](#).