

Manuals.plus /

- › Ronson /
- › Ronson Multi-Fill Ultra Butane Fuel 1.48oz (42g) Instruction Manual

## Ronson Multi-Fill Ultra Butane Fuel

# Ronson Multi-Fill Ultra Butane Fuel 1.48oz (42g) Instruction Manual

Your guide to safe and effective use of Ronson Butane Fuel.

## 1. PRODUCT OVERVIEW

The Ronson Multi-Fill Ultra Butane Fuel is designed for refilling various butane-powered devices, including lighters, igniters, soldering torches, and curling wands. Each can contains 1.48 ounces (42 grams) of high-quality butane, featuring universal fueling tip adapters for broad compatibility.



Image: A box containing 12 cans of Ronson Multi-Fill Ultra Butane Fuel. The packaging highlights "NOW OVER 10% MORE BUTANE" and "UNIVERSAL FUELING TIP ADAPTS TO REFILLABLE BUTANE LIGHTERS, IGNITERS, SOLDERING TORCHES AND CURLING WANDS."

## 2. SAFETY INFORMATION

**DANGER: EXTREMELY FLAMMABLE. CONTENTS UNDER PRESSURE.**

- Keep away from heat, sparks, open flames, and hot surfaces. No smoking.
- Do not puncture or incinerate container.

- Do not expose to temperatures exceeding 120°F (49°C).
- Use only in a well-ventilated area.
- Do not inhale contents. Intentional misuse by deliberately concentrating and inhaling the contents can be harmful or fatal.
- Keep out of reach of children.
- Wear appropriate personal protective equipment (PPE) such as gloves and eye protection when handling.

### 3. SETUP AND REFILLING INSTRUCTIONS

---

Before refilling, ensure your device is compatible with butane fuel and locate its refill valve. Most devices have a small valve at the bottom.

1. **Prepare the Area:** Work in a well-ventilated area, away from any ignition sources.
2. **Prepare the Device:** If your device has a flame adjustment, set it to the lowest setting. If it has any residual gas, gently press the refill valve with a small tool (like a pen tip) to release any air or remaining fuel until no more gas escapes. This helps prevent air pockets.
3. **Invert the Can:** Hold the Ronson Multi-Fill Ultra Butane Fuel can upside down.
4. **Insert Nozzle:** Firmly press the nozzle of the butane can directly onto the refill valve of your device. You may hear a hissing sound, which indicates the fuel is transferring.
5. **Refill:** Hold for approximately 5-10 seconds, or until the fuel begins to overflow or the device's fuel window indicates it is full. Avoid overfilling.
6. **Remove Can:** Carefully remove the butane can from the device's valve.
7. **Wait:** Allow the device to rest for at least 2-3 minutes after refilling. This allows the butane to stabilize and reach room temperature, which is crucial for proper ignition.

### 4. OPERATING YOUR DEVICE AFTER REFILL

---

After following the refilling instructions and allowing the fuel to stabilize:

- Ensure the flame adjustment (if present) is set to your desired level.
- Attempt to ignite the device as per its manufacturer's instructions.
- If the device does not ignite immediately, wait another minute and try again.

### 5. MAINTENANCE AND STORAGE

---

Proper maintenance and storage ensure the longevity of your butane fuel and safety.

- **Storage:** Store Ronson Multi-Fill Ultra Butane Fuel in a cool, dry, and well-ventilated area. Keep it away from direct sunlight, heat sources, and any potential ignition sources.
- **Cap Security:** Always ensure the red cap is securely replaced on the can after each use to prevent accidental discharge or contamination.
- **Disposal:** Dispose of empty cans according to local regulations for pressurized containers. Do not puncture or incinerate.

### 6. TROUBLESHOOTING

---

If you encounter issues after refilling your device:

- **Device Not Igniting:**
  - **Insufficient Fuel:** Re-check if the device is fully refilled. Some devices may require a longer refill time.
  - **Air Pockets:** Air can get trapped in the fuel tank during refilling. Purge the air by holding the device upside down and pressing the refill valve with a small tool until a steady stream of gas (not liquid) escapes. Repeat the refilling process.
  - **Insufficient Wait Time:** Ensure you have waited at least 2-3 minutes after refilling for the butane to stabilize.
  - **Flame Adjustment:** Verify that the flame adjustment on your device is not set too low.
- **Leaking During Refill:** Ensure the butane can nozzle is pressed firmly and straight onto the device's refill valve. A loose connection can cause leakage.
- **Weak Flame:** This could indicate low fuel, air in the tank, or a clogged burner nozzle on your device. Try purging air and refilling, or consult your device's manual for cleaning instructions.

## 7. SPECIFICATIONS

---

- **Product:** Ronson Multi-Fill Ultra Butane Fuel
- **Brand:** Ronson
- **Model:** Multi-Fill Ultra Butane Fuel
- **Contents:** Butane
- **Net Weight (per can):** 1.48 oz (42 g)
- **Features:** Universal fueling tip adapters
- **ASIN:** B00JB2PTYK