

[Manuals.plus](#) /

› [Citizen](#) /

› User Manual: Citizen Eco-Drive Super Titanium Men's Watch - AW1251-51E

Citizen AW1251-51E

Citizen Eco-Drive Super Titanium Men's Watch

Model: AW1251-51E

1. INTRODUCTION

This manual provides essential information for the proper use, care, and maintenance of your Citizen Eco-Drive Super Titanium Men's Watch, Model AW1251-51E. Please read this manual thoroughly to ensure optimal performance and longevity of your timepiece.





Figure 1: Front view of the Citizen Eco-Drive Super Titanium Men's Watch AW1251-51E, showcasing its black dial and silver titanium band.

The Citizen Eco-Drive technology harnesses the power of light from any natural or artificial source and converts it into energy, eliminating the need for battery replacement. This watch features a durable Super Titanium case and band, a black dial, and is designed for everyday wear.

2. SETUP AND INITIAL CHARGING

Your Eco-Drive watch is powered by light. Upon receiving your watch, it may not be running or may be running with an insufficient charge.

2.1 Initial Charging

To ensure proper operation, expose the watch dial to direct sunlight or bright artificial light for several hours. The watch will begin to operate once it receives sufficient light. For a full charge, expose the watch to direct sunlight for approximately 11 hours or to fluorescent light (30W, 20 inches away) for about 50 hours.

- Avoid placing the watch too close to a light source, as this may cause the watch to overheat and malfunction.
- Do not charge the watch in high-temperature environments (e.g., on a car dashboard).

2.2 Setting the Time and Date

1. Pull the crown out to the first click for date adjustment, or to the second click for time adjustment.
2. Turn the crown to set the desired time or date.
3. Push the crown back into the normal position.



Figure 2: Side view of the watch, highlighting the crown for time and date adjustments.

3. OPERATING YOUR ECO-DRIVE WATCH

The Eco-Drive system ensures continuous operation by converting light into electrical energy. This energy is stored in a power cell, allowing the watch to function even in the dark for extended periods once fully charged.

3.1 Power Reserve

On a single full charge, your Citizen Eco-Drive watch can run for over six months, even if stored in complete darkness.

3.2 Understanding Eco-Drive Technology

For a visual explanation of how Citizen Eco-Drive technology works, please watch the official video below:

Your browser does not support the video tag.

Video 1: An official video explaining the Citizen Eco-Drive technology and how it converts light into energy to power the watch.

4. MAINTENANCE AND CARE

4.1 Cleaning Your Watch

To maintain the appearance of your watch, wipe the case and band regularly with a soft, dry cloth. For titanium bands, a slightly damp cloth can be used, followed by a dry cloth. Avoid using chemical cleaners or abrasive materials.

4.2 Water Resistance

This watch has a water resistance depth of 50 meters. This rating means it is suitable for short periods of recreational swimming, but not for diving or snorkeling. Ensure the crown is pushed in completely before any contact with water.

4.3 Storage

When not wearing your watch, store it in a location where it can receive light periodically to maintain its charge. If storing for an extended period, ensure it is fully charged to prevent the power cell from depleting.



Figure 3: The watch is typically supplied in a protective box, suitable for storage.

5. TROUBLESHOOTING

5.1 Watch Not Running or Stopping Frequently

This is typically an indication of insufficient charge. Expose the watch to bright light for an extended period (refer to Section 2.1).

5.2 Time or Date Incorrect

Adjust the time and date manually using the crown (refer to Section 2.2). Ensure the watch has sufficient charge before setting.

5.3 Condensation Inside the Crystal

If condensation appears inside the watch crystal and does not dissipate quickly, it may indicate a seal issue. Contact Citizen customer support or an authorized service center immediately.

6. SPECIFICATIONS

Feature	Detail
Model Number	AW1251-51E
Dial Color	Black
Case Shape	Round
Dial Glass Material	Sapphire
Band Color	Silver
Band Material	Titanium
Watch Movement Type	Light Powered (Eco-Drive)
Watch Display Type	Analog
Case Material	Titanium
Water Resistance Depth	50 meters
Case Diameter	37 Millimetres
Item Weight	380 g



Figure 4: Rear view of the watch, showing the case back and titanium bracelet with clasp.

7. WARRANTY AND SUPPORT

7.1 Warranty Information

This Citizen watch comes with a **1 Year International Guarantee**. Please retain your proof of purchase for warranty claims. The warranty covers manufacturing defects under normal use. It does not cover damage resulting from improper handling, accidents, or unauthorized repairs.

7.2 Customer Support

For further assistance, service, or inquiries regarding your Citizen watch, please visit the official Citizen website or contact an authorized Citizen service center in your region.

You can find more information and support on the [Citizen Store on Amazon](#).

© 2024 Citizen Watch Co., Ltd. All rights reserved.
This manual is for informational purposes only.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B00JBUK9JC>

More documents and user manuals: <https://manuals.plus/>