

## Tupperware I57

# Tupperware Microwave Pasta Master 1.9 L

## USER MANUAL

### Product Overview

The Tupperware Microwave Pasta Master is designed for convenient and efficient cooking of pasta in a microwave oven. With a capacity of 1.9 liters, it allows for easy preparation of various pasta types, offering a simple and clean cooking method without the need for a stovetop.



Image: The Tupperware Microwave Pasta Master in purple, with its lid slightly ajar, revealing cooked pasta inside.

## Important Safety Information

- Do not exceed 800 watts when using the Microwave Pasta Master in a microwave oven. Higher wattage may damage the product or cause overflow.
- Do not add oil, grease, butter, milk, or other fatty liquids to the water when cooking pasta. These substances can cause overheating and damage to the product or microwave.
- Always ensure the lid is properly aligned for draining, but not sealed during cooking, to allow steam to escape.
- Use caution when handling the product after microwaving, as it will be hot. Use oven mitts or heat-resistant gloves.

## Setup and First Use

1. Before first use, wash the Tupperware Microwave Pasta Master and its lid thoroughly with warm soapy water.
2. Rinse all components completely and dry them.
3. Inspect the product for any damage. Do not use if damaged.

## Operating Instructions

### Cooking Pasta

1. **Add Pasta:** Place the desired amount of pasta into the Microwave Pasta Master. Refer to the markings inside the container for suggested serving sizes (e.g., 1, 3, or 5 servings).
2. **Add Water:** Fill the container with cold water up to the corresponding water level marking for your chosen pasta quantity. Ensure the pasta is fully submerged.



Image: An interior view of the Tupperware Microwave Pasta Master, highlighting the embossed markings for water levels

corresponding to 1, 3, and 5 servings of pasta.

3. **Microwave:** Place the Microwave Pasta Master, without its lid, into the microwave oven. Cook at a maximum of 800 watts. The cooking time will vary depending on the type of pasta and your microwave's power. Generally, microwave for the time indicated on your pasta packaging plus an additional 3-5 minutes. For best results, check pasta for desired doneness.
4. **Drain Water:** Once cooking is complete, carefully remove the hot container from the microwave. Place the lid onto the container, aligning the draining slots with the container's opening. Tilt the container to drain the hot water through the slots.



Image: A visual guide showing the process of using the pasta cooker: first, adding pasta; second, adding water; and third, using the lid to drain the water.

5. **Serve:** Once drained, the pasta is ready to be served. You can use the lid as a base for the container while serving.



Image: The Tupperware Microwave Pasta Master with its lid securely closed, resting on the inverted lid which serves as a stable base.

## Maintenance and Care

- The Tupperware Microwave Pasta Master is dishwasher safe. Place it on the top rack of your dishwasher for cleaning.
- Alternatively, wash by hand with warm water and mild dish soap.
- Avoid using abrasive cleaners or scouring pads, as these can scratch the plastic surface.
- Ensure the product is completely dry before storing.

## Troubleshooting

### Problem: Water overflows during cooking.

**Solution:** Ensure you are not exceeding the recommended water fill lines for the amount of pasta. Also, verify that your microwave's wattage does not exceed 800 watts. Overfilling or excessive wattage can cause boiling over. Make sure the lid is not sealed during cooking, allowing steam to escape.

### Problem: Pasta is not cooked evenly or is too hard/soft.

**Solution:** Adjust cooking time. Microwave ovens vary in power, and pasta types require different cooking durations. Start with the recommended time on the pasta package plus 3-5 minutes, then adjust in 1-minute increments until desired doneness is achieved. Ensure pasta is fully submerged in water.

**Problem: Product appears discolored or damaged after use.**

**Solution:** This can occur if fatty liquids (oils, butter, milk) were added to the water, or if the microwave wattage exceeded 800 watts. Always adhere to the safety guidelines. If the product is damaged, discontinue use.

## Specifications

<b>Brand</b>	Tupperware
<b>Model</b>	I57
<b>Capacity</b>	1.9 Liters
<b>Dimensions (L x W x H)</b>	11.77" x 6.06" x 4.65"
<b>Material</b>	Plastic
<b>Color</b>	Purple
<b>Microwave Safe</b>	Yes (Max 800 watts)
<b>Dishwasher Safe</b>	Yes
<b>Item Weight</b>	0.29 Kilograms (10.2 ounces)

## Warranty and Support

Specific warranty details for the Tupperware Microwave Pasta Master are not provided within this manual. For warranty claims, product support, or further inquiries, please refer to the official Tupperware website or contact Tupperware customer service directly.

You may find additional information by visiting the [Tupperware Store on Amazon](#).

© 2024 Tupperware. All rights reserved.

Documents - Tupperware – I57

no relevant documents