



Manuals.plus /

› Melitta /

› Melitta Aromaboy 1015-03 Compact Filter Coffee Maker User Manual

Melitta 1015-03

Melitta Aromaboy 1015-03 Compact Filter Coffee Maker User Manual

Model: 1015-03 | Brand: Melitta

INTRODUCTION

This manual provides comprehensive instructions for the safe and efficient operation, maintenance, and troubleshooting of your Melitta Aromaboy 1015-03 Compact Filter Coffee Maker. Please read this manual thoroughly before first use and retain it for future reference.

The Melitta Aromaboy 1015-03 is designed for brewing up to two cups of filter coffee, featuring a compact design, optimal brewing temperature, and a 30-minute keep-warm function.



Image: Melitta Aromaboy 1015-03 Compact Filter Coffee Maker, showing its overall design and components.

IMPORTANT SAFETY INSTRUCTIONS

To reduce the risk of fire, electric shock, and/or injury, basic safety precautions should always be followed

when using electrical appliances. Please observe the following:

- Read all instructions carefully before operating the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against fire, electric shock, and personal injury, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner. Contact customer service for examination, repair, or adjustment.
- The use of accessory attachments not recommended by the appliance manufacturer may result in fire, electric shock, or personal injury.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.

PRODUCT COMPONENTS

Familiarize yourself with the parts of your Melitta Aromaboy coffee maker:

- **Water Tank:** Located on the side, with clear markings for water levels (up to 2 cups / 0.3L).
- **Filter Holder:** Removable component where the coffee filter and ground coffee are placed.
- **Glass Carafe:** Borosilicate glass carafe for collecting brewed coffee.
- **Heating Plate:** Keeps the brewed coffee warm for up to 30 minutes.
- **On/Off Switch:** Illuminated switch to power the appliance on or off.
- **Lid:** Covers the water tank and filter holder area.



Image: Side view of the Melitta Aromaboy, highlighting the water tank with level indicators and the illuminated On/Off switch.

SETUP

1. **Unpack:** Carefully remove all packaging materials and labels from the coffee maker.
2. **Initial Cleaning:** Before first use, clean the glass carafe and removable filter holder with warm, soapy water. Rinse thoroughly.
3. **First Brew Cycle (without coffee):** Fill the water tank to the MAX (2 cups) level with fresh cold water. Place the empty carafe on the heating plate. Turn on the coffee maker and let it complete a full brewing cycle. Discard the water. This cleans the internal components and removes any manufacturing residues.
4. **Placement:** Place the coffee maker on a stable, level, heat-resistant surface, away from the edge of the counter. Ensure there is adequate ventilation around the appliance.
5. **Power Connection:** Plug the power cord into a suitable electrical outlet (230 Volts).

OPERATING INSTRUCTIONS

Follow these steps to brew a fresh cup of coffee:

1. **Fill Water Tank:** Open the lid and fill the water tank with fresh, cold water. The tank has markings for up to 2 cups (0.3 Liters). Do not exceed the 'MAX' level.
2. **Insert Filter:** Place a Melitta size 100 paper filter into the removable filter holder.
3. **Add Coffee Grounds:** Add your desired amount of ground coffee into the paper filter. A general guideline is one level tablespoon of coffee per cup, but adjust to your personal taste.
4. **Position Carafe:** Ensure the glass carafe is correctly placed on the heating plate beneath the filter holder.
5. **Start Brewing:** Close the lid and press the illuminated On/Off switch. The light will indicate that the brewing process has started.
6. **Serving:** Once brewing is complete, the coffee maker will automatically switch to a keep-warm mode for approximately 30 minutes. You can serve the coffee during this period.
7. **Auto Shut-off:** The appliance will automatically turn off after the 30-minute keep-warm cycle. If you wish to turn it off sooner, press the On/Off switch again.



Image: Front view of the Melitta Aromaboy, showing the filter holder and glass carafe in position for brewing.

CLEANING AND MAINTENANCE

Regular cleaning ensures optimal performance and extends the lifespan of your coffee maker.

Daily Cleaning:

- Always unplug the coffee maker and allow it to cool completely before cleaning.
- Remove the used paper filter and discard coffee grounds.
- The glass carafe and the removable filter holder are dishwasher safe. Alternatively, wash them by hand with warm, soapy water and rinse thoroughly.
- Wipe the exterior of the coffee maker with a soft, damp cloth. Do not use abrasive cleaners or scouring pads.
- Never immerse the main unit (with electrical components) in water or any other liquid.

Descaling:

Mineral deposits from water can build up over time, affecting brewing performance and coffee taste. Descale your coffee maker regularly, depending on water hardness and frequency of use.

- Use a commercially available descaling solution suitable for coffee makers, following the manufacturer's instructions.
- Alternatively, a solution of white vinegar and water (1:2 ratio) can be used.
- Run a brewing cycle with the descaling solution.
- After descaling, run at least two full cycles with fresh, clean water to rinse out any residual descaling agent.

TROUBLESHOOTING

If you encounter issues with your coffee maker, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Coffee does not brew.	No power; water tank empty; carafe not correctly placed.	Check power connection and On/Off switch. Fill water tank. Ensure carafe is properly seated on the heating plate.
Coffee tastes weak or too strong.	Incorrect coffee-to-water ratio; coffee too coarse/fine; old coffee.	Adjust coffee amount. Use fresh, medium-ground coffee.
Coffee overflows from filter holder.	Too much coffee grounds; filter clogged; carafe not in place.	Reduce coffee amount. Ensure filter is not collapsed. Check carafe position. Descale if necessary.
Appliance leaks.	Carafe not positioned correctly; water tank overfilled; component damage.	Ensure carafe is correctly placed. Do not overfill water tank. Inspect for cracks or damage; contact support if found.
Coffee is not hot enough.	Heating plate issue; descaling needed.	Ensure the coffee maker has completed its brewing cycle. Descale the appliance.

TECHNICAL SPECIFICATIONS

- **Brand:** Melitta
- **Model Number:** 1015-03
- **Color:** Brown
- **Dimensions (L x W x H):** 12.8 x 16.8 x 19.8 cm (5.04 x 6.61 x 7.8 inches)
- **Weight:** 789.25 grams (1.74 lbs)
- **Water Tank Capacity:** 0.3 Liters (for 2 cups)
- **Power:** 500 Watts
- **Voltage:** 230 Volts
- **Material:** Plastic
- **Automatic Shut-off:** Yes
- **Special Features:** Keep-warm function (30 minutes), Illuminated On/Off switch, Removable filter holder, Dishwasher-safe carafe and filter holder.
- **Filter Compatibility:** Melitta Size 100

WARRANTY AND SUPPORT

Specific warranty details for your Melitta Aromaboy 1015-03 coffee maker are typically provided with the product packaging or can be found on the official Melitta website. Please refer to these resources for information regarding warranty coverage, terms, and conditions.

For technical support, spare parts, or any other inquiries, please contact Melitta customer service. Contact information can usually be found on the Melitta website or in the documentation included with your product.

Always retain your proof of purchase for warranty claims.