Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Nerf FBA_A6563F01

Nerf Zombie Strike SlingFire Blaster Instruction Manual

Introduction

This manual provides essential instructions for the safe and proper use of your Nerf Zombie Strike SlingFire Blaster. Please read this manual thoroughly before assembly and operation to ensure correct usage and to prevent injury.



Image: The Nerf Zombie Strike SlingFire Blaster, six darts, and a dart clip are shown in their product packaging.

Package Contents

Verify that all items listed below are included in your package:

- 1 Nerf Zombie Strike SlingFire Blaster
- 1 Six-dart clip
- 6 Zombie Strike darts
- 1 Instruction Manual



Image: The Nerf Zombie Strike SlingFire Blaster, a six-dart clip, and six green Zombie Strike darts are displayed.

Setup

Loading the Dart Clip

To load the dart clip, insert the included Zombie Strike darts into the clip until they are securely seated. Ensure darts are inserted correctly to prevent jamming.

Video: A person demonstrates how to load darts into the six-dart clip for the Nerf Zombie Strike SlingFire Blaster.

Inserting the Clip

Align the loaded dart clip with the blaster's magazine well and push it firmly until it clicks into place.

Customizing with Tactical Rail Accessories

The SlingFire Blaster features a Tactical Rail system. You can attach compatible Nerf accessories (sold separately) to this rail to enhance your blaster.



Image: A close-up view highlights the black tactical rail located on the top of the green Nerf SlingFire Blaster.

Operating Instructions

Cocking the Blaster

The SlingFire Blaster can be cocked in two ways:

1. **Lever-Action Cocking:** Hold the blaster firmly. Use your non-firing hand to pull the lever down and then push it back up until it locks into place. This action primes the blaster for firing.
2. **One-Handed Flick Cocking:** For rapid action, hold the blaster with one hand and flick your wrist to swing the lever down and back up, priming the blaster. Practice this motion for smooth operation.



Image: A person demonstrates pulling the lever down on the Nerf SlingFire Blaster to cock it.



Image: A person holds the Nerf SlingFire Blaster, preparing to cock the lever mechanism.

Firing the Blaster

Once the blaster is cocked, aim at your target and pull the trigger to fire a dart.





Image: A person aims the Nerf Zombie Strike SlingFire Blaster forward, ready to fire.

Maintenance

Keep the blaster clean and free from dirt or debris. Do not use damaged darts, as they can cause jamming. Store the blaster and darts in a dry, cool place.
Do not modify the blaster or darts. Modifications can impair performance and safety.

Troubleshooting

Darts are not firing or are jamming:

- Ensure the dart clip is fully inserted and locked into place.
- Verify that the blaster is fully cocked. The lever must be pulled down and pushed back up completely.

- Check for any bent or damaged darts in the clip or firing mechanism. Remove and replace damaged darts.
- Ensure no foreign objects are obstructing the dart path.

Lever mechanism feels stiff:

- Ensure the blaster is not jammed.
- Operate the lever several times without darts to loosen the mechanism. If stiffness persists, contact customer support.

Specifications

Feature	Detail
Model Number	FBA_A6563F01
Brand	Nerf
Age Recommendation	8 years and up
Operation Mode	Manual
Dart Capacity	6 darts (clip included)
Special Features	Lever-action blasting, 2-way cocking mechanism, Tactical Rail
Material	Plastic
Dimensions	2.01 x 7.52 x 26.5 inches
Weight	1 Pound

Note: Accessories for the Tactical Rail are sold separately.

Safety Information

WARNING: Do not aim at eyes or face. Use only official NERF darts. Other darts may not meet safety standards. Do not modify darts or blaster.
CAUTION: Small parts may be generated. Not for children under 3 years. Adult supervision recommended.

Warranty and Support

For warranty information or customer support, please refer to the contact details provided on the product packaging or visit the official Nerf website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00JMCJI0U

More documents and user manuals: **https://manuals.plus/**