**ASUS ME181C-A1-BK**

# ASUS MeMO Pad 8 ME181C-A1-BK Tablet User Manual

Model: ME181C-A1-BK

Introduction Setup Operating Instructions Key Features Maintenance Troubleshooting Specifications Warranty & Support

## 1. Introduction

This manual provides essential information for setting up, operating, and maintaining your ASUS MeMO Pad 8 ME181C-A1-BK tablet. The ASUS MeMO Pad 8 is an 8-inch touch screen tablet featuring an Intel Bay Trail processor, 1GB RAM, 16GB internal storage, and runs on Android 4.4 Kit Kat. It includes a 2MP front camera and a 5MP rear camera, along with Bluetooth 4.0 connectivity. Designed for portability and performance, this tablet offers a versatile mobile computing experience.





*Figure 1: ASUS MeMO Pad 8 ME181C-A1-BK Tablet (Black)*

## 2. Setup

### 2.1. Initial Charging

Before first use, fully charge your ASUS MeMO Pad 8 using the provided power adapter and USB cable. Connect the USB cable to the tablet's charging port and the adapter to a power outlet. The battery indicator on the screen will show charging status.

### 2.2. Powering On/Off

- To power on: Press and hold the Power button until the ASUS logo appears.
- To power off: Press and hold the Power button, then select "Power off" from the options.

### 2.3. Initial Configuration

### 2.3. Initial Configuration

Upon first startup, follow the on-screen prompts to configure your tablet. This includes selecting your language, connecting to a Wi-Fi network, setting up your Google account, and configuring date and time settings.

### 2.4. Inserting a MicroSD Card

The ASUS MeMO Pad 8 supports MicroSD cards for expanded storage. Locate the MicroSD card slot on the side of the tablet. Gently insert the card until it clicks into place. Ensure the tablet is powered off before inserting or removing the card to prevent data corruption.

## 3. Operating Instructions

The ASUS MeMO Pad 8 features the ASUS ZenUI, an exclusive software suite designed to enhance your Android experience with a simple, clear user interface and advanced functions. The following sections detail some of its key functionalities.

### 3.1. ZenUI Overview

Your browser does not support the video tag.

*Video 1: ASUS ZenUI Features Overview. This video demonstrates the core functionalities and user interface of ASUS ZenUI, including "What's Next," "Omlet Chat," "Open Cloud," "Do It Later," and "Share Link."*

### 3.2. What's Next

"What's Next" is a feature that keeps you informed of upcoming events and tasks. It provides timely reminders for commitments and items on your to-do list, and can even notify you of appointment changes or unexpected cancellations. This feature helps you stay organized by presenting an informative timeline of your schedule.

### 3.3. Omlet Chat Messenger

The Omlet Chat Messenger app allows you to easily share various types of content, such as photos, videos, and messages, with friends and family, regardless of the device they are using. It integrates with your email and calendar, enabling you to send out event invitations with a simple tap.

### 3.4. Open Cloud & File Management

ZenUI's "Open Cloud" feature allows you to access all your files from various cloud storage services, including Dropbox, OneDrive, Google Drive, and ASUS WebStorage. This centralizes your cloud files, making them accessible directly from your tablet. Additionally, ASUS notebooks, desktop PCs, and motherboards often come with Home Cloud software, turning their internal storage into a personal cloud accessible via Open Cloud.

### 3.5. Do It Later

The "Do It Later" function helps you prioritize and organize tasks. It can remind you to return unanswered calls or reply to emails and texts. When you are ready to resume a task, a simple tap on your task list brings you back to exactly where you left off, ensuring continuity in your workflow.

### 3.6. Share Link

ASUS ZenLink, including "Share Link," seamlessly integrates information across all your devices. This feature allows for easy and fast sharing of photos, videos, contact information, and more between your ASUS devices.

### 3.7. Customization: Color Theme

ASUS ZenUI offers customizable color themes, allowing you to personalize your user interface. You can match the UI theme with the color of your device, and with interchangeable back covers (if applicable to your specific model), you can change the look of your tablet to suit your personality or mood.

## 4. Key Features

- **Operating System:** Android 4.4 Kit Kat
- **Display:** 8-inch Touch Screen
- **Processor:** Intel Bay Trail, 1.33 GHz Intel Atom
- **Memory:** 1 GB RAM, 16 GB Internal Storage
- **Cameras:** 2MP Front Camera, 5MP Rear Camera
- **Connectivity:** Bluetooth 4.0, 802.11bgn Wireless Type
- **Battery Life:** Up to 9-10 hours (average)
- **Weight:** Approximately 11.2 ounces (0.7 pounds)
- **Dimensions:** 8.3 x 4.9 x 0.3 inches

## 5. Maintenance

### 5.1. Cleaning Your Tablet

To clean your tablet, use a soft, lint-free cloth. For stubborn smudges, slightly dampen the cloth with water or a screen-safe cleaning solution. Avoid using harsh chemicals, abrasive materials, or excessive moisture, as these can damage the screen or internal components.

### 5.2. Battery Care

To maximize battery life, avoid exposing the tablet to extreme temperatures. For optimal performance, it is recommended to keep the battery charged between 20% and 80%. If storing the tablet for an extended period, charge it to about 50% before powering it off.

### 5.3. Software Updates

Regularly check for and install software updates to ensure your tablet has the latest features, security patches, and performance improvements. You can typically find update options in the tablet's Settings menu under "About tablet" or "System updates."

## 6. Troubleshooting

### 6.1. Tablet Not Responding

If your tablet becomes unresponsive, perform a forced restart. Press and hold the Power button for approximately 10-15 seconds until the device powers off and then restarts.

### 6.2. Wi-Fi Connectivity Issues

If you experience issues connecting to Wi-Fi, try the following:

- Toggle Wi-Fi off and on in Settings.

- Restart your Wi-Fi router.
- Forget the network in your tablet's Wi-Fi settings and reconnect.

### 6.3. App Crashing or Freezing

If a specific app is crashing, try clearing its cache and data in the tablet's App settings. If the issue persists, uninstall and reinstall the app. Ensure all system updates are installed, as this can resolve compatibility issues.

### 6.4. Performing a Factory Reset

A factory reset can resolve persistent software issues but will erase all data on your tablet. **Back up all important data before proceeding.** To perform a factory reset, go to *Settings > Backup & reset > Factory data reset* Confirm your choice and follow the on-screen instructions. It is recommended to perform all system updates before a factory reset for optimal results.

## 7. Specifications

| Feature | Detail |
|---|---|
| **Model Number** | ME181C-A1-BK |
| **Operating System** | Android 4.4 KitKat |
| **Screen Size** | 8 Inches |
| **Screen Resolution** | 1280 x 800 Pixels |
| **Processor** | 1.33 GHz Intel Atom (4 Processors) |
| **RAM** | 1 GB DDR3 |
| **Hard Drive / Storage** | 16 GB |
| **Wireless Type** | 802.11bgn |
| **USB Ports** | 1 (USB 2.0) |
| **Average Battery Life** | 10 Hours |
| **Item Weight** | 11.2 ounces |
| **Product Dimensions** | 8.3 x 4.9 x 0.3 inches |
| **Color** | Black |
| **Rear Webcam Resolution** | 2 MP |
| **Processor Brand** | Intel |

## 8. Warranty & Support

### 8.1. Product Warranty

The ASUS MeMO Pad 8 ME181C-A1-BK comes with a **1-year North America Warranty**. Please retain your proof of purchase for warranty claims. For detailed terms and conditions, refer to the warranty card included with your product or

visit the official ASUS support website.

### 8.2. Customer Support

For further assistance, technical support, or service inquiries, please visit the official ASUS support website or contact their customer service. You can find contact information and FAQs on the ASUS website.
**ASUS Support Website:** https://www.asus.com/support/

© 2024 ASUS. All rights reserved. Information in this manual is subject to change without notice.


## Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question