

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [vidaXL](#) /

› **vidaXL 8-Tier Fabric Shoe Cabinet with Cover Instruction Manual**

vidaXL 240491

vidaXL 8-Tier Fabric Shoe Cabinet with Cover

MODEL: 240491

Introduction


This manual provides detailed instructions for the assembly, operation, and maintenance of your vidaXL 8-Tier Fabric Shoe Cabinet with Cover. Please read these instructions carefully before assembly and use to ensure proper function and longevity of the product.

The vidaXL 8-Tier Fabric Shoe Cabinet is designed to offer a space-saving and dust-proof solution for organizing your footwear. Its lightweight and portable design allows for flexible placement within your home.

Safety Warnings

WARNING: Furniture tip-over can cause serious or fatal crushing injuries. To prevent tip-over, this product must be permanently attached to the wall using the provided anchoring devices. Always use tip-over restraints.

⚠ WARNING



Children have died from furniture tipover.

- **ALWAYS** secure it with an anchor device.
- **NEVER** allow children to stand, climb or hang on drawers, doors, or shelves.
- **NEVER** open more than one drawer at a time.
- Place heavy items down low.

**NEVER put a TV
on this furniture**



Image: Safety warning regarding furniture tip-over. It illustrates the danger of unsecured furniture and the importance of using anchor devices. It also advises against allowing children to climb on furniture, opening multiple drawers, and placing heavy items high up. A specific warning against placing a TV on the furniture is also included.

- **ALWAYS** secure the cabinet with an anchor device to prevent tip-over.
- **NEVER** allow children to stand, climb, or hang on the shelves.
- Place heavier items on the lower shelves to improve stability.
- Do not overload the shelves.

- Keep the product away from open flames and excessive heat.

Package Contents

Please verify that all components are present before beginning assembly. If any parts are missing or damaged, please contact customer support.

- Long Metal Tubes (for vertical supports)
- Medium Metal Tubes (for horizontal supports)
- Short Metal Tubes (for base and top frame)
- Plastic Connectors (various types for corners and joints)
- Fabric Shelves (8 pieces)
- Fabric Cover with Zipper
- Assembly Diagram (if included in physical package)

Assembly Instructions

Assembly typically requires no tools. Follow these steps carefully:

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, flat surface.
2. **Assemble Base Frame:** Connect the short metal tubes using plastic connectors to form the base rectangle. Ensure all connections are secure.
3. **Install First Level Supports:** Insert long vertical tubes into the base connectors. Then, attach horizontal medium tubes to form the first shelf level using appropriate connectors.
4. **Place First Fabric Shelf:** Slide one fabric shelf over the horizontal tubes of the first level. Ensure it sits flat and taut.
5. **Continue Building Upwards:** Repeat steps 3 and 4 for the remaining seven shelves, building the structure layer by layer. Ensure all tubes are fully inserted into the connectors for stability.
6. **Assemble Top Frame:** Once all shelves are in place, use the remaining short metal tubes and connectors to form the top rectangle of the cabinet.
7. **Apply Fabric Cover:** Carefully drape the fabric cover over the assembled frame. Ensure the bottom edges align with the base.
8. **Secure Cover:** Zip up the front of the cover. The cover features a roll-up door with ties for easy access.



Image: The fully assembled 8-tier fabric shoe cabinet with its black cover zipped closed, providing a neat and enclosed storage solution.



Image: A close-up view of the interior shelves of the shoe cabinet, demonstrating the eight tiers designed for organizing shoes.

Operating Instructions

- **Placing Shoes:** Open the zippered front cover. Place shoes on each of the eight fabric shelves. Distribute weight evenly across the shelves.
- **Using the Cover:** The fabric cover protects your shoes from dust and keeps them out of sight. To access shoes, unzip the front panel. The panel can be rolled up and secured with the attached ties at the top for continuous access.
- **Portability:** Due to its lightweight design, the cabinet can be moved if needed. Ensure it is empty

before attempting to move it to prevent damage or injury.



Image: Detail of the roll-up door feature, illustrating how the front fabric panel can be rolled up and fastened with ties for easy access to the shelves.

Maintenance and Care

- **Cleaning the Fabric Cover and Shelves:** Wipe down the fabric surfaces with a damp cloth and mild soap if necessary. Do not use harsh chemicals or abrasive cleaners. Allow to air dry completely.
- **Cleaning the Metal Frame:** The metal tubes can be wiped clean with a damp cloth.
- **Inspection:** Periodically check all connections to ensure they remain secure. Tighten any loose connections to maintain stability.
- **Storage:** If disassembling for storage, ensure all parts are clean and dry. Store in a cool, dry place away from direct sunlight.

Troubleshooting

Issue: Cabinet feels unstable or wobbly.

Solution: Ensure all metal tubes are fully inserted into their plastic connectors. Check that the cabinet is

placed on a flat, level surface. If applicable, ensure the anti-tip device is securely installed.

Issue: Zipper on the cover is difficult to close or gets stuck.

Solution: Ensure the fabric cover is correctly aligned on the frame and not stretched too tightly. Gently guide the zipper. Avoid forcing it, as this can cause damage.

Issue: Missing parts during assembly.

Solution: Double-check all packaging materials. If parts are genuinely missing, contact vidaXL customer support with your product model number and a description of the missing parts.

Specifications

Model Number	240491
Brand	vidaXL
Color	Black
Material	Fabric (Non-woven), Powder-coated Steel Tubes, Plastic Connectors
Dimensions (D x W x H)	11" x 22" x 64" (29 cm x 57 cm x 162 cm)
Number of Tiers/Shelves	8
Shoe Capacity	Up to 20 pairs (approximate, depending on shoe size)
Item Weight	5.72 pounds (2.6 kg)
Assembly Required	Yes



Image: Dimensional drawing of the shoe cabinet, indicating a height of 162 cm (64 inches), a width of 57 cm (22 inches), and a depth of 29 cm (11 inches).

Warranty Information

All products sold by vidaXL are covered by a legal guarantee of at least 2 years. Please retain your proof of purchase for warranty claims. For specific terms and conditions, refer to the vidaXL official website or contact customer support.

Customer Support

If you encounter any issues during assembly or use, or if you have questions about your product, please

contact vidaXL customer support. Have your model number (240491) and proof of purchase ready when contacting support.

For the most up-to-date contact information, please visit the official vidaXL website:

www.vidaxl.com/customer-service