

[Manuals.plus](#) /

› [Cora](#) /

› Cora SMARTLINE SLBB22C1BLK 2200 mAh Power Bank User Manual

Cora SLBB22C1BLK

Cora SMARTLINE SLBB22C1BLK 2200 mAh Power Bank User Manual

Model: SLBB22C1BLK | Brand: Cora

INTRODUCTION

Thank you for choosing the Cora SMARTLINE SLBB22C1BLK 2200 mAh Power Bank. This portable power bank is designed to provide convenient charging for your mobile devices on the go. Please read this manual carefully before using the product to ensure proper operation and to maximize its lifespan.

PACKAGE CONTENTS

- Cora SMARTLINE SLBB22C1BLK 2200 mAh Power Bank
- USB Charging Cable (Micro-USB to USB-A)
- User Manual

PRODUCT OVERVIEW

Familiarize yourself with the components of your power bank.



Image 1: Front view of the Cora SMARTLINE SLBB22C1BLK Power Bank. This image shows the compact design of the power bank, typically featuring a USB output port, a Micro-USB input port, and an LED indicator.

1. **USB Output Port:** For charging your mobile devices.
2. **Micro-USB Input Port:** For charging the power bank itself.
3. **LED Indicator:** Shows charging status and remaining battery level.
4. **Power Button (if applicable):** To check battery level or initiate charging.

SETUP

Charging the Power Bank

1. Connect the small end of the provided USB cable (Micro-USB) to the input port of the power bank.
2. Connect the large end of the USB cable (USB-A) to a USB wall charger (not included) or a computer's USB port.
3. The LED indicator(s) on the power bank will illuminate or flash to indicate that it is charging. Once fully charged, the indicator(s) will typically show a solid light or turn off.
4. Disconnect the cable once charging is complete.

Note: For optimal performance, fully charge the power bank before its first use.

OPERATING

Charging Your Device

1. Connect your device's charging cable (e.g., USB-A to Lightning, USB-A to USB-C, or USB-A to Micro-USB) to the

USB output port of the power bank.

2. Connect the other end of your device's charging cable to your mobile device.
3. The power bank should automatically begin charging your device. If not, press the power button on the power bank (if available) to initiate charging.
4. The LED indicator(s) on the power bank will show that it is actively discharging.
5. Disconnect your device once it is fully charged or when you no longer need to charge it.

Checking Battery Level

Press the power button (if available) briefly to check the remaining battery level of the power bank. The LED indicator(s) will light up to show the current charge status.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the power bank. Do not use liquid cleaners or aerosols.
- **Storage:** Store the power bank in a cool, dry place away from direct sunlight, extreme temperatures, and humidity.
- **Battery Care:** To prolong battery life, fully charge the power bank at least once every three months, even if not in regular use.
- **Avoid Damage:** Do not drop, disassemble, or attempt to repair the power bank yourself. This may void the warranty and cause damage.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Power bank not charging	Cable not connected properly Faulty charging cable Wall adapter not working	Ensure all connections are secure. Try a different USB charging cable. Use a different USB wall adapter or computer port.
Device not charging from power bank	Power bank battery is empty Device charging cable is faulty Power bank is not activated	Recharge the power bank. Try a different charging cable for your device. Press the power button on the power bank to start charging.
Slow charging	Low output current from power bank High power consumption by device Cable quality	Ensure the power bank is fully charged. Close unnecessary apps on your device. Use a high-quality charging cable.

SPECIFICATIONS

- **Model:** SLBB22C1BLK
- **Capacity:** 2200 mAh
- **Input:** 5V
- **Output:** 5V
- **Manufacturer:** PURO

- **ASIN:** B00JP6IALG
- **EAN/UPC:** 08033830098369

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation provided with your purchase or contact your retailer. As specific warranty terms can vary by region and retailer, it is recommended to consult the official Cora or PURO website for the most up-to-date information.

For further assistance, please visit the manufacturer's website or contact their customer service department. Keep your purchase receipt for warranty claims.

© 2023 Cora. All rights reserved. Information in this manual is subject to change without notice.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question