

[Manuals.plus](#) /

› [Motorola](#) /

› Motorola RMN5050A Moto Turbo Desktop Microphone User Manual

Motorola RMN5050

Motorola RMN5050A Moto Turbo Desktop Microphone User Manual

Model: RMN5050

1. PRODUCT OVERVIEW

The Motorola RMN5050A is an original Moto Turbo Desktop Microphone designed for use with compatible Motorola mobile radios. This microphone provides clear audio transmission and reception, enhancing communication efficiency in various professional environments. Its robust design ensures durability and reliable performance.



Image 1.1: The Motorola RMN5050A Moto Turbo Desktop Microphone, featuring its sturdy base, coiled cable, and multi-pin connector. The microphone unit includes a Motorola logo and several control buttons.

Key Features:

- Color: Black
- Compatible with MOTOTRBO XPR4300, XPR4500, and XPR4550 mobile radios.
- Omnidirectional polar pattern for versatile audio pickup.
- Corded electric power source.

2. PACKAGE CONTENTS

Please verify that all items listed below are present in your product package:

- Motorola RMN5050A Desktop Microphone
- Warranty Card

3. SETUP

Connecting the Microphone

Follow these steps to properly connect your desktop microphone to a compatible mobile radio:

1. Ensure your mobile radio (e.g., MOTOTRBO XPR4300, XPR4500, XPR4550) is powered off.
2. Locate the microphone port on your mobile radio. This is typically a multi-pin connector.
3. Align the multi-pin connector of the RMN5050A desktop microphone with the port on the radio.
4. Gently push the connector into the port until it clicks securely into place. Do not force the connection.
5. Once connected, you may power on your mobile radio. The microphone draws power directly from the radio.

4. OPERATION

Basic Use

The Motorola RMN5050A desktop microphone is designed for straightforward communication. To transmit, press and hold the Push-To-Talk (PTT) button located on the microphone unit. Speak clearly into the microphone. Release the PTT button to listen for incoming transmissions.

Microphone Placement

For optimal audio quality, position the desktop microphone on a stable surface, such as a desk, at a comfortable distance from the user. As it features an omnidirectional polar pattern, it picks up sound equally from all directions. Ensure there are no obstructions between the speaker and the microphone to prevent muffled audio.

5. MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your Motorola RMN5050A desktop microphone.

- **Cleaning:** Use a soft, dry cloth to wipe down the exterior of the microphone. For stubborn dirt, a slightly damp cloth with mild soap can be used, ensuring no moisture enters the microphone grille or connector.
- **Storage:** When not in use for extended periods, store the microphone in a clean, dry environment away from extreme temperatures and direct sunlight.
- **Cable Care:** Avoid sharp bends or kinks in the coiled cable. Do not pull the microphone by its cable when disconnecting it from the radio; always grasp the connector itself.

6. TROUBLESHOOTING

This section addresses common issues you might encounter with your desktop microphone.

Problem	Possible Cause	Solution
No audio output from microphone	Microphone not properly connected.	Ensure the microphone connector is fully seated and locked into the radio's port.
Intermittent audio transmission	Loose connection or damaged cable.	Check the connection. Inspect the cable for visible damage. If damaged, contact support.

Problem	Possible Cause	Solution
Poor audio quality (muffled, distorted)	Microphone too far or too close; obstruction; dirty grille.	Adjust microphone position. Ensure clear path to speaker. Clean microphone grille if necessary.
Microphone buttons unresponsive	Radio not powered on or microphone not recognized.	Verify radio is powered on. Disconnect and reconnect the microphone.

7. SPECIFICATIONS

Feature	Detail
Model Number	RMN5050
Color	Black
Connectivity Technology	XLR (Multi-pin connector for radio)
Polar Pattern	Omnidirectional
Power Source	Corded Electric (powered by radio)
Item Weight	14.4 ounces (approx. 0.9 lbs)
Product Dimensions (L x W x H)	9 x 5 x 3 inches
Compatible Radios	MOTOTRBO XPR4300, XPR4500, XPR4550 mobile radios
Date First Available	April 15, 2014
Manufacturer	Motorola

8. WARRANTY AND SUPPORT

Your Motorola RMN5050A Desktop Microphone comes with a warranty. Please refer to the included warranty card for detailed information regarding coverage, terms, and conditions. It is recommended to retain your proof of purchase for warranty claims.

For technical assistance, troubleshooting beyond this manual, or warranty service, please contact Motorola customer support. Contact information can typically be found on the Motorola official website or on the warranty card provided with your product.

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question