



Manuals.plus /

› Gemmy /

› Gemmy Lightshow Projection- Kaleidoscope -Red/ Green

Gemmy B00JRFGI00

Instruction Manual

Product: Gemmy Lightshow Projection - Kaleidoscope - Red/Green

Model: B00JRFGI00 | **Brand:** Gemmy

1. INTRODUCTION

The Gemmy Lightshow Projection Kaleidoscope is designed to create a dazzling visual effect for outdoor decoration. This spotlight projects a green and red kaleidoscope pattern, ideal for enhancing the festive appearance of your home. Its durable construction is suitable for outdoor use and is ETL listed for safety.

2. SAFETY INFORMATION

- This product is intended for decorative purposes only and is not a toy.
- For outdoor use only. Do not use indoors.
- Ensure the power cord is not damaged and is connected to a 110-volt outlet.
- Do not stare directly into the light source, as it is very bright.
- Keep away from children and pets.
- Do not attempt to disassemble or modify the product.
- Always unplug the unit from the power outlet before cleaning or when not in use.

3. PACKAGE CONTENTS

Please ensure all items are present before proceeding with installation:

- Gemmy Lightshow Projection Kaleidoscope Unit
- Ground Stake (pre-attached or separate)
- Power Cord (5-foot long, attached)



Figure 3.1: Front of the product packaging, illustrating the projector and its light display.

4. SETUP

1. **Choose a Location:** Select a suitable outdoor location for the projector. Consider the desired projection area on your home, trees, garage door, or shrubbery. The projector can project up to 20 feet.
2. **Install the Stake:** If the ground stake is separate, securely attach it to the projector unit. Insert the stake firmly into the ground in your chosen location.
3. **Position the Projector:** Adjust the angle of the projector to direct the light show onto the desired

surface.

4. **Connect to Power:** Plug the 5-foot power cord into a standard 110-volt outdoor electrical outlet. Ensure the outlet is protected from weather elements.



Figure 4.1: Product packaging illustrating potential projection surfaces.

5. OPERATING INSTRUCTIONS

The Gemmy Lightshow Projection Kaleidoscope is designed for simple operation:

1. Once the unit is securely placed and plugged into a live 110-volt outdoor outlet, the projector will

automatically turn on and begin displaying the red and green kaleidoscope light show.

2. To turn off the projector, simply unplug it from the power outlet.

6. MAINTENANCE

- **Cleaning:** Ensure the unit is unplugged before cleaning. Use a soft, dry cloth to wipe the exterior of the projector. Do not use abrasive cleaners or immerse the unit in water.
- **Storage:** When not in use, store the projector in a cool, dry place, away from direct sunlight and extreme temperatures. It is recommended to store it in its original packaging to protect it from dust and damage.
- **Weather Resistance:** The durable plastic design is built to resist corrosion in winter elements. However, for prolonged product life, consider bringing the unit indoors during severe weather conditions.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Projector does not turn on.	No power to the outlet. Power cord is damaged.	Check the power outlet with another device. Inspect the power cord for damage. If damaged, discontinue use and replace the unit.
Light is dim or flickering.	Low voltage. Lens is dirty.	Ensure the outlet provides stable 110-volt power. Clean the projector lens gently with a soft, dry cloth.
Projection is not clear.	Projector is too far from the surface. Lens is dirty.	Move the projector closer to the projection surface (maximum 20 ft). Clean the projector lens gently with a soft, dry cloth.

8. SPECIFICATIONS

Product Dimensions: 8.31 x 4.8 x 4.09 inches

Item Weight: 1.1 pounds

ASIN: B00JRFGI00

Power Requirement: 110 Volt Outlet

Cord Length: 5 feet

Projection Distance: Up to 20 feet

Usage: Outdoor Use Only

Certifications: ETL Listed


Manufacturer: Gemmy

LED LIGHTSHOW®

Projection™

KALEIDOSCOPE™

Turning, Swirling Light



This item is not a toy and should be used for decorative purposes only. Actual item may vary slightly from photo. **WARNING: The light is very bright. Do not shine directly into eyes.** Detailed instruction sheet included. For Indoor and Outdoor Use.

U.S. Patent 9,068,726



©2016 GEMMY INDUSTRIES CORP
117 WRANGLER DRIVE, SUITE 100
COPPELL, TX 75019 U.S.A.
MADE IN CHINA
WWW.GEMMY.COM



Item # 88610

Figure 8.1: Back of the product packaging with additional details and warnings.

9. WARRANTY AND SUPPORT

For information regarding warranty coverage or technical support, please refer to the contact information provided on the product packaging or visit the official Gemmy website. Keep your purchase receipt as proof of purchase.

Gemmy Industries Website: www.gemmy.com

